























## RF\_FRONT\_END P{4,5,6,10} RF\_IN\_SPDT GPS IRIDUM ANT RF\_IN\_IRIDUM C4N1 NPO 10pF 5% 0402 50V NM R10939 0E 0402P C4N2 NPO 10pF 5% 0402 50V 3.3VD TIVA U.FL-R-SMT-1 C2609 33pF 0402P X7R 50V U2604 <sup>2</sup> R2610 > 100K > 0402P 63mW ±1% DNP R2611 100K 0402P 63mW ±1% LAYOUT: Place these resistor(R874,R875) as crowfeet option(3PAD) GND\_1 VCC 0E 0402P RF IN SPDT ENB R2612 1K 63mW SPDT\_CNTRL\_IN R10945 0E 0402P SPDT\_CNTRL 0402P 11% P{4,5,6,10} R874 GND\_2 CTRL 3.3VD\_TIVA GND\_3 RF3 GND\_4 R10931 0E 0402P 0E R10930 SKY13330-397LF 0402P C4478 1uF C4477 C4479 0.1uF C4480 33pF 0402P X6S 16V 0402P X7R 25V 0402P X7R 50V 0402P X7R 50V R10922 0E LAYOUT: Place these resistors(R10924,R10925 and R876) in PI PAD provision for the Input to the IC(U2605). LAYOUT: Place these resistor(R10922,R10923) as crowfeet option(3PAD) 0402P LAYOUT: Place these resistors(R10927,R10926 and R878) in PI PAD provision for the Input to the IC(U2606). U2605 U2606 (10923 OF 0402R R10924 0E 0402P INPUT PON VCC L4001 6.8nH R10926\_ 0E \_\_\_0402P\_\_ GPS\_LNA\_INC4462 GND1 GPS\_LNA\_OUT R10925 0E 0402P DNP R876 0E 0402P DNP OUTPUT AO 3 GND2 5 GND3 GNDRF GND R10927 0E 0402P DNP R10928 0E 0402P DNP 857139 BGA824N6 0E 0402P LAYOUT: Place these resistor(R10935,R10936) as crowfeet option(3PAD) LAYOUT: Place these resistor(R10937,R151,R10938) as crowfeet option(4PAD) DNP LAYOUT: Place these resistor(R10923,R150) as crowfeet option(3PAD) 151 0E 0402R U2607 0402P OF R10935 0402P OF R10932 INPUT GND\_ RF\_IN\_LTE P{10} OUT 0E 0402P DNP OUTPUT GND2 R10938 0E 0402P GND3 857140 DNP \ **FACEBOOK CONNECT1** DOCUMENT NUMBER: 00 TITLE: RF FRONT END REV: Life-3 SHEET 13 OF 14

