


В

This footprint shows the XY space available for installing a custom tool.

When designing custom tools, a tool may take up the space specified below without interfering with the build plate volume and without colliding with other tools provided that:

A: Tool active centers (nozzles, spindles, etc) must remain within 30mm from the carriage coupling plate.

В



Dimensions of these regions are driven by constraints from the frame geometry (see dimensions on the previous page), not from a desired total number of tools. Any number of tools (usually about 4) may be added provided that the sum of tool widths does not exceed 409mm.

Tool Max XY Footprint		
© BY	Created by: Joshua Vasquez	last edited: 1/6/2020
	SCALE: 1:3.5	SHEET 2 OF 2

of the machine.