
Install the insert using the plate-press technique.

В



Explodled View



В

Assembled View

A


ITEM NO.	DESCRIPTION	QTY.
1	M3 Tapered Heat Set Insert	1
2	Tool Holder	1

Created by Joshua Vasquez	TITLE: Insert Installation		
last edited:	UNLESS OTHERWISE SPI DIMENSIONS ARE BREAK ALL SHARP	IN MM	
MATERIAL	SCALE: 1:1	SHEET 1 OF 4	


2


В

Install the dowel pins with an arbor press, ensuring that they seat vertically, not at an angle.



Exploded View





Assembled View

Created by Joshua Vasquez	TITLE: Tool Holder Assembly		
last edited:	UNLESS OTHERWISE SPECIFIED: DIMENSIONS ARE IN MM BREAK ALL SHARP EDGES		SIZE A REV
MATERIAL	SCALE: 1:1 SHEET 2 OF		OF 4


В

2


-

В

В



Keep these nuts loose; only two full turns. They will be tightened into the frame later.




Assembled View

Α

ITEM NO.	DESCRIPTION	QTY.
1	Parking Post Base	1
2	M5 x 0.8 Screw, Low Profile, 10mm	2
3	M3 Tapered Heat Set Insert	1
4	M5 Drop-In T-Nut for 20x20 Extrusion	2

Created by Joshua Vasquez	TITLE: Parking Post Base Assembly		
last edited:	UNLESS OTHERWISE SPECIFIED: DIMENSIONS ARE IN MM BREAK ALL SHARP EDGES		SIZE A REV 1.0
MATERIAL	SCALE: 1:1	SHEET 3 OF 4	






Exploded View

When dialing in the parking location on the frame, loosen this screw to adjust vertical height of the parked tool.

And loosen these screws to adjust the horizontal location of the parked tool.~

В



Assembled View

ITEM NO.	DESCRIPTION	QTY.
1	Parking Post Base Assembly	1
8	Tool Holder Assembly	1

Created by Joshua Vasquez	TITLE: Final Asse	mbly	
last edited:	UNLESS OTHERWISE SPECIFIED: DIMENSIONS ARE IN MM BREAK ALL SHARP EDGES		SIZE A REV
MATERIAL	SCALE: 1:1	SHEET 4	OF 4

В