




Install the following three M3 Heat Set Inserts in their respective locations using the Plate Press technique.


В





**Exploded View** 





Assembled View

| ITEM NO. | DESCRIPTION                | QTY. |
|----------|----------------------------|------|
| 1        | M3 Tapered Heat Set Insert | 3    |
| 2        | 47mm Tool Holder           | 1    |
| 3        | 3 47mm Parking Post Base   |      |


| Heat Set Insert Installation |            |                |              |  |
|------------------------------|------------|----------------|--------------|--|
|                              | <b>(1)</b> | Created by:    | last edited: |  |
|                              | BY         | Joshua Vasquez | 2/15/2020    |  |
|                              |            | SCALE: 1:1     | SHEET 2 OF 5 |  |

2


Α

В

Carefully press fit the two dowel pins into the Tool Holder (with an arbor press) until they are flush with the bottom of the part.



Exploded View



Assembled View

| ITEM NO. | DESCRIPTION              | QTY. |
|----------|--------------------------|------|
| 1        | M5 Dowel Pin, 60mm len   | 2    |
| 2        | Tool Holder with Inserts | 1    |

| Dowel Pin Installation |                            |                        |  |
|------------------------|----------------------------|------------------------|--|
| CC BY                  | Created by: Joshua Vasquez | last edited: 2/15/2020 |  |
|                        | SCALE: 1:1                 | SHEET 3 OF 5           |  |

В


A

2

В

Exploded View

Install this screw all the way, but do not tighten it. >




Keep these nuts loose (about 2-3 turns).

| F | 7 |
|---|---|
|   |   |

| ITEM NO. | DESCRIPTION QTY.                     |   |  |  |
|----------|--------------------------------------|---|--|--|
| 1        | Parking Post Base with Inserts       | 1 |  |  |
| 2        | M5 Buttonhead Screw, 10mm long       | 2 |  |  |
| 3        | M5 Drop-In T-Nut for 20x20 Extrusion | 2 |  |  |
| 4        | 4 M3 Buttonhead Screw, 8mm long      |   |  |  |

| Parking Post Base Screw Prep |            |                |              |
|------------------------------|------------|----------------|--------------|
| ( )                          | <b>(i)</b> | Created by:    | last edited: |
|                              | BY         | Joshua Vasquez | 2/15/2020    |
|                              |            | SCALE: 1:1     | SHEET 4 OF 5 |




**Exploded View** 

When the post is installed on the machine, use the top screw to fine-tune the height at the parking location.

В

Use the two screws in the pockets to set the parking position.



| ITEM NO.                  | DESCRIPTION                   | QTY. |
|---------------------------|-------------------------------|------|
| 1                         | Parking Post Base Subassembly | 1    |
| 2 Tool Holder Subassembly |                               | 1    |
| 3                         | M3 Buttonhead Screw, 8mm long | 2    |

Assembled View

| Final Assembly |                        |                |              |
|----------------|------------------------|----------------|--------------|
|                | $\widehat{\mathbf{f}}$ | Created by:    | last edited: |
| (00)           | BY                     | Joshua Vasquez | 2/15/2020    |
|                |                        | SCALE: 1:1     | SHEET 5 OF 5 |

В

A

2