


ITEM NO.	DESCRIPTION	QTY.
1	M3 18mm standoff, 6mm wide	1
2	M4 shoulder screw, 20mm-I, 5mm-d	2
3	20T toothless idler, 5mm bore	1
4	20T Idler pulley, 2GT, 5mm bore	1
5	M5 Shim, 0.2mm thick	2
6	Printed Pulley Spacer	2
7	Crossbar Pulley Reinforcement Plate	1
8	M3 Buttonhead Screw, 6mm long	1

Note the orientation of the Reinforcement Plate

Α




Left Crossbar Pulley Assembly
-------------------------------

	Created by:	last edited:
BY	Joshua Vasquez	2/2/2020
	SCALE: 1:1	SHEET 2 OF 6

Δ

В






A

В

ITEM NO.	DESCRIPTION	QTY.
1	Pocketed Crossbar	1
2	Left Crossbar Pulley Assembly	
3 M3 Buttonhead Screw, 10mm long		1

Left Crossbar Pulley Installation			
<u>@</u>	BY	Created by: Joshua Vasquez	last edited: 2/2/2020
		SCALE: 1:3	SHEET 3 OF 6

В



ITEM NO.	DESCRIPTION	
1	Crossbar X Limit Trigger	1
2	M3 10mm standoff, 4.5mm wide	1
3	M4 shoulder screw, 20mm-l, 5mm-d	2
4	M5 Shim, 0.2mm thick	
5	20T Idler pulley, 2GT, 5mm bore	1
6	20T toothless idler, 5mm bore	1
7	Printed Pulley Spacer	1
8	Crossbar Pulley Reinforcement Plate	
9	M3 Buttonhead Screw, 6mm long	1

This Side is short.

This Side is long.

В


Right Crossbar Pulley Assembly			
	Created by:	last edited:	
BY	Joshua Vasquez	2/2/2020	
	SCALE: 1:1	SHEET 4 OF 6	

2


•

Α

В







ITEM NO.	DESCRIPTION	QTY.
4	M3 Buttonhead Screw, 16mm long	1
5	M3 Buttonhead Screw, 10mm long	17
6	395mm long MGN12 rail	
7	7 M3 Locknut	
8	8 MGN12C Carriage Block	

В

**Assembled View** 

Sheet3			
(C) (B)	Created by: Joshua Vasquez	last edited: 2/2/2020	
	SCALE: 1:2	SHEET 6 OF 6	

В