Forge Viewer Sectioning


Eason Kang

Autodesk Developer Network (ADN) & FPD

AUTODESK UNIVERSITY CHINA 2018





- Overview:
 - Take advantage of Viewer3D#setCutPlanes(planes: THREE.Vector4[])
 - Equation of the section plan ax + by + cz + d = 0




Isometric view

Front view (Y direction)







● 康益昇 (Eason ... = -

Download WeChat for Windows

Autodesk Forge 二号群

Autodesk Forge 讨论群

文件传输助手

<u>}=</u>

Q Search

Is it possible to create section planes regarding to the elevation?




Copyright (c) Tencent Holdings, Ltd. All rights reserved



X

viewer.setCutPlanes([new THREE.Vector4(-1, 0, 0, 0)])


viewer.setCutPlanes([new THREE.Vector4(-1, 0, 0, -23.45)])




Z


viewer.setCutPlanes([new THREE.Vector4(0, 0, 1, 0)])

viewer.setCutPlanes([new THREE.Vector4(0, 0, 1, -12.81)])






viewer.setCutPlanes([new THREE.Vector4(0, 0, 1, 12.81)])





The relation of the d value and the section plane when plan normal is in positive direction:




viewer.setCutPlanes([new THREE.Vector4(0, 0, -1, 0)])

viewer.setCutPlanes([new THREE.Vector4(0, 0, -1, -12.81)])







viewer.setCutPlanes([new THREE.Vector4(0, 0, -1, 12.81)])





The relation of the d value and the section plane when plan normal is in negative direction:



Do sectioning with Revit's elevations








Do sectioning with Revit's elevations_{2. Convert length units (From SI to IM)}, 2700mm = 8.85 ft



Celling, EL. 2700 mm


Levell, EL. 0 mm



Celling, d= 1.575

Levell, d= 0

- 1. Obtain z value of the celling level, 2700mm
- 3. Convert coordinate system (From Revit to Viewer):
 - GobalOffset = model.getData().globalOffset
 - z = 8.85 GobalOffset.z = -1.575 units
- 4. Convert coordinate system (From Viewer to Section plane):




- 5. Create planes:
 - planeUpper = new THREE. Vector4(0, 0, 1, 1.575)
 - viewer.setCutPlanes([planeUpper])

Do sectioning with Revit's elevations



- 1. Obtain z value of the Level 1 Living Rm, -550mm
- 2. Convert length units (From SI to IM) $^{\circ}$ -550mm = -1.804 ft
- 3. Convert coordinate system (From Revit to Viewer):
 - GobalOffset = model.getData().globalOffset
 - z = -1.804 GobalOffset.z = -12.237 units
- 4. Convert coordinate system (From Viewer to Section plane):




- d = -12.237
- 5. Create planes:
 - planeLower = new THREE. Vector4(0, 0, -1, -12.237)
 - viewer.setCutPlanes([planeLower])




https://forge.autodesk.com/blog/viewer-setcutplanes

Do sectioning with Revit's elevations




Section planes for elevations:

- planeUpper = new THREE.Vector4(0, 0, 1, 1.575)
- planeLower = new THREE. Vector4(0, 0, -1, -12.237)
- viewer.setCutPlanes([planeUpper, planeLower])



Level 1 Living Rm., d= -12.237



https://github.com/yiskang/forge-au-sample



Autodesk and the Autodesk logo are registered trademarks or trademarks of Autodesk, Inc., and/or its subsidiaries and/or other countries. All other brand names, product names, or trademarks belong to their respective holders. Autodesk reserves the right to alter product and services offerings, and specifications and pricing at any time without notice, and is not responsible for typographical or graphical errors that may appear in this document.

© 2018 Autodesk. All rights reserved.

