

Cornfed 1" Front Spacer Lift

Monday, August 10, 2026 1:02 PM

I purchased this level lift from someone here on the forum as well. It's the Cornfed 1" spacer level lift. The instructions that came from the lift mfg are pretty basic but it's really a straight forward install. I did watch a couple YouTube videos to get familiar with what all I needed to do. This was helpful as I needed a couple sockets and tools I didn't already have. This is the first real wrenching I've done on the truck too, so I wanted to make sure.

Front measurements before lift (all measured from ground up to bottom edge of factory fender flare as seen in the pic below):



Driver = 35-1/4"

Passenger = 35-3/8"

Front end measurements after lift:

Driver = 36-1/2"

Passenger = 36-5/8"

I'm super happy with how it turned out! It leveled it out a bit more and still have some rake, which is what I wanted. I have the Sport model so it brought it back up some that the factory natural drop is for that suspension type it came with. I didn't upgrade anything having to do with the suspension - just added the spacers for struts and bumpstop spacers.

Unfortunately, I didn't get a good before side profile shot... but here is a side by side I have. The left pic is the first day I picked it up at the dealership (best pre-lift profile pic I had) and the right pic is right after I installed the spacer level lift. You can definitely get an idea there is a change:



I did take it in for an alignment at the dealership after I did this and the wheel spacers and it's a good thing I did! The alignment was out pretty far so it was corrected.