

Glovebox Lighting

Monday, August 10, 2026 1:07 PM

This one was not intentional but I decided to knock it out while I was installing the footwell lighting.

Cost = \$5.30 (for the harness I bought)

Parts:

One male to female connector 90980-12937 from AliXpress

One repurposed OEM passenger footwell light (free!)

Step 1: I used the short wire harness I had ordered and I extended it with some additional wire. I added about 18" or so to it.

Step 2: Remove the passenger OEM light and connect the male end of you made harness to where the light was at the footwell area. Route the rest of the harness around the glovebox and connect it to the light you just removed.

Step 3: Then plug it into the slot where the cutout is above the glovebox ceiling. You'll feel it with your hand up top when you open the glovebox and see from the inside - that's where the light will shine through. To route this, you'll need to remove at lease the passenger side trim of the front dash and I also removed the top piece connected to the vent and started back the long piece that travels across the entire dash has "Tundra" letters recessed in the trim piece. You won't want to take that entire piece out but just bring it back enough to get your hands in to place the light in the spot above the glovebox. Here's a pic of the wire from the side trim piece that's out. It's a TIGHT fit without removing any more trim but it's doable. You can see my white and green wires traveling along the red line I drew and I circled the light that's already in place above the glovebox.



Now just button back up all the trim and enjoy some repurposed light in that darkness of a pit of a glovebox! Yay, now I can see all my boring papers and manual I never read!

