


В



Press-fit each dowel pin into each socket until it is flush with the surface.

ITEM NO.	DESCRIPTION	QTY.
1	Carriage Front Plate	1
2	M4 Dowel Pin, 20mm long	6
3	Pin Insertion Fixture	1


Use the pin insertion fixture to hold the Carriage Front Plate at the right angle for pin insertion.

Coupling Plate Assembly			
	<b>(i)</b>	Created by:	last edited:
CC	BY	Joshua Vasquez	4/11/2020
		SCALE: 1:1	SHEET 2 OF 7

Α

В







Step 2: Loosely install both screw components such that they engage the threads. The set screw should not peek out into the center hole. The buttonhead screw will be tightened later.



В

A

В

ITEM NO.	DESCRIPTION	QTY.
1	Tool Lock Pulley with Insert	1
2	M3 Square Nut	1
3	M3 Buttonhead Screw, 6mm long	1
5	M3 Set Screw, 8mm long	1


Pulley Assembly


Created by: last edited:

Joshua Vasquez 4/11/2020

SCALE: 1:1 SHEET 3 OF 7

2





ITEM NO.	DESCRIPTION	QTY.
1	Twist Lock Shaft	1
2	M3 Dowel Pin, 12mm long	1
3	M3 Set Screw, 3mm long	1
4	E-Clip	1
5	M5 Shim, 0.2mm thick	2
6	Twist Lock Spacer	1

Twist Lock Assembly			
Created by: last edited:  Joshua Vasquez  4/11/2020			
		SCALE: 1:1	SHEET 4 OF 7

В

A

В

2

(Optional: twist the wires into two pairs for easier cable management.)

Solder two wires to the outer ends of each limit switch with the wires bent in the directions shown above. Note that the direction is different for each limit switch!

А


ITEM NO.	DESCRIPTION	QTY
1	900mm of 26AWG stranded white wire	4
2	Dust Proof Limit Switch	2

Wiring Installation			
<u>@</u>	<b>(i)</b>	last edited: 4/11/2020	
		SCALE: 1:1	SHEET 5 OF 7


В

Select the limit switch with wires bent towards the button.





Exploded View




В

Assembled View

ITEM NO.	DESCRIPTION	QTY.
1	Belt Clasp	2
2	Dust-Proof Limit Switch	1
3	M3 Buttonhead Screw, 8mm long	3
4	Carriage Back Plate with Inserts	1

Carriage Back Plate Assembly			
Created by: last edited:  Joshua Vasquez 4/11/2020			
		SCALE: 1:1	SHEET 6 OF 7

Select the limit switch with wires bent away from the button. Route the wires as shown above.



Set all completed subassemblies aside for installation on the CoreXY frame at a later step.

F	4

ITEM NO.	DESCRIPTION	
1	Dust-Proof Limit Switch with wires installed	1
2	M3 Buttonhead Screw, 8mm long	1
3	Carriage Center Plate	1

Carriage Center Assembly			
Created by: Joshua Vasquez    last edited: 4/11/2020			
		SCALE: 1:1	SHEET 7 OF 7

В

2