



NOTE: This assemby step is for generic brand pulleys only. If you are using genuine Gates brand pulleys, skip this page and see the next page.


В

Note the plate orientation!



Top View





В

Assembled View

| 1 | ۸. | |
|---|----|--|
| r | ┪. | |
| • | • | |

| ITEM NO. | DESCRIPTION | |
|----------|--------------------------------------|---|
| 1 | M3 20mm standoff, 6mm wide | 2 |
| 2 | Back Left Pulley Reinforcement Plate | 1 |
| 3 | M4 Shoulder Screw, 25mm long | 1 |
| 4 | M3 Buttonhead Screw, 8mm long | 2 |
| 5 | M5 Shim, 0.2mm thick | 4 |
| 6 | 20T Idler pulley, 2GT, 5mm bore | 2 |
| 7 | M5 Washer, 0.8-1.2mm thick | 2 |

Left Corner Generic Pulley Assembly

| | Created by: | last edited: |
|--------|----------------|--------------|
| CCC BY | Joshua Vasquez | 3/23/2020 |
| | SCALE: 1:1 | SHEET 2 OF 7 |

2

.

NOTE: This assemby step is for Gates brand pulleys only. If you are using generic brand pulleys, skip this page and see the previous page.


В


Note the plate orientation!


This side is short.

This side is long.










Exploded View



В

Assembled View

Α

| ITEM NO. | DESCRIPTION | QTY. |
|----------|--------------------------------------|------|
| 1 | M3 20mm standoff, 6mm wide | 2 |
| 2 | Back Left Pulley Reinforcement Plate | 1 |
| 3 | M4 Shoulder Screw, 25mm long | 1 |
| 4 | M3 Buttonhead Screw, 8mm long | 2 |
| 5 | M5 Shim, 0.2mm thick | 2 |
| 6 | 20T Idler pulley, 2GT, 5mm bore | 2 |


Left Corner Gates Pulley Assembly


Created by: last edited:

| | Created by: | last edited: |
|-------|----------------|--------------|
| CC BY | Joshua Vasquez | 3/23/2020 |
| | SCALE: 1:1 | SHEET 3 OF 7 |

2

•





Assembled View

| ITEM NO. | DESCRIPTION | |
|----------|-----------------------------------------|---|
| 1 | Left Corner Plate with Insert Installed | 1 |
| 3 | Left Corner Pulley Assembly | 1 |
| 6 | M3 Buttonhead Screw, 10mm long | 2 |
| 7 | M5 x 0.8 Screw, Low Profile. 20mm | 3 |
| 10 | M5 Drop-In T-Nut for 20x20 Extrusion | 3 |
| 11 | M5 Washer, 0.8-1.2mm thick | 2 |

| Left Corner Pulley Plate Assembly | | | |
|-----------------------------------|----------------|--------------|--|
| | Created by: | last edited: | |
| BY | Joshua Vasquez | 3/23/2020 | |
| | SCALE: 1:1 | SHEET 4 OF 7 | |
| | | | |

В

Δ


В

2


•


NOTE: This assemby step is for generic brand pulleys only. If you are using genuine Gates brand pulleys, skip this page and see the next page.

B Top View



Note the plate orientation! Also note that this orientation is different from the prior pulley assembly.





В

Exploded View

| ITEM NO. | DESCRIPTION | |
|----------|---------------------------------------|---|
| 1 | M3 20mm standoff, 6mm wide | 2 |
| 2 | M4 Shoulder Screw, 25mm long | 1 |
| 3 | 20T Idler pulley, 2GT, 5mm bore | 2 |
| 4 | M5 Shim, 0.2mm thick | 4 |
| 5 | M3 Buttonhead Screw, 8mm long | 2 |
| 6 | M5 Washer, 0.8-1.2mm thick | 2 |
| 7 | Back Right Pulley Reinforcement Plate | 1 |

Right Corner Generic Pulley Assembly

| | Created by: | last edited: |
|----|----------------|--------------|
| BY | Joshua Vasquez | 3/23/2020 |
| | SCALE: 1:1 | SHEET 5 OF 7 |


A

2


.

NOTE: This assemby step is for Gates brand pulleys only. If you are using generic brand pulleys, skip this page and see the previous page.


Top View



Note the plate orientation! Also note that this orientation is different from the prior pulley assembly.








Assembled View


| ITEM NO. | DESCRIPTION | QTY. |
|----------|---------------------------------------|------|
| 1 | M3 20mm standoff, 6mm wide | 2 |
| 2 | M4 Shoulder Screw, 25mm long | 1 |
| 3 | M5 Shim, 0.2mm thick | 2 |
| 4 | 20T Idler pulley, 2GT, 5mm bore | 2 |
| 5 | Back Right Pulley Reinforcement Plate | 1 |
| 6 | M3 Buttonhead Screw 8mm long | 2 |

Right Corner Gates Pulley Assembly last edited: Created by: Joshua Vasquez 3/23/2020 SCALE: 1:1 SHEET 6 OF 7

В

В





В

Assembled View

A

| ITEM NO. | DESCRIPTION | |
|----------|------------------------------------------|---|
| 1 | Right Corner Plate with Insert Installed | 1 |
| 3 | Right Corner Pulley Assembly | 1 |
| 5 | M3 Buttonhead Screw, 10mm long | 2 |
| 7 | M5 x 0.8 Screw, Low Profile. 20mm | 3 |
| 9 | M5 Drop-In T-Nut for 20x20 Extrusion | 3 |
| 11 | M5 Washer, 0.8-1.2mm thick | 2 |

| Right Corner Pulley Plate Assembly | | | |
|------------------------------------|------------|----------------|--------------|
| | (i) | Created by: | last edited: |
| (CC) | BY | Joshua Vasquez | 3/23/2020 |
| | | SCALE: 1:1 | SHEET 7 OF 7 |

2