

NOTE: This assemby step is for generic brand pulleys only. If you are using genuine Gates brand pulleys, skip this page and see the next page.


В


Note the plate orientation!

This side is short.

This side is long.

Top View





В

Assembled View

1	M3 Standoff, 20mm long, 6mm wide	2
2	M4 Shoulder Screw, 25mm long	1
3	M3 Buttonhead Screw, 8mm long	2
4	M5 Shim, 0.2mm thick, 7mm OD	4
5	20T Idler pulley, 2GT, 5mm bore	2
6	M5 Washer, 0.8-1.2mm thick	2

DESCRIPTION

Left Corner Generic Pulley Assembly				
© BY	Created by: Joshua Vasquez	last edited: 5/27/2020		
	SCALE: 1:1	SHEET 2 OF 7		

A

ITEM NO.

7

•

Left Corner Pulley Reinforcement Plate

•

NOTE: This assemby step is for **Gates** brand pulleys only. If you are using **generic** brand pulleys, skip this page and see the previous page.


В


Note the plate orientation!


This side is short.

This side is long.


Top View







Exploded View



В

Assembled View

A


ITEM NO.	DESCRIPTION	QTY.
1	M3 Standoff, 20mm long, 6mm wide	2
2	M4 Shoulder Screw, 25mm long	1
3	M3 Buttonhead Screw, 8mm long	2
4	M5 Shim, 0.2mm thick, 7mm OD	2
5	20T Idler pulley, 2GT, 5mm bore	2
6	Left Corner Pulley Reinforcement Plate	1


Left Corner Gates Pulley Assembly				
CC BY	Created by: Joshua Vasquez	last edited: 5/27/2020		
	SCALE: 1:1	SHEET 3 OF 7		

2

.

В





Assembled View

A
A

ITEM NO.	DESCRIPTION	
1	Left Corner Plate with Insert Installed	1
5	M3 Buttonhead Screw, 10mm long	2
6	M5 Buttonhead Screw, 20mm long	3
9	M5 Drop-In T-Nut for 20x20 Extrusion	3
10	M5 Washer, 0.8-1.2mm thick	2
11	Left Corner Pulley Reinforcement Plate	1

Exploded View

[11]

Left Corn	Left Corner Pulley Plate Assembly			
CC BY	Created by: Joshua Vasquez	last edited: 5/27/2020		
	SCALE: 1:1	SHEET 4 OF 7		


2

NOTE: This assemby step is for **generic** brand pulleys only. If you are using genuine **Gates** brand pulleys, skip this page and see the next page.


Top View В

> This side is short. ackslash This side is long.

Note the plate orientation! Also note that this orientation is different from the prior pulley assembly.



Exploded View



В

Assembled View

ITEM NO.	DESCRIPTION	
1	M3 Standoff, 20mm long, 6mm wide	2
2	M4 Shoulder Screw, 25mm long	1
3	20T Idler pulley, 2GT, 5mm bore	2
4	M5 Shim, 0.2mm thick, 7mm OD	4
5	M3 Buttonhead Screw, 8mm long	2
6	M5 Washer, 0.8-1.2mm thick	2
7	Right Corner Pulley Reinforcement Plate	1


Right Corner Generic Pulley Assembly

	Created by:	last edited:
CC (i)	Joshua Vasquez	5/27/2020
	SCALE: 1:1	SHEET 5 OF 7


NOTE: This assemby step is for Gates brand pulleys only. If you are using generic brand pulleys, skip this page and see the previous page.

В


Top View



Note the plate orientation! Also note that this orientation is different from the prior pulley assembly.



Exploded View



В

Assembled View

ITEM NO.	DESCRIPTION	QTY.
1	M3 Standoff, 20mm long, 6mm wide	2
2	M4 Shoulder Screw, 25mm long	1
3	M5 Shim, 0.2mm thick, 7mm OD	2
4	20T Idler pulley, 2GT, 5mm bore	2
5	Right Corner Pulley Reinforcement Plate	1
6	M3 Buttonhead Screw, 8mm long	2

Right Corner Gates Pulley Assembly

Created by:
Joshua Vasquez

5/27/2020


SHEET 6 OF 7


SCALE: 1:1

A

2

.





Assembled View

Exploded View

ITEM NO.	DESCRIPTION	
1	Right Corner Plate with Insert Installed	1
3	Right Corner Pulley Assembly	1
5	M3 Buttonhead Screw, 10mm long	2
7	M5 Buttonhead Screw, 20mm long	3
9	M5 Drop-In T-Nut for 20x20 Extrusion	3
11	M5 Washer, 0.8-1.2mm thick	2

Right Corner Pulley P	late Assembly
-----------------------	---------------

В

(3)	 Created by: Joshua Vasquez	last edited: 5/27/2020
	SCALE: 1:1	SHEET 7 OF 7

2