

Install the insert using the plate-press technique.




В

Explodled View



Assembled View




Explodled View



Assembled View


ITEM NO.	DESCRIPTION	QTY.
1	M3 Tapered Heat Set Insert	3
2	Parking Post Base	1
3	Parking Post Base	1



Α


В

Install the dowel pins with an arbor press, ensuring that they seat vertically, not at an angle.



Exploded View





Assembled View


Created by	TITLE:		
Joshua Vasquez	Tool Holder Assembly		
last edited:	UNLESS OTHERWISE SPECIFIED: DIMENSIONS ARE IN MM BREAK ALL SHARP EDGES		SIZE A REV
MATERIAL	SCALE: 1:1	SHEET 2 C	DF 4

В

A

В









Assembled View

A

ITEM NO.	DESCRIPTION	QTY.
1	Parking Post Base	1
2	M5 Buttonhead Screw, 8mm long	2
4	M5 Drop-In T-Nut for 20x20 Extrusion	2
5	M3 Buttonhead Screw, 8mm long	1



2




Exploded View

When dialing in the parking location on the frame, loosen this screw to adjust vertical height of the parked tool.

And loosen these screws to adjust the horizontal location of the parked tool.

В



Assembled View

ITEM NO.	DESCRIPTION	QTY.
1	Parking Post Base Assembly	1
7	Tool Holder Assembly	1
8	M3 Buttonhead Screw, 10mm long	2

Created by Joshua Vasquez	TITLE: Final Asse	mbly	
last edited:	UNLESS OTHERWISE SPECIFIED: DIMENSIONS ARE IN MM BREAK ALL SHARP EDGES		SIZE A REV 1.0
MATERIAL	SCALE: 1:1	SHEET 4 (OF 4

В

A

1