— DRAFT — do not distribute

MATPOWER Optimal Scheduling Tool MOST 1.0-dev User's Manual

Ray D. Zimmerman Carlos E. Murillo-Sánchez February 22, 2016

— DRAFT —

Contents

1	Intr	oduction	3
	1.1	License and Terms of Use	S
	1.2	Citing MOST	7
2	Get	ting Started 8	3
	2.1	System Requirements	3
	2.2	Installation	8
	2.3		9
			9
		2.3.2 Solving the Case	Э
		2.3.3 Accessing the Results	1
		2.3.4 Setting Options	2
	2.4	Documentation	2
3	Bac	kground and Overview	3
	3.1	Continuous Single Period Problems	3
	3.2	Security	5
	3.3	Uncertainty of Demand and Renewable Generation	7
	3.4	Multiple Periods	3
	3.5	Ramping and Load Following Ramp Reserves	9
	3.6	Storage and Deferrable Demand	
	3.7	Dynamic Linear Time-Invariant System	
	3.8	Unit Commitment	2
4	Pro	olem Formulation 25	5
	4.1	Nomenclature	5
	4.2	Formulation	2
		4.2.1 Objective Function	2
		4.2.2 Constraints	3
	4.3	Probability Weighting of Base and Contingency States	
	4.4	Value of Residual Storage)
5	most	48	3
	5.1	Input Data	
		5.1.1 mpc - Matpower Case	
		5.1.2 transmat – Transition Probability Matrices	
		5.1.3 xgd - Extra Generator Data (xGenData) 49	-

— DRAFT —

			51
		\circ	51
		1	53
	5.2		54
	5.3		56
		1	56
		ı	61
	5.4	Additional Considerations	66
6	\mathbf{Add}	litional Functions	37
	6.1	addgen2mpc	67
	6.2	addstorage	68
	6.3	addwind	68
	6.4	apply_profile	69
	6.5	filter_ramp_transitions	69
	6.6	getprofiles	70
	6.7	idx_profile	70
	6.8	loadgenericdata	70
	6.9	loadmd	71
	6.10	loadstoragedata	72
	6.11	loadxgendata	73
	6.12	mostver	74
7	Tute	orial Examples	75
	7.1	•	75
			75
			75
		7.1.3 Secure DC OPF	75
			75
	7.2		75
			75
			75
			75
8	Ack	nowledgments	76
\mathbf{A}	ppen	dix A MOST Files and Functions	77
			77
			 7Ω

Appendix B Release History	79
B.1 Version 1.0b1 – released Mmm DD, 2016	79

References

— DRAFT —

80

List of Figures

3-1	0	4
3-2	The state of the s	6
3-3		6
3-4	1	7
3-5		8
3-6		20
3-7		21
3-8		22
3-9	MOST Mixed Integer and Multi-Period Problems	23
List	of Tables	
4-1	Five Price Model	l5
5-1	Fields of xGenData struct (xgd)	0
5-2		52
5-3		53
5-4	MOST Run Options	64
5-5		55
5-6	Input Data Fields of md	7
5-7	Additional Input Data Fields of md 5	8
5-8	Fields of Offer struct md.offer(t)	69
5-9		60
5-10		32
		3
5-12	Fields of QP struct md.QP 6	64
		55
6-1	Typical Generator Types	57
6-2		8
6-3	•	69
6-4		1
6-5		2
6-6		4
A-1		7
A-2		8
A-3		28

1 Introduction

Beginning with version 6, MATPOWER [1] includes a framework for solving generalized steady-state electric power scheduling problems. This framework is known as MOST, for MATPOWER Optimal Scheduling Tool [2].

MOST can be used to solve problems as simple as a deterministic, single period economic dispatch problem with no transmission constraints or as complex as a stochastic, security-constrained, combined unit-commitment and multi-period optimal power flow problem with locational contingency and load-following reserves, ramping costs and constraints, deferrable demands, lossy storage resources and uncertain renewable generation.

While the problem formulation is general and incorporates a full nonlinear AC network model, the current implementation is limited to DC power flow modeling of the network. Some work has been done on an AC implementation, but it is not yet ready for release.

The primary developers of MOST are Carlos E. Murillo-Sánchez¹ and Ray D. Zimmerman² of PSERC³. It is built on top of MATPOWER⁴, a package of MATLAB[®] M-files for solving power flow and optimal power flow problems [1, 3]. This manual assumes that the user is familiar with using MATPOWER, especially for solving optimal power flow problems, and makes numerious references to version 6.0-dev of the MATPOWER User's Manual [4].

1.1 License and Terms of Use

The code in MOST is distributed along with MATPOWER under the 3-clause BSD license [5]. The full text of the license can be found in the LICENSE file at the top level of the distribution or at http://www.pserc.cornell.edu/matpower/LICENSE.txt and reads as follows.

¹Universidad Nacional de Colombia, Manizales, Colombia

²Cornell University, Ithaca, NY, USA

³http://pserc.org/

⁴See http://www.pserc.cornell.edu/matpower/ for more information on MATPOWER.

Copyright (c) 1996-2016, Power System Engineering Research Center (PSERC) and individual contributors (see AUTHORS file for details). All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- 1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- 2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- 3. Neither the name of the copyright holder nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

1.2 Citing MOST

While not required by the terms of the license, we do request that publications derived from the use of MOST explicitly acknowledge that fact by citing both the main MATPOWER reference [1] and reference [2]:

C. E. Murillo-Sánchez, R. D. Zimmerman, C. L. Anderson, and R. J. Thomas, "Secure Planning and Operations of Systems with Stochastic Sources, Energy Storage and Active Demand," *Smart Grid, IEEE Transactions on*, vol. 4, no. 4, pp. 2220–2229, Dec. 2013, http://dx.doi.org/10.1109/TSG.2013.2281001.

2 Getting Started

The first step in beginning to use the MOST is to get familiar with MATPOWER. This step is essential and this manual will assume familiarity with MATPOWER.

2.1 System Requirements

To use MOST you will need a working installation of MATPOWER 6.0-dev or later. See the corresponding section in the MATPOWER User's Manual for more information on the system requirements. MATPOWER 6 and later includes a full version of MOST in the <mathcal{MATPOWER}/most directory.

It is also highly recommended that you install a high-performance solver such as Gurobi, CPLEX, MOSEK, MATLAB's Optimization Toolbox or GLPK, described in Appendix G in the MATPOWER User's Manual. For problems involving unit-commitment, a mixed integer solver is required.⁵ But even for continuous LP and QP problems, these solvers will offer much better performance than MATPOWER's built-in solver based on qps_mips. The problems MOST generates can quickly become very large, so using the best solver you have available is a priority.⁶

2.2 Installation

If you have followed the directions for installing MATPOWER found in Section 2.2 of the MATPOWER User's Manual, then MOST should already be installed in the <MATPOWER>/most directory and the appropriate paths⁷ added to your MATLAB path.

To run the test suite and verify that MOST is properly installed and functioning, at the MATLAB prompt, type test_most. The result should resemble the following, possibly including extra tests, depending on the availablility of optional packages.

⁵At the time of this writing, MATLAB's Optimization Toolbox and GLPK only address MILP problems. Gurobi, CPLEX and MOSEK all handle MIQP problems as well.

⁶Gurobi and CPLEX are currently our preferred solvers for most MOST problems.

⁷To use MOST your MATLAB path must include <*MATPOWER*>/most and, to run the tests, <*MATPOWER*>/most/t.

```
>> test_most
t_most_3b_1_1_0.....ok
t_most_3b_3_1_0.....ok
t_most_30b_1_1_0.....ok
t_most_30b_3_1_0....ok
t_most_fixed_res.....ok
t_most_w_ds.....ok
t_most_30b_1_1_0_uc...ok
t_most_s0b_1_1_0_uc...ok
t_most_uc.....ok
t_most_suc.....ok
Elapsed time 150.73 seconds.
```

2.3 Running a Simulation

Running a MOST simulation involves (1) preparing the input data defining all of the relevant power system parameters, transition probabilities, additional generator data and offers, storage data, contingencies, and profiles (2) invoking the function to run the simulation and (3) accessing the results in the output data structures. The input data is provided in a MOST Data struct and the results are returned in an updated version of the input data structure.

Since MOST is built upon MATPOWER, it is assumed that the user is already familiar with running OPF simulations in MATPOWER (see Section 2.3 in the MATPOWER User's Manual).

2.3.1 Preparing Input Data

The MOST Data struct, containing all of the data needed for the problem, is sufficiently complex that it is not typically created directly, but rather is assembled from numerous other files or data structures by the loadmd function, as described in Section 5.1. They consist of (1) a MATPOWER case file or struct describing the system parameters for the base case, (2) transition probability matrices, (3) additional generator parameters, including commitment parameters, offer parameters related to reserves, inc/dec prices, and bounds on energy contract amounts, (4) parameters for storage units, (5) a contingency table defining a credible set of contingencies and their probabilities, and (6) profiles for time varying parameters such as load and renewable availability. In addition to the input data, aspects of the simulation are controlled by a set of MATPOWER options.

Typically, the MATPOWER case is defined in a case file and loaded into a struct

using the loadcase function. The transition probability matrices can be specified as desired via a user-defined script or function as shown in the example below. The additional generator parameters are typically provided in a file defining an xGenDataTable and loaded by the loadxgendata function. Both the MATPOWER case and the xGenData can be modified by adding wind generators, or generators that represent energy storage units, using the functions addwind and addstorage, respectively. The latter also loads the additional storage parameters into a StorageData struct. The contingency table can be provided directly or returned by a user-defined function and is a changes table (chgtab) in the form expected by MATPOWER's apply_changes function. And any time-varying parameters, such as load scaling factors and wind availability, are specified in profile data files and loaded with the getprofiles function.

```
mpc = loadcase('eg_case3');
transmat = eg_transmat(12);
xgd = loadxgendata('eg_xgd', mpc);
[iwind, mpc, xgd] = addwind('eg_wind', mpc, xgd);
[iess, mpc, xgd, sd] = addstorage('eg_storage', mpc, xgd);
contab = eg_contab();
profiles = getprofiles('eg_load_profile');
profiles = getprofiles('eg_wind_profile', profiles, iwind);
md_in = loadmd(mpc, transmat, xgd, sd, contab, profiles);
mpopt = mpoption('verbose', 0);
```

2.3.2 Solving the Case

The solver in MOST is implemented in the most function. Assuming the input data have been loaded into the variable md_in and the MATPOWER options set in mpopt, the first stage solver can be called as follows.

```
md_out = most(md_in, mpopt);
```

⁸See Section 9.3.5 in the MATPOWER User's Manual.

```
______
        MATPOWER Optimal Scheduling Tool -- MOST Version 1.0b1
         A multi-period stochastic secure OPF with unit commitment
                    ---- Built on MATPOWER ----
 by Carlos E. Murillo-Sanchez, Universidad Nacional de Colombia -- Manizales
                and Ray D. Zimmerman, Cornell University
               (c) 2012-2016 Cornell University and PSERC
- Building indexing structures.
- Building expected storage-tracking mechanism.
- Building constraint submatrices.
 - Building DC flow constraints.
 - Splitting storage injections into charge/discharge.
 - Building CCV constraints for piecewise-linear costs.
 - Building contingency reserve constraints.
 - Building ramping transitions and reserve constraints.
 - Building storage constraints.
 - Building unit commitment constraints.
- Building cost structures.
- Assembling full set of costs.
- Assembling full set of constraints.
- Assembling full set of variable bounds.
- Calling MILP solver.
Gurobi Version 6.5.0 -- automatic MILP solver
--- Integer stage complete, starting price computation stage ---
Gurobi Version 6.5.0 -- automatic LP solver
_____
- MOST: MILP solved successfully.
- Post-processing results.
- MOST: Done.
```

2.3.3 Accessing the Results

By default, the simulation does not output any results to the screen, instead storing the results in the output MOST Data struct (md_out). The details of the results in md_out can be found in Section 5.3.2.

For example, quantities like the commitment, expected dispatch and expected energy price, upward contingency and ramping reserve amounts for generator i in period t, and the dispatch of generator i in period t, scenario j and contingency k

can be extracted as follows.

```
define_constants;
unit_commitment = md_out.UC.CommitSched(i, t);
expected_dispatch = md_out.results.ExpectedDispatch(i, t);
expected_price = md_out.results.GenPrices(i, t);
cont_reserve_up = md_out.results.Rpp(i, t);
ramp_reserve_up = md_out.results.Rrp(i, t);
Pg_tijk = md_out.flow(t,j,k).mpc.gen(i, PG);
```

2.3.4 Setting Options

The standard MATPOWER options struct is used to set options such as the amount of progress output to display and algorithm to use to solve the underlying optimization problem. The options struct is set using the mpoption function.

```
mpopt = mpoption('verbose', 2, 'most.solver', 'GUROBI');
```

The full set of MOST options are detailed in Section 5.2.

2.4 Documentation

There are two primary sources of documentation for MOST. The first is this manual, which gives an overview of the capabilities and structure and describes the problem formulation. The MOST User's Manual can be found in your MATPOWER distribution at <mathree <mathree MATPOWER distribution at <mathree <mathree manual.pdf.

The second is the built-in help command. As with MATLAB's built-in functions and toolbox routines, you can type help followed by the name of a command or M-file to get help on that particular function. Many of the MOST related M-files have such documentation and this should be considered the main reference for the calling options for each individual function. See Appendix A for a list of MOST functions.

There is one other important source of related documentation and that is the MATPOWER User's Manual. It is assumed that the user is very familiar with MATPOWER and its OPF capabilities.

3 Background and Overview

MOST grew out of research at Cornell University on the development and testing of new tools for the power industry, funded by the U.S. Department of Energy through the the CERTS Reliability and Markets program. Initially the work was focused on extending the AC optimal power flow problem to include co-optimization of locational reserves for security defined in terms of explicitly included contingencies [6, 7]. This work was then extended to include multiple base scenarios to represent stochastic load and renewable generation availability, a multiperiod planning horizon, energy storage resources, ramping considerations and binary unit commitment decisions [2].

The formulation implemented in MOST and described in the next section further generalizes the problem by including the facility to define zonal reserve requirements like those from Section 7.5.1 in the MATPOWER User's Manual [4], and to constrain the solutions via a general time-invariant linear dynamic system. The initial prototype was implemented by Carlos E. Murillo-Sánchez with subsequent development by Ray D. Zimmerman along with contributions by Daniel Muñoz-Álvarez and Alberto J. Lamadrid.

The description of the problem formulation will begin with a conceptual overview of the approach, beginning with the simplest single period problem that MOST handles and extending and expanding the problem one step at a time to illustrate how each additional aspect of the full problem is handled.

3.1 Continuous Single Period Problems

A single period problem can be as simple as a lossless economic dispatch (ED) problem, where the objective is to find the set of generator dispatch points that minimize the total cost of meeting a specified demand, with no modeling of any network flows at all. Even at this level, dispatchable demands can be introduced, modeled as negative generation as in Section 6.4.2 in the MATPOWER User's Manual, to model either involuntary load shedding or demand-side resources dispatched according to a benefit or bid function. It is assumed throughout that power injection variables may represent either generators or loads.

By introducing DC power flow equations as a function of bus voltage angle variables, along with limits on the branch flows, the problem becomes a DC OPF, taking

⁹This work was supported by the Consortium for Electric Reliability Technology Solutions and the Office of Electricity Delivery and Energy Reliability, Transmission Reliability Program of the U.S. Department of Energy under the National Energy Technology Laboratory Cooperative Agreement No. DE-FC26-09NT43321. https://certs.lbl.gov/research-areas/reliability-markets-rm




Figure 3-1: MOST Continuous Single-Period Problems

into account transmission system limitations. Using instead the AC power flow equations and flow constraints and introducing voltage magnitude and reactive injection variables results in an AC OPF problem, which models losses along with voltage and reactive power requirements.

Figure 3-1 illustrates the range of continuous single period problems considered by the formulation, with the varying level of detail of the network modeling represented by the vertical dimension. The horizontal dimension represents different ways to handle (or not) operational security requirements, with a third dimension adding a stochastic option for handling the uncertainty of demand and renewable generation. The green portion denotes the parts of the formulation that are implemented in the current version of MOST.

3.2 Security

Two options are included for addressing security in the single period problem, that is the need to find a dispatch that meets some criteria for withstanding disturbances or outages. The first is a deterministic approach that simply adds fixed zonal reserve requirements using the additional variables, constraints and costs described in Section 7.5.1 in the MATPOWER User's Manual.

The second is a stochastic approach, based on explicitly modeling the post-contingency state for each of a set of credible contingencies. In this approach, the base case ED or OPF problem is fully duplicated (all variables, costs and constraints) for each of the contingency states and modified to reflect the outaged equipment.

The base and contingency states are then combined into one large problem, where they are treated as separate islands in a single network, with the cost of each state weighted by its probability of occurrence. The base and contingency states are further tied together by ramp limits on the generators, ensuring that the contingency state dispatches can be reached from the base case while respecting ramp rate constraints.

Finally, associated with each generator is a variable representing a reference dispatch value (e.g. optimal contract value) from which dispatch deviations (incremental and decremental redispatches) are defined. The maximum upward and downward deviations from this reference dispatch across all (base and contingency) states are defined as the upward and downward contingency reserves, respectively, and these reserves can have costs associated with them. In addition, the state specific deviations from the reference quantity can have their own probability weighted redispatch costs.

This second approach to security yields security constrained dispatch (ED or OPF) problem with endogenously determined generator-specific locational reserve requirements, derived optimally as a function of the set of included credible contingencies. In this problem formulation, it is assumed that the decisions regarding a reference dispatch and the corresponding dispatch ranges that define the reserves are made before the uncertain outcome of the occurrence or non-occurrence of a contingency is revealed. The state specific dispatch decisions are recourse decisions contingent on the outcome of that uncertainty.

The structure of this problem is illustrated by the diagram in Figure 3-2, where the circles represent the ED or OPF problems corresponding to the individual states, the dashed box denotes the reference dispatch, redispatches, reserves and associated costs and constraints, and the arrows illustrate the ramp limits constraining the deviations of contingency state dispatches from the base case dispatch.

Figure 3-3 shows the reserve structure for generator i. The green and pink bars show upward and downward redispatches from the reference dispatch p_c^i , where the




Figure 3-2: Secure Dispatch Problem Structure




Figure 3-3: Reserve Structure for Generator i

maximums of these deviations define the corresponding reserve quantities. The physical ramp limit restrict deviations of contingency dispatches with respect to the base case dispatch p^{i0} .




Figure 3-4: Problem Structure with Multiple Base Scenarios

3.3 Uncertainty of Demand and Renewable Generation

While contingencies refer to discrete low probability events, there is another kind of uncertainty introduced by errors in forecasting of demand and renewable sources of generation, such as wind and solar production. This type of uncertainty can be characterized by random system parameters with continuous probability distributions. MOST can model this type of uncertainty by drawing scenarios from the joint distribution of uncertain parameters and including these scenarios as multiple probability-weighted base cases in a structure similar to that described above for the continencies. There are two primary differences. First, the probabilities of the scenarios used to represent this type of uncertainty need not be small and, second, the base scenarios are tied to each other by the inc/dec and reserve variables, but not by physical ramp limits. This results in a stochastic dispatch problem with endogenously determined generator-specific locational reserves.

To make this problem secure, outage scenarios can be added for each base case, in the same manner as they were added to the single base case problem described previously. For a case with two contingency states, representing uncertain forecasts with two base scenarios results in the problem structure shown in Figure 3-4. In this case the reserves are defined by the maximum redispatch deviations across all scenarios and contingencies and the physical ramp rates limit the deviations of contingecy cases from the base case within each scenario, as illustrated in Figure 3-5. In this figure the variables include a t index as well, since the same structure is used at each period t in the multiperiod problems discussed below.

Though there are now two types of uncertainty, contingencies and parameter uncertainty for demand and renewables, the reference dispatch and reserve decisions are made before the uncertainty is realized, with the state-specific dispatch decisions being recourse decisions contingent on the revealed outcome of both types of




Figure 3-5: Reserve Structure for Generator i in Period t

uncertainty.

3.4 Multiple Periods

For deterministic scheduling problems, the extension to multiple periods is straightforward. The single period problem is duplicated for each period in the planning horizon and combined into a single large problem which the individual periods appear as islands in a single network. Linking between adjacent periods is in the form of ramping costs and constraints involving the corresponding dispatch variables.

In the case of the stochastic problems with multiple probabilistic system states in each period, the extension to multiple periods is more complicated. One approach is to define each "scenario" as a particular realization of all uncertainties, defining a full trajectory through the entire planning horizon. The challenge here is in enforcing the non-anticipativity of the recourse decisions, since in reality the uncertainty is revealed period by period. On the other extreme, the option is to assume that from each scenario in period t the system might transition to any of a number of states in period t + 1. Clearly, the explosion of the number of states with the length of the planning horizon is the barrier to adopting this approach.

MOST takes this multi-stage decision approach, but adds scenario recombination and scenario trimming to avoid the exploding number of scenarios. This is accomplished by assuming a Markovian structure for a high-probability central path where a transition probability matrix is used to describe the transitions from a limited set of base scenarios in one period to a limited set of base scenarios in the next period. States subsequent to contingency states are trimmed, on the assumption that they occur with low probability and likely require re-optimizing for the future following their occurence.

3.5 Ramping and Load Following Ramp Reserves

Ramping feasibility is only enforced on this high probability central path, in which all possible transitions are constrained to be feasible with respect to physical ramping capabilities as well as any load following reserve capacity offers. MOST includes the facility to define a simple quadratic "wear and tear" cost on the difference in dispatch from one period to another, applied in as a probability-weighted cost to each possible transition, as well as up and down load-following ramping reserve costs. These reserve costs apply to maximum upward and downward transitions included in the central path scenarios, as illustrated in Figure 3-6.

3.6 Storage and Deferrable Demand

Including the time dimension in the problem also opens the door for centrally dispatching resources such as energy storage and deferrable demand technologies which inherently couple operations across time periods. Battery terminology, such as charging and discharging, will be used to describe the storage model implemented by MOST, though the concepts and model are applicable to a range of storage and energy limited technologies, including batteries, pumped-storage units, combined space conditioning and thermal storage (e.g. ice batteries), and even dispatchable demands or generation with an energy quota over a given horizon.

A storage unit is implemented as a generator with an associated stored energy. The unit has upper and lower bounds on both power and energy, all of which can be either positive or negative. The power bounds define the maximum and minimum power injections, corresponding to the discharging and charging power limits for a traditional battery. The bounds on stored energy, which can vary over time, are used to specify the energy capacity (e.g. for a battery) or quota (e.g. time-flexible demand). The storage unit can also have non-unity charging and discharging efficiencies as well as a loss coefficient defining energy losses in each period as a linear




Figure 3-6: Ramping and Load Following Ramp Reserves

function of the amount of stored energy.

For deterministic problems, as with ramping, enforcing the intertemporal constraints imposed by such an energy storage resource is straightforward. In this case, it is a simple set of conservation of energy constraints.

For the stochastic problems, on the other hand, it becomes more complicated. Since the quantity of stored energy available in any given scenario at time t is dependent on the dispatches in preceding periods, there is no uniquely defined quantity of stored energy for each scenario, so it is not possible to track actual stored energy values, only expected values and minimum and maximum values.

For this reason MOST defines decision variables representing the upper and lower bounds on stored energy in each period and enforces feasibility with respect to these limits. Figure 3-7 shows how these limits spread out from period to period when the dispatch of the storage unit varies across scenarios. The only instance in which the limits do not spread out is if the unit adheres to the same dispatch schedule across all scenarios in a period. This formulation allows the optimization problem to make an optimal tradeoff between using the storage to arbitrage energy across time




Figure 3-7: Storage

(same dispatch schedule across scenarios to avoid spreading of limits) and using it to mitigate uncertainty (vary the dispatch in response to the different scenarios, but at the expense of spreading limits).

The formulation also includes the option to relax the restrictions on the stored energy bounds in some or all periods to base them on the range of *expected* stored energy quantities in the previous period, rather than on the worst case ranges.

An important aspect of modeling storage is to include some way of either valuing or constraining both the initial amount of stored energy in each unit and the amount of leftover storage in terminal states, both end-of-horizon states and contingency states. MOST includes several options. First, for each unit there is a cost assigned to any initial stored energy at the beginning of the horizon. Similarly, there are a number of parameters used to specify the value of leftover stored energy in terminal states. Furthermore, the initial stored energy amount can be specified and the final expected stored energy amount can be constrained to equal a target quantity. Finally, there is also the option to simply constrain the initial amount and the final expected amount to be equal while letting that level be determined as an output of the optimization.




Figure 3-8: Overall Problem Structure

3.7 Dynamic Linear Time-Invariant System

The dispatch schedule can also be restricted by putting constraints on the states of a linear time-invariant system whose inputs are the expected dispatches at each time period. This can be used, for example, to model certain types of generator emission constraints.

This section needs to be expanded a bit to describe the dynamic system model and potential uses ...

3.8 Unit Commitment

So far, the discussion has been restricted to problems with continuous optimization variables, with an overall structure for the general case as illustrated in Figure 3-8.¹⁰ The class of problems addressed by MOST also includes those with discrete unit

¹⁰The dynamic linear time-invariant system constraints and the unit commitment aspects of the problem are not included in this illustration.




Figure 3-9: MOST Mixed Integer and Multi-Period Problems

commitment decisions, with optional startup and shutdown costs associated with changes in online status from a prior commitment state. In multiperiod problems these state states are coupled through time, not only by the startup and shutdown costs, but also by minimum up and down time constraints.

For stochastic problems modeling multiple scenarios and/or contingency states there is a single commitment schedule shared by all states. That is, in the current formulation, a single binary variable is used to model the commitment for a given unit across all scenarios and contingencies in a given period.¹¹

¹¹To correctly model the commitment of fast start units with non-zero minimum generation

Figure 3-9 illustrates the ways in which any one of the single period continuous variable problems of Figure 3-1 can be extended to include combinations of multiple periods, ramping, storage, integer commitment, startup and shutdown costs and minimum up and down times.

constraints requires individual commitment variables for each scenario. $\,$

4 Problem Formulation

4.1 Nomenclature

This section summarizes the nomenclature for the full multi-period mixed-integer nonlinear problem. In order to simplify the indexing notation, the index literals and their order are maintained wherever possible. Furthermore, no commas are used, so the superindex tijk refers to time period t, generator i (or dispatchable load or storage unit i), base scenario j and contingency k. A dispatchable or curtailable load is modeled as negative generation, as in Section 6.4.2 in the MATPOWER User's Manual, each wind farm as a generator whose maximum output varies by scenario according to the forecast distribution, and a storage unit as a device with a given loss factor, energy capacity, and "charging" and "discharging" power capacities and efficiencies.

Variable and Parameter Indexing

Symbol	Meaning
t	Index over time periods.
T	Set of indices of time periods in planning horizon, typically $\{1 \dots n_t\}$.
j	Index over scenarios.
J^t	Set of indices of all scenarios considered at time t .
k	Index over post-contingency cases ($k=0$ for base case, i.e. no contingency occured).
K^{tj}	Set of indices of contingencies considered in scenario j at time t , including base case $(k=0)$.
i	Index over injections (generation units, storage units and dispatchable or curtailable loads).
I^t	Indices of all units (generators, storage and dispatchable or curtailable loads) available for dispatch in any contingency at time t .
I^{tjk}	Indices of all units available for dispatch in post-contingency state k of scenario j at time t .

l	Index over reserve zones.
L^{tjk}	Indices of all reserve zones defined in post-contingency state k of scenario j at time t .
Z_l^{tjk}	Set of generators providing reserves in zone l in post-contingency state k of scenario j at time t .
$n_t^{ m ds}$	Number of time periods in the horizon of the dynamic system model.

Optimization Variables

Symbol	Meaning
p^{tijk}, q^{tijk}	Active/reactive injection for unit i in post-contingency state k of scenario j at time t .
p_c^{ti}	Active power contract quantity for unit i at time t .
p_+^{tijk}, p^{tijk}	Upward/downward deviation from active power contract quantity for unit i in post-contingency state k of scenario j at time t .
r_z^{tijk}	Zonal reserve quantity provided by unit i in post-contingency state k of scenario j at time t .
r_+^{ti}, r^{ti}	Upward/downward active contingency reserve quantity provided by unit i at time t .
$\delta_+^{ti}, \delta^{ti}$	Upward/downward load-following ramping reserves needed from unit i at time t for transition to time $t+1$.
$\theta^{tjk}, V^{tjk}, p^{tjk}, q^{tjk}$	Voltage angles and magnitudes, active and reactive injections for power flow in post-contingency state k of scenario j at time t .
$p_{ m sc}^{tijk}, p_{ m sd}^{tijk}$	Charge/discharge power injections of storage unit i in post-contingency state k of scenario j at time t .
s_+^{ti}, s^{ti}	Endogenously computed upper/lower bounds on the energy stored in storage unit i at the end of period t . For $t=0$ this is a fixed input parameter representing the bounds at the beginning of the first period.

s_0^i	Initial stored energy (expected) in storage unit i .
u^{ti}	Binary commitment state for unit i in period t , 1 if unit is on-line, 0 otherwise.
v^{ti}, w^{ti}	Binary startup and shutdown states for unit i in period t , 1 if unit has a startup/shutdown event in period t , 0 otherwise.
z^t	Partition $(n_z \times 1 \text{ vector})$ corresponding to period t of state variable z of the dynamic system model.

Constraint Functions and Parameters

Symbol	Meaning
$g^{tjk}(\cdot)$	Nonlinear AC power flow equations in post-contingency state k of scenario j at time t .
$h^{tjk}(\cdot)$	Transmission, voltage and other limits in post-contingency state k of scenario j at time t .
$P_{\min}^{tijk}, P_{\max}^{tijk}$	Limits on active injection for unit i in post-contingency state k of scenario j at time t .
$Q_{\min}^{tijk}, Q_{\max}^{tijk}$	Limits on reactive injection for unit i in post-contingency state k of scenario j at time t .
$R_{\text{max}+}^{ti}, R_{\text{max}-}^{ti}$	Upward/downward contingency (or zonal) reserve capacity limits for unit i at time t .
R_l^{tjk}	MW reserve requirement for zone l in post-contingency state k of scenario j at time t .
$\delta^i_{\rm max+}, \delta^i_{\rm max-}$	Upward/downward load-following ramping reserve limits for unit i .
Δ^i_+, Δ^i	Upward/downward physical ramping limits for unit i for transitions from base $(k=0)$ to contingency cases.
$ ho^{ti}$	Parameter for storage unit i at period t that determines the weighting in storage constraints, where the storage dispatch bounds

	are computed relative to a weighted average of previous period endogenous bounds $s_+^{(t-1)i}$, $s^{(t-1)i}$ ($\rho^{ti}=1$) and period- and scenariospecific initial expected stored energy ($\rho^{ti}=0$).
$S_{\max}^{ti}, S_{\min}^{ti}$	Stored energy (in MWh) max/min limits for storage unit i at time t .
$S_{\min}^{0i},S_{\max}^{0i}$	Lower/upper bounds on initial stored energy (expected) in storage unit $i.$
$S_{\min}^{n_t i}, S_{\max}^{n_t i}$	Lower/upper bounds on target stored energy (expected) in storage unit i at end of final period n_t .
τ_i^+,τ_i^-	Minimum up and down times for unit i in number of periods.
$A_{\mathrm{ds}}^t, B_{\mathrm{ds}}^t, C_{\mathrm{ds}}^t, D_{\mathrm{ds}}^t$	Matrices used to define the state transitions and output constraints for the dynamic system model at time t .
z_{\min}^t, z_{\max}^t	Lower and upper bounds on dynamic system model state \boldsymbol{z}^t at time t .
y_{\min}^t, y_{\max}^t	Lower and upper bounds on dynamic system model output at time t .

Cost Functions and Parameters

Symbol	Meaning
$C_P^{ti}(\cdot)$	Cost function for active injection i at time t .
$C_{P+}^{ti}(\cdot), C_{P-}^{ti}(\cdot)$	Cost for upward/downward deviation from active power contract quantity for unit i at time t .
$C_z^{ti}(\cdot)$	Cost function for zonal reserve purchased from unit i at time t .
$C_{R+}^{ti}(\cdot), C_{R-}^{ti}(\cdot)$	Cost function for upward/downward contingency reserve purchased from unit i at time t .
$C^{ti}_{\delta+}(\cdot), C^{ti}_{\delta-}(\cdot)$	Cost of upward/downward load-following ramp reserve for unit i at time t .

$C^i_\delta(\cdot)$	Quadratic, symmetric ramping cost on the difference between the dispatches for unit i in adjacent periods.
C_{s0}	Vector of costs by storage unit associated with starting out with a given level of stored energy s_0 in the storage units at time $t = 0$.
C_s	Vector of prices by storage unit for contributions to terminal storage ¹² from charging or discharging in non-terminal states.
$C_{ m sc0}, C_{ m sd0}$	Vector of prices by storage unit for contributions to terminal storage 12 from charging/discharging in terminal end-of-horizon base states.
$C_{\mathrm{sc}k}, C_{\mathrm{sd}k}$	Vector of prices by storage unit for contributions to terminal storage 12 from charging/discharging in terminal contingency states.
C_v^{ti}, C_w^{ti}	Startup and shutdown costs for unit i at time t in \$ per startup/shutdown.

Other Parameters

Symbol	Meaning
Δ	Length of scheduling time slice in hours, typically 1 hour.
$\eta_{ ext{in}}^{ti}, \eta_{ ext{out}}^{ti}$	Charging/discharging (or pumping/generating) efficiencies for storage unit i at time t .
$\eta_{ m loss}^{ti}$	Fraction of stored energy lost per hour by storage unit i at time t .
α	For contingency cases, the fraction of the time slice that is spent in the base case before the contingency occurs ($\alpha = 0$ means the entire period is spent in the contingency).
ψ_0^{tjk}	Conditional probability of contingency k in scenario j at time t , conditioned on making it to period t without branching off the central path in a contingency in periods $1 \dots t-1$ and on scenario j being realized in some form (base or contingency). ψ_0^{tj0} is the conditional probability of no contingency, i.e. the base case.

¹²That is, expected leftover stored energy in terminal states.

 $\phi^{tj_2j_1}$ Probability of transitioning to scenario j_2 in period t given that scenario j_1 was realized in period t-1.

 $\zeta^{tj_2j_1}$ Binary valued mask indicating whether transition to scenario j_2 in period t from scenario j_1 in period t-1 should be included in load-following ramp requirements.

Derived Parameters

Symbol Meaning

 $\widetilde{C}_{P}^{ti}(\cdot)$ Modified cost function for active injection i at time t with the no load cost subtracted, $\widetilde{C}_{P}^{ti}(p) \equiv C_{P}^{ti}(p) - C_{P}^{ti}(0)$.

 $C_{\rm ts0}, C_{\rm tsc}, C_{\rm tsd}$ Weighted price vectors summarizing contributions to the value of terminal storage¹² from initial storage/charging/discharging, derived from C_s , $C_{\rm sc0}$, $C_{\rm sc0}$, $C_{\rm sck}$, $C_{\rm sdk}$.¹³

 ψ^{tjk} Probability of contingency k in scenario j at time t, derived from transition probabilities $\phi^{tj_2j_1}$ and conditional probabilities of contingencies ψ_0^{tjk} . ψ^{tj0} is the probability of no contingency, i.e. the base case.

 ψ_{α}^{tjk} Probability ψ^{tjk} of contingency k in scenario j at time t adjusted for α .

$$\psi_{\alpha}^{tjk} = \begin{cases} \psi^{tj0} + \alpha \sum_{\kappa \in K^{tj} \neq 0} \psi^{tj\kappa}, & k = 0\\ (1 - \alpha)\psi^{tjk}, & \forall k \in K^{tj} \neq 0 \end{cases}$$

$$(4.1)$$

 γ^t Probability of making it to period t without branching off the central path in a contingency in periods $1 \dots t - 1$.

$$\gamma^{t} \equiv \sum_{j \in J^{t-1}} \psi^{(t-1)j0} = \sum_{j \in J^{t}, k \in K^{tj}} \psi^{tjk}$$
 (4.2)

Storage parameters defined in (4.60) and (4.68)–(4.70) in terms of Δ , α and η_{loss}^{ti} to simplify storage constraint expression.

 $^{^{13}}$ See Section 4.4, especially (4.103)–(4.106), for details.

Derived Variables ¹⁴

C1-1	11.
Symbol	Meaning

$$s_{\Delta}^{tijk}$$
 Net increase in stored energy due to charging or discharging for unit i in post-contingency state k of scenario j at time t .

$$s_{\Delta}^{tijk} \equiv -\Delta(\eta_{\rm in}^{ti} p_{\rm sc}^{tijk} + \frac{1}{\eta_{\rm out}^{ti}} p_{\rm sd}^{tijk}) \tag{4.3}$$

$$\bar{S}_I^{tj}$$
 Vector of expected stored energy for all storage units in base scenario j at the beginning of period t , defined as a linear function of s_0 , $p_{\rm sc}$ and $p_{\rm sd}$.¹⁵

$$\bar{s}_I^{tij0}$$
 Expected stored energy in storage unit i in base scenario j at the beginning of period t (i -th element of \bar{S}_I^{tj}).

$$s_F^{n_t i}$$
 Expected stored energy in storage unit i at the end of period n_t , the final period. 15

$$\bar{p}^t$$
 Vector of expected values of p^{tijk} across j and k at time t , conditional on making it to time t .

$$\bar{p}^t = \frac{1}{\gamma^t} \sum_{j \in J^t, k \in K^{tj}} \psi_{\alpha}^{tjk} p^{tjk}$$

$$\tag{4.4}$$

Individual variables can be grouped into vectors such as p^t for all active injections considered across all scenarios and contingencies at hour t and it will be consistent with the context. The subset referring to scenario j would be p^{tj} .

¹⁴All are linear functions of the optimization variables, used only to simplify the presentation.

 $^{^{15}}$ See Section 4.4 for details.

4.2 Formulation

The problem formulation can be expressed as a mixed-integer nonlinear optimization problem, where the optimization variable x is comprised of all the θ , V, p, q, p_c , p_+ , p_- , r_z , r_+ , r_- , δ_+ , δ_- , $p_{\rm sc}$, $p_{\rm sd}$, s_0 , s_+ , s_- , u, v, w, and z variables, for all t, j, k, i and l. The u commitment variables are binary and the rest continuous. For simplicity, the formulation restricts the treatment of costs, deviations, ramping and reserves to consider only active power, but an extension to include reactive counterparts is straightforward.

4.2.1 Objective Function

The objective then is to

$$\min_{x} f(x) \tag{4.5}$$

where f(x) is comprised of seven components.¹⁶

$$f(x) = f_p(p, p_+, p_-) + f_z(r_z) + f_r(r_+, r_-) + f_\delta(p) + f_{\rm lf}(\delta_+, \delta_-) + f_s(s_0, p_{\rm sc}, p_{\rm sd}) + f_{\rm uc}(v, w)$$

$$(4.6)$$

Each part is expressed in terms of the individual optimization variables as follows.

- expected cost of active power dispatch and redispatch

$$f_p(p, p_+, p_-) = \sum_{t \in T} \sum_{j \in J^t} \sum_{k \in K^{tj}} \psi_{\alpha}^{tjk} \sum_{i \in I^{tjk}} \left[\widetilde{C}_P^{tijk}(p^{tijk}) + C_{P+}^{ti}(p_+^{tijk}) + C_{P-}^{ti}(p_-^{tijk}) \right]$$
(4.7)

- cost of zonal reserves¹⁶

$$f_z(r_z) = \sum_{t \in T} \sum_{j \in J^t} \sum_{k \in K^{tj}} \psi_{\alpha}^{tjk} \sum_{i \in I^{tjk}} C_z^{ti}(r_z^{tijk})$$
 (4.8)

- cost of endogenous contingency reserves¹⁶

$$f_r(r_+, r_-) = \sum_{t \in T} \gamma^t \sum_{i \in I^t} \left[C_{R+}^{ti}(r_+^{ti}) + C_{R-}^{ti}(r_-^{ti}) \right]$$
 (4.9)

¹⁶A typical secure problem uses either zonal reserves or endogenous contingency reserves, but not both. Zonal reserves are typically used only for cases with a single base scenario with no contingencies, that is, when $J^t = \{1\}$ and $K^{tj} = \{0\}$.

- expected cost of load-following ramping (wear and tear)

$$f_{\delta}(p) = \sum_{t \in T} \gamma^{t} \sum_{\substack{j_{1} \in J^{t-1} \\ j_{2} \in J^{t}}} \phi^{tj_{2}j_{1}} \sum_{i \in I^{tj_{2}0}} C_{\delta}^{i}(p^{tij_{2}0} - p^{(t-1)ij_{1}0})$$

$$(4.10)$$

cost of load-following ramp reserves

$$f_{\rm lf}(\delta_+, \delta_-) = \sum_{t \in T} \gamma^t \sum_{i \in I^t} \left[C_{\delta_+}^{ti}(\delta_+^{ti}) + C_{\delta_-}^{ti}(\delta_-^{ti}) \right]$$
(4.11)

 cost of initial stored energy and value (since it is negative) of expected leftover stored energy in terminal states

$$f_s(s_0, p_{\text{sc}}, p_{\text{sd}}) = C_{s0}^{\mathsf{T}} s_0 - (C_{ts0}^{\mathsf{T}} s_0 + C_{tsc}^{\mathsf{T}} p_{\text{sc}} + C_{tsd}^{\mathsf{T}} p_{\text{sd}})$$
(4.12)

- no load, startup and shutdown costs

$$f_{uc}(u, v, w) = \sum_{t \in T} \gamma^t \sum_{i \in I^t} \left(C_P^{ti}(0) u^{ti} + C_v^{ti} v^{ti} + C_w^{ti} w^{ti} \right)$$
(4.13)

4.2.2 Constraints

This minimization is subject to the following constraints, for all $t \in T$, all $j \in J^t$, all $k \in K^{tj}$, all $i \in I^{tjk}$, and all $l \in L^{tjk}$, beginning with the constraints that are separable by period.

Standard OPF Constraints

– power balance equations¹⁷

$$g^{tjk}(\theta^{tjk}, V^{tjk}, p^{tjk}, q^{tjk}) = 0 (4.14)$$

- transmission flow limits, voltage limits, any other OPF inequality constraints¹⁸

$$h^{tjk}(\theta^{tjk}, V^{tjk}, p^{tjk}, q^{tjk}) \le 0 \tag{4.15}$$

¹⁷These can take the form of nonlinear AC power balance equations (not yet implemented) (4.2) and (4.3), linear DC power balance equations (6.16), or a simple equating of total demand and total supply, where the equation numbers referenced are from the MATPOWER User's Manual.

¹⁸These can also take the form of inequality constraints from a nonlinear AC OPF (not yet implemented) including (6.7), (6.8) and (6.11), a linear DC OPF including (6.17) and (6.18), or a simple economic dispatch, where the equation numbers referenced are from the MATPOWER User's Manual.

Security Constraints (Option 1): Zonal Reserve Requirements¹⁹

- fixed zonal reserve requirements

$$0 \le r_z^{tijk} \le \min(R_{\text{max}+}^{ti}, \Delta_+^i) \tag{4.16}$$

$$p^{tijk} + r_z^{tijk} \le u^{ti} P_{\text{max}}^{tijk} \tag{4.17}$$

$$\sum_{i \in Z^{tjk}} r_z^{tijk} \ge R_l^{tjk} \tag{4.18}$$

Security Constraints (Option 2): Contingency Constraints¹⁹

- reserve, redispatch and contract variables

$$0 \le p_{+}^{tijk} \le r_{+}^{ti} \le R_{\max+}^{ti} \tag{4.19}$$

$$0 \le p_{-}^{tijk} \le r_{-}^{ti} \le R_{\text{max}-}^{ti} \tag{4.20}$$

$$p^{tijk} - p_c^{ti} = p_+^{tijk} - p_-^{tijk} \tag{4.21}$$

- ramping limits on transitions from base to contingency cases

$$-\Delta_{-}^{i} \le p^{tijk} - p^{tij0} \le \Delta_{+}^{i}, \quad k \ne 0$$

$$\tag{4.22}$$

The remaining sets of constraints include intertemporal restrictions and typically include constraints from a known starting point at t = 0 into the first period.

Load-following Ramping Limits and Reserves

- variable limits

$$0 \le \delta_+^{ti} \le \delta_{\text{max}+}^{ti} \tag{4.23}$$

$$0 \le \delta_{-}^{ti} \le \delta_{\max}^{ti} \tag{4.24}$$

- load-following ramp reserve definition

$$\forall \{t \in T, i \in I^{tjk}, j_1 \in J^{t-1}, j_2 \in J^t \mid \zeta^{tj_2j_1} = 1\} :$$

$$p^{tij_20} - p^{(t-1)ij_10} \le \delta_+^{(t-1)i}$$

$$(4.25)$$

$$p^{(t-1)ij_10} - p^{tij_20} \le \delta_-^{(t-1)i} \tag{4.26}$$

¹⁹A typical secure problem uses either zonal reserves or endogenous contingency reserves, but not both. Zonal reserves are typically used only for cases with a single base scenario with no contingencies, that is, when $J^t = \{1\}$ and $K^{tj} = \{0\}$.

Storage Constraints

- storage dispatch definition and limits

$$p^{tijk} = p_{sc}^{tijk} + p_{sd}^{tijk} \tag{4.27}$$

$$p_{sc}^{tijk} \le 0 \tag{4.28}$$

$$p_{\rm sd}^{tijk} \ge 0 \tag{4.29}$$

- energy bound limits

$$s_{-}^{ti} \ge S_{\min}^{ti} \tag{4.30}$$

$$s_+^{ti} \le S_{\text{max}}^{ti} \tag{4.31}$$

- storage dispatch vs. base scenario energy bounds

$$s_{-}^{ti} \le \beta_{1}^{ti} \left[\rho^{ti} s_{-}^{(t-1)i} + \left(1 - \rho^{ti} \right) \bar{s}_{I}^{tij0} \right] + \beta_{2}^{ti} s_{\Delta}^{tij0}$$
 (4.32)

$$s_{+}^{ti} \ge \beta_{1}^{ti} \left[\rho^{ti} s_{+}^{(t-1)i} + \left(1 - \rho^{ti} \right) \bar{s}_{I}^{tij0} \right] + \beta_{2}^{ti} s_{\Delta}^{tij0}$$
 (4.33)

- storage dispatch vs. contingency scenario energy limits

$$S_{\min}^{ti} \le \beta_5^{ti} \left[\rho^{ti} s_-^{(t-1)i} + \left(1 - \rho^{ti} \right) \bar{s}_I^{tij0} \right] + \beta_4^{ti} s_\Delta^{tij0} + \beta_3^{ti} s_\Delta^{tijk}, \quad k \ne 0$$
 (4.34)

$$S_{\max}^{ti} \ge \beta_5^{ti} \left[\rho^{ti} s_+^{(t-1)i} + \left(1 - \rho^{ti} \right) \bar{s}_I^{tij0} \right] + \beta_4^{ti} s_\Delta^{tij0} + \beta_3^{ti} s_\Delta^{tijk}, \quad k \ne 0$$
 (4.35)

- optional storage constraints
 - Option 1 : Constrain the expected final stored energy in each unit at the end of the horizon²⁰ to equal some target value or lie in some target range.

$$S_{\min}^{n_t i} \le S_F^{n_t i} \le S_{\max}^{n_t i} \tag{4.36}$$

 Option 2 : Constrain the expected final stored energy at the end of the horizon²⁰ to equal the initial stored energy.

$$s_F^{n_t i} = s_0^i (4.37)$$

$$S_{\min}^{0i} \le s_0^i \le S_{\max}^{0i} \tag{4.38}$$

When using this option s_0^i is an optimization variable that can take on any value between its bounds. When not using this option, it is simply a fixed parameter.

²⁰See (4.92) in the Section 4.4 for details on how $s_F^{n_t i}$ is computed as a linear function of x.

Unit Commitment

- injection limits and commitments

$$u^{ti}P_{\min}^{tijk} \le p^{tijk} \le u^{ti}P_{\max}^{tijk} \tag{4.39}$$

$$u^{ti}P_{\min}^{tijk} \leq p^{tijk} \leq u^{ti}P_{\max}^{tijk}$$

$$u^{ti}Q_{\min}^{tijk} \leq q^{tijk} \leq u^{ti}Q_{\max}^{tijk}$$

$$(4.39)$$

- startup and shutdown events

$$u^{ti} - u^{(t-1)i} = v^{ti} - w^{ti} (4.41)$$

$$0 < v^{ti} < 1 \tag{4.42}$$

$$0 \le w^{ti} \le 1 \tag{4.43}$$

- minimum up and down times

$$\sum_{y=t-\tau_i^++1}^t v^{yi} \le u^{ti} \tag{4.44}$$

$$\sum_{y=t-\tau_i^-+1}^t w^{yi} \le 1 - u^{ti} \tag{4.45}$$

Note: These summations can be made to "wrap around" to implement a cyclic commitment schedule where commitment transitions from the last period of the horizon back to the first are also constrained to be feasible.

- integrality constraints

$$u^{ti} \in \{0, 1\} \tag{4.46}$$

Dynamic Linear Time-Invariant System

The partition of the state variable corresponding to time t is denoted z^t , the corresponding output by y^t (not an explicit optimization variable), and \bar{p}^t represents the vector of expected values of p^{tijk} across j and k at time t, conditional on making it to time t, as defined in (4.4). That is

$$\bar{p}^t = \frac{1}{\gamma^t} \sum_{j \in J^t, k \in K^{tj}} \psi_{\alpha}^{tjk} p^{tjk} \tag{4.47}$$

state bounds

$$z_{\min}^t \le z^t \le z_{\max}^t, \qquad t = 1 \dots n_t^{\text{ds}} \tag{4.48}$$

state update equations

$$z^{t+1} = A_{ds}^t z^t + B_{ds}^t \bar{p}^t, t = 1 \dots n_t (4.49)$$

$$z^{t+1} = A_{ds}^t z^t, t = n_t + 1 \dots n_t^{ds} (4.50)$$

- output equations

$$y_{\min}^{t} \le C_{\text{ds}}^{t} z^{t} + D_{\text{ds}}^{t} \bar{p}^{t} \le y_{\max}^{t},$$
 $t = 1 \dots n_{t}$ (4.51)
 $y_{\min}^{t} \le C_{\text{ds}}^{t} z^{t} \le y_{\max}^{t},$ $t = n_{t} + 1 \dots n_{t}^{\text{ds}}$ (4.52)

$$y_{\min}^t \le C_{\mathrm{ds}}^t z^t \qquad \le y_{\max}^t, \qquad t = n_t + 1 \dots n_t^{\mathrm{ds}} \tag{4.52}$$

The initial state z^1 is not a variable, but is assumed to be a given initial condition.

4.3 Probability Weighting of Base and Contingency States

This section describes the assumptions regarding the probabilistic weighting of each term in the cost function. A given initial state at time t=0, with known dispatches and energy storage states, is assumed to have probability 1. From this initial state, transitions, each with some known probability, are possible to any of the scenarios considered for period t=1. Hence the probabilities assigned to each of the states in period t = 1 sum to 1.

Now, consider the transition into t=2. This transition is only possible provided the system did not branch off into any contingency at time t=1, that is, provided the realized state at t=1 is one of the base scenarios. However, given that at least one contingency has a non-zero probability of occurrence, the sum of the probabilities of these base cases for t=1 is less than 1. So the probability of actually making it to t=2 in the considered graph is equal to the sum of the probabilities of the base cases at t=1, which is less than 1. Generalizing for period t, the probability of making it to period t is equal to the sum of the probabilities of the base cases at t-1, a value less than 1 except when t=1:

$$\gamma^{t} = \sum_{j \in J^{t}} \psi^{(t-1)j0} = \sum_{j \in J^{t}, k \in K^{tj}} \psi^{tjk} < 1, \quad t > 1$$
(4.53)

While the fact that the probabilities in future periods do not sum to 1 may seem odd, this results from choosing, in an N-1 contingency fashion, to ignore the cost implications of resuming normal operations after branching off in a contingency, since that would involve exploration of a geometric number of possible paths. This implies, for the branches that have been trimmed, the existence of an unknown cost with respect to the decision variables. Since we do not have any information about the relationship of this unknown cost to our decisions, we explicitly ignore its impact by excluding it from the optimization.

The probability of transitioning to scenario j_2 in period t given that scenario j_1 was realized in period t-1 is assumed to be a known value $\phi^{tj_2j_1}$. These transition probabilities for each time step t can be arranged in a transition probability matrix.

$$\Phi^{t} = \begin{bmatrix}
\phi^{t11} & \phi^{t12} & \cdots & \phi^{t1n_{Jt-1}} \\
\phi^{t21} & \phi^{t22} & \cdots & \phi^{t2n_{Jt-1}} \\
\vdots & \vdots & \ddots & \vdots \\
\phi^{tn_{Jt}1} & \phi^{tn_{Jt}2} & \cdots & \phi^{tn_{Jt}n_{Jt-1}}
\end{bmatrix}$$
(4.54)

The columns of Φ^t sum to 1, and its coefficients are used to weight the wear and tear costs of ramping.

The individual state specific probabilities ψ^{tjk} for period t can be derived from those in period t-1 in two steps. First, the probability γ^{tj} that scenario j or any of its associated contingencies will occur at time t is given by

$$\begin{bmatrix} \gamma^{t1} \\ \gamma^{t2} \\ \vdots \\ \gamma^{tn_{J^t}} \end{bmatrix} = \Phi^t \begin{bmatrix} \psi^{(t-1)10} \\ \psi^{(t-1)20} \\ \vdots \\ \psi^{(t-1)n_{J^{t-1}0}} \end{bmatrix}$$

$$(4.55)$$

where

$$\gamma^{tj} = \sum_{k \in K^{tj}} \psi^{tjk}. \tag{4.56}$$

Since the sum across k of the conditional probabilities of contingencies ψ_0^{tjk} is 1, we simply scale each by the corresponding γ^{tj} to get the correct state specific probabilities

$$\psi^{tjk} = \gamma^{tj}\psi_0^{tjk}. (4.57)$$

Caveat Regarding Unit Commitment

The derivation of scenario probabilities presented above is based on the assumption that the conditional probability of a contingency occurring in any given state

j is fixed and independent of any optimization variables. However, in the context of unit commitment, this is not a valid assumption for a generator outage contingency. In this case the probability of that contingency goes to zero if the generator is not committed. The current MOST implementation uses the formulation described above and does not take into account this dependency of contingency probabilities on commitment status.

4.4 Value of Residual Storage

Given the complexity of the storage model, numerous derived parameters and variables were used in Section 4.2 to simplify the presentation of the problem formulation. The specifics of these derivations are presented here. This includes details of the sixth term $f_s(\cdot)$ of the objective function (4.6), specifically the last three terms of (4.12) related to the expected residual value of stored energy in terminal states. It also includes details of the storage constraints (4.32)–(4.37).

First, for each storage resource i, an efficient method is needed to compute the expected amount of stored energy at the beginning and end of each period t for each scenario j. We will denote these by the $n_{J^t} \times 1$ vectors S_I^{ti} and S_F^{ti} , respectively, where n_{J^t} is the number of scenarios in period t.

The stored energy s_F^{tij0} in unit i at the end of period t in base state j can be computed deterministically from the stored energy at the beginning s_I^{tij0} and the injections in that state, where the losses are assumed to be proportional to the average stored energy during the period. Using the definition of s_{Δ}^{tijk} from (4.3), this relationship can be expressed as follows

$$s_F^{tij0} = s_I^{tij0} + s_\Delta^{tij0} - \Delta \eta_{\text{loss}}^{ti} \frac{s_I^{tij0} + s_F^{tij0}}{2}$$
 (4.58)

$$= \beta_1^{ti} s_I^{tij0} + \beta_2^{ti} s_\Delta^{tij0}, \tag{4.59}$$

where

$$\beta_1^{ti} \equiv \frac{1 - \Delta \frac{\eta_{\text{loss}}^{ti}}{2}}{1 + \Delta \frac{\eta_{\text{loss}}^{ti}}{2}}, \quad \beta_2^{ti} \equiv \frac{1}{1 + \Delta \frac{\eta_{\text{loss}}^{ti}}{2}}.$$
 (4.60)

For a period where a contingency occurs at a fraction α of the way through the period, the losses are more tricky to compute. Let us call the expected stored energy at the moment the contingency occurs s_{α}^{tijk} , expressed as

$$s_{\alpha}^{tijk} = s_I^{tijk} + \alpha (s_F^{tij0} - s_I^{tijk}). \tag{4.61}$$

Then the losses are equal to

$$s_{\text{loss}}^{tijk} = \Delta \eta_{\text{loss}}^{ti} \left[\alpha \frac{s_I^{tijk} + s_\alpha^{tijk}}{2} + (1 - \alpha) \frac{s_\alpha^{tijk} + s_F^{tijk}}{2} \right]$$
(4.62)

$$= \Delta \eta_{\text{loss}}^{ti} \left[\alpha \frac{s_I^{tij0} + s_F^{tij0}}{2} + (1 - \alpha) \frac{s_I^{tijk} + s_F^{tijk}}{2} \right]$$
(4.63)

where (4.63) follows directly from (4.61) and (4.62), keeping in mind that $s_I^{tijk} = s_I^{tij0}$. In this case, the stored energy in unit i at the end of period t in state jk can be computed deterministically from the stored energy at the beginning and the injections in states j0 and jk as follows.

$$s_F^{tijk} = s_I^{tijk} + \alpha s_\Delta^{tij0} + (1 - \alpha) s_\Delta^{tijk} - s_{loss}^{tijk}$$

$$= \alpha \left[s_I^{tij0} + s_\Delta^{tij0} - \Delta \eta_{loss}^{ti} \frac{s_I^{tij0} + s_F^{tij0}}{2} \right]$$

$$(4.64)$$

$$+ (1 - \alpha) \left[s_I^{tijk} + s_\Delta^{tijk} - \Delta \eta_{\text{loss}}^{ti} \frac{s_I^{tijk} + s_F^{tijk}}{2} \right]$$
 (4.65)

$$= \alpha \left[\beta_1^{ti} s_I^{tij0} + \beta_2^{ti} s_{\Delta}^{tij0} \right] + (1 - \alpha) \left[s_I^{tijk} + s_{\Delta}^{tijk} - \Delta \eta_{\text{loss}}^{ti} \frac{s_I^{tijk} + s_F^{tijk}}{2} \right]$$
(4.66)

$$= \beta_5^{ti} s_I^{tijk} + \beta_4^{ti} s_\Delta^{tij0} + \beta_3^{ti} s_\Delta^{tijk} \tag{4.67}$$

where

$$\beta_3^{ti} \equiv \left(\frac{1}{1-\alpha} + \Delta \frac{\eta_{\text{loss}}^{ti}}{2}\right)^{-1}$$

$$= \frac{1-\alpha}{1+(1-\alpha)\Delta \frac{\eta_{\text{loss}}^{ti}}{2}}$$
(4.68)

$$\beta_4^{ti} \equiv \frac{\alpha}{1 - \alpha} \beta_2^{ti} \beta_3^{ti}$$

$$= \frac{\alpha}{(1 + \Delta \frac{\eta_{\text{loss}}^{ti}}{2})(1 + (1 - \alpha)\Delta \frac{\eta_{\text{loss}}^{ti}}{2})}$$
(4.69)

$$\beta_5^{ti} \equiv \frac{\beta_1^{ti}}{\beta_2^{ti}} (\beta_3^{ti} + \beta_4^{ti})$$

$$= \left(1 - \Delta \frac{\eta_{\text{loss}}^{ti}}{2}\right) \frac{\alpha + (1 - \alpha)(1 + \Delta \frac{\eta_{\text{loss}}^{ti}}{2})}{(1 + \Delta \frac{\eta_{\text{loss}}^{ti}}{2})(1 + (1 - \alpha)\Delta \frac{\eta_{\text{loss}}^{ti}}{2})}$$
(4.70)

Let G_k^{ti} and H_k^{ti} be matrices containing appropriately placed efficiencies relating the charging and discharging injections, respectively, in state jk of storage unit i in period t to the corresponding change in stored energy from the beginning to the end of the period. Specifically, the elements g_{jl}^{ti} and h_{jl}^{ti} in row j and column l of G_k^{ti} and H_k^{ti} are set as follows

$$g_{jl}^{ti} = \begin{cases} -\Delta \eta_{\text{in}}^{ti}, & \text{where column } l \text{ corresponds to } p_{\text{sc}}^{tijk} \\ 0, & \text{otherwise} \end{cases}$$
(4.71)

$$h_{jl}^{ti} = \begin{cases} -\Delta \frac{1}{\eta_{\text{out}}^{ti}}, & \text{where column } l \text{ corresponds to } p_{\text{sd}}^{tijk} \\ 0, & \text{otherwise} \end{cases}$$
(4.72)

The reason for keeping G_k^{ti} and H_k^{ti} separate is to make it possible to use different prices to represent the gain in value from increasing the amount of residual storage and the loss in value from reducing the amount of residual storage. The need to use different prices to value charging and discharging is supported by the intuition that stored energy should not be used in a given terminal state if there is a better time to use it (expect a higher price on the horizon), neither should we be storing additional energy in a given terminal state if there is a better time to store it (expect a lower price on the horizon).

Using these matrices, (4.59) can be expressed for the vector S_F^{ti} as a deterministic function of S_I^{ti} and the injections as

$$S_F^{ti} = \beta_1^{ti} S_I^{ti} + \beta_2^{ti} (G_0^{ti} + H_0^{ti}) x \tag{4.73}$$

On the other hand, the expected stored energy in each scenario at the beginning of period t depends on the corresponding values at the end of period t-1 and the transition probabilities. Let σ^t equal the vector of probabilities of each of the base scenarios at the end of period t-1, conditional on arriving at the end of that period without the occurrence of a continency.

$$\sigma^{t} \equiv \frac{1}{\gamma^{t}} \psi^{(t-1)J0} = \frac{1}{\gamma^{t}} \begin{bmatrix} \psi^{(t-1)10} \\ \psi^{(t-1)20} \\ \vdots \\ \psi^{(t-1)n_{J^{t-1}}0} \end{bmatrix}. \tag{4.74}$$

If we also let [a] denote a diagonal matrix with the vector a on the main diagonal, then the relationship between S_I^{ti} and $S_F^{(t-1)i}$ can be expressed as

$$\left[\Phi^t \sigma^t\right] S_I^{ti} = \Phi^t \left[\sigma^t\right] S_F^{(t-1)i}. \tag{4.75}$$

In other words,

$$S_I^{ti} = D^{ti} S_F^{(t-1)i} (4.76)$$

where

$$D^{ti} \equiv \begin{cases} \mathbf{1}_{n_{J^t} \times 1}, & t = 1\\ \left[\Phi^t \sigma^t\right]^{-1} \Phi^t \left[\sigma^t\right], & t \neq 1. \end{cases}$$
 (4.77)

Stacking the vectors S_I^{ti} and S_F^{ti} for all storage units (*i* from 1 to n_s) allows the relationships above to be expressed in terms of matrices formed by stacking the D^{ti} along the diagonals and the G_k^{ti} and H_k^{ti} vertically.

$$D^{t} = \begin{bmatrix} D^{t1} & 0 & \cdots & 0 \\ 0 & D^{t2} & \cdots & 0 \\ \vdots & \vdots & \ddots & \vdots \\ 0 & 0 & \cdots & D^{tn_{s}} \end{bmatrix}, G_{k}^{t} = \begin{bmatrix} G_{k}^{t1} \\ G_{k}^{t2} \\ \vdots \\ G_{k}^{tn_{s}} \end{bmatrix}, H_{k}^{t} = \begin{bmatrix} H_{k}^{t1} \\ H_{k}^{t2} \\ \vdots \\ H_{k}^{tn_{s}} \end{bmatrix}$$
(4.78)

Similarly, scalars β_n^{ti} are converted to diagonal matrices $B_n^{ti} \equiv \beta_n^{ti} \cdot I_{n_{J^t} \times n_{J^t}}$ and stacked to form

$$B_n^t = \begin{bmatrix} B_n^{t1} & 0 & \cdots & 0 \\ 0 & B_n^{t2} & \cdots & 0 \\ \vdots & \vdots & \ddots & \vdots \\ 0 & 0 & \cdots & B_n^{tn_s} \end{bmatrix}. \tag{4.79}$$

The full expression for all storage units in all scenarios in period t can then be expressed as follows.

$$S_I^t = D^t S_F^{(t-1)} (4.80)$$

$$S_F^t = B_1^t S_I^t + B_2^t (G_0^t + H_0^t) x (4.81)$$

The relationships in (4.80) and (4.81) imply that the expected stored energy at any point in the planning horizon can be expressed in the following form as a linear function of the expected initial stored energy s_0 and the active power injections in x, specifically the injections of the storage units.

$$S_I^t = L_I^t s_0 + (M_g^t + M_h^t) x (4.82)$$

$$S_F^t = L_F^t s_0 + (N_q^t + N_h^t) x (4.83)$$

The following recursive expressions can be used for computing L_I^t , L_F^t , M_g^t , M_h^t , N_g^t

and N_h^t

$$L_I^t = D^t L_F^{(t-1)} = D^t B_1^{(t-1)} L_I^{(t-1)}$$
 (4.84)

$$L_F^t = B_1^t L_I^t = B_1^t D^t L_F^{(t-1)}$$

$$M_g^t = D^t N_g^{(t-1)}$$
(4.85)

$$M_a^t = D^t N_a^{(t-1)} (4.86)$$

$$M_h^t = D^t N_h^{(t-1)} (4.87)$$

$$N_q^t = B_1^t M_q^t + B_2^t G_0^t (4.88)$$

$$N_h^t = B_1^t M_h^t + B_2^t H_0^t, (4.89)$$

where $L_I^1 = D^1$ and $M_g^1 = M_h^1 = \mathbf{0}$.

If the rows of each of these vectors and matrices are sorted and partitioned by scenario (as opposed to by storage unit), we can denote the resulting j-th components, whose *i*-th row corresponds to storage unit *i*, with a bar, for example \bar{S}_F^{tj} , \bar{S}_{I}^{tj} , \bar{G}_{k}^{tj} , \bar{H}_{k}^{tj} , \bar{L}_{I}^{tj} , \bar{L}_{F}^{tj} , \bar{M}_{g}^{tj} , \bar{M}_{h}^{tj} , \bar{N}_{g}^{tj} and \bar{N}_{h}^{tj} . It should be noted that for the B matrices, the corresponding \bar{B}_{n}^{tj} is just the diagonal matrix $[\beta_{n}^{t}]$, with the individual β_n^{ti} on the diagonal. Using this notation, the expected residual stored energy for all units in a base scenario j at the end of the last period n_t of the horizon, the vector $\bar{S}_{F}^{n_{t}j}$ can be written as a function of these matrices

$$\begin{split} \bar{S}_F^{n_t j} &= [\beta_1^t] \bar{S}_I^{n_t j} + [\beta_2^t] (\bar{G}_0^{n_t j} + \bar{H}_0^{n_t j}) x \\ &= [\beta_1^t] \left(\bar{L}_I^{n_t j} s_0 + (\bar{M}_g^{n_t j} + \bar{M}_h^{n_t j}) x \right) + [\beta_2^t] (\bar{G}_0^{n_t j} + \bar{H}_0^{n_t j}) x \\ &= [\beta_1^t] \bar{L}_I^{n_t j} s_0 + \left([\beta_1^t] \bar{M}_g^{n_t j} + [\beta_2^t] \bar{G}_0^{n_t j} + [\beta_1^t] \bar{M}_h^{n_t j} + [\beta_2^t] \bar{H}_0^{n_t j} \right) x. \end{split}$$
(4.90)

Likewise, the expected residual stored energy at the end of period t for any scenario jand contingency k is expressed as follows,

$$\bar{S}_{F}^{tjk} = [\beta_{5}^{t}] \bar{S}_{I}^{tj} + [\beta_{4}^{t}] \bar{S}_{\Delta}^{tj0} + [\beta_{3}^{t}] \bar{S}_{\Delta}^{tjk}
= [\beta_{5}^{t}] \bar{S}_{I}^{tj} + ([\beta_{4}^{t}] (\bar{G}_{0}^{tj} + \bar{H}_{0}^{tj}) + [\beta_{3}^{t}] (\bar{G}_{k}^{tj} + \bar{H}_{k}^{tj})) x
= [\beta_{5}^{t}] (\bar{L}_{I}^{tj} s_{0} + (\bar{M}_{g}^{tj} + \bar{M}_{k}^{tj}) x) + ([\beta_{4}^{t}] (\bar{G}_{0}^{tj} + \bar{H}_{0}^{tj}) + [\beta_{3}^{t}] (\bar{G}_{k}^{tj} + \bar{H}_{k}^{tj})) x
= [\beta_{5}^{t}] \bar{L}_{I}^{tj} s_{0} + ([\beta_{5}^{t}] \bar{M}_{g}^{tj} + [\beta_{4}^{t}] \bar{G}_{0}^{tj} + [\beta_{3}^{t}] \bar{G}_{k}^{tj}
+ [\beta_{5}^{t}] \bar{M}_{b}^{tj} + [\beta_{4}^{t}] \bar{H}_{0}^{tj} + [\beta_{3}^{t}] \bar{H}_{k}^{tj}) x.$$
(4.91)

The overall expected quantity of stored energy across all non-contingency states at the end of the horizon is given by

$$s_F^{n_t} = \frac{1}{\gamma^{(n_t+1)}} \sum_{j \in J^{n_t}} \psi^{n_t j 0} \bar{S}_F^{n_t j}$$
(4.92)

where $\gamma^{(n_t+1)} = \sum_j \psi^{n_t j 0}$. This expression can be used in contraints, such as (4.36) or (4.37) or in constructing terms of the objective function.

Finally, we return to the value, call it $v_s(x)$, of the expected stored energy leftover in terminal states, expressed in the last three terms of f_s in (4.12).

$$v_S(x) = C_{\text{ts0}}^{\mathsf{T}} s_0 + C_{\text{tsc}}^{\mathsf{T}} p_{\text{sc}} + C_{\text{tsd}}^{\mathsf{T}} p_{\text{sd}}$$

$$\tag{4.93}$$

If we were to use a single price for each storage unit i to value all contributions to that expected leftover energy, regardless of the state in which they occur, then the value $v_S(x)$ would be that price times a simple probability-weighted sum of the energy in each state, modified by the output efficiency. To be more precise, the price relates to the value of each MW of recoverable energy²¹ as opposed to stored energy.

$$v_S(x) = C_s^{\mathsf{T}} \left([\eta_{\text{out}}^{n_t}] \sum_{j \in J^{n_t}} \psi^{n_t j 0} \bar{S}_F^{n_t j} + \sum_{t \in T} [\eta_{\text{out}}^t] \sum_{j \in J^t} \sum_{k \in K^{tj} \neq 0} \psi^{tjk} \bar{S}_F^{tjk} \right)$$
(4.94)

However, it may be useful to classify the system states into three categories: terminal contingency states, terminal end-of-horizon base states, and non-terminal states (base states preceding the last period). This allows for the possibility of valuing differently the contributions made to the expected terminal stored energy in each of these categories of states. It may also be useful to differentiate between the value gained by increasing the expected terminal stored energy and the value lost by decreasing it.

Table 4-1: Five Price Model

price	applies to contributions from
C_s $C_{ m sc0}$ $C_{ m sd0}$ $C_{ m sc}$ $C_{ m sc}$ $C_{ m sd}$	charging and discharging in non-terminal states charging in terminal end-of-horizon base states discharging in terminal end-of-horizon base states charging in terminal contingency states discharging in terminal contingency states

This leads to the current design based on the five price model summarized in Table 4-1. Expressing (4.94) in terms of (4.90) and (4.91), splitting up the terms and applying different prices to the five different types of contributions to the expected terminal storage quantities, yields the following.

 $^{^{21}}$ It is not the amount of energy stored that is of interest, but rather the amount which can be recovered after output efficiency losses η_{out}^{ti} .

$$v_S(x) = C_s^{\mathsf{T}}(A_1 s_0 + A_2 x + A_3 x) + C_{\text{sc0}}^{\mathsf{T}} A_4 x + C_{\text{sd0}}^{\mathsf{T}} A_5 x + C_{\text{sck}}^{\mathsf{T}} A_6 x + C_{\text{sdk}}^{\mathsf{T}} A_7 x$$
(4.95)

where

$$A_{1} = [\eta_{\text{out}}^{n_{t}}][\beta_{1}^{n_{t}}] \sum_{j \in J^{n_{t}}} \psi^{n_{t}j0} \bar{L}_{I}^{n_{t}j} + \sum_{t \in T} [\eta_{\text{out}}^{t}][\beta_{5}^{t}] \sum_{j \in J^{t}} \left(\sum_{k \in K^{tj} \neq 0} \psi^{tjk} \right) \bar{L}_{I}^{tj}$$

$$(4.96)$$

$$A_{2} = [\eta_{\text{out}}^{n_{t}}][\beta_{1}^{n_{t}}] \sum_{j \in J^{n_{t}}} \psi^{n_{t}j0} \bar{M}_{g}^{n_{t}j} + \sum_{t \in T} [\eta_{\text{out}}^{t}] \sum_{j \in J^{t}} \left(\sum_{k \in K^{tj} \neq 0} \psi^{tjk} \right) \left([\beta_{5}^{t}] \bar{M}_{g}^{tj} + [\beta_{4}^{t}] \bar{G}_{0}^{tj} \right)$$

$$(4.97)$$

$$A_{3} = [\eta_{\text{out}}^{n_{t}}][\beta_{1}^{n_{t}}] \sum_{j \in J^{n_{t}}} \psi^{n_{t}j0} \bar{M}_{h}^{n_{t}j} + \sum_{t \in T} [\eta_{\text{out}}^{t}] \sum_{j \in J^{t}} \left(\sum_{k \in K^{tj} \neq 0} \psi^{tjk} \right) \left([\beta_{5}^{t}] \bar{M}_{h}^{tj} + [\beta_{4}^{t}] \bar{H}_{0}^{tj} \right)$$

$$(4.98)$$

$$A_4 = [\eta_{\text{out}}^{n_t}][\beta_2^{n_t}] \sum_{j \in J^{n_t}} \psi^{n_t j 0} \bar{G}_0^{n_t j}$$
(4.99)

$$A_5 = [\eta_{\text{out}}^{n_t}][\beta_2^{n_t}] \sum_{j \in J^{n_t}} \psi^{n_t j 0} \bar{H}_0^{n_t j}$$
(4.100)

$$A_6 = \sum_{t \in T} [\eta_{\text{out}}^t] [\beta_3^t] \sum_{j \in J^t} \sum_{k \in K^{tj} \neq 0} \psi^{tjk} \bar{G}_k^{tj}$$
(4.101)

$$A_7 = \sum_{t \in T} [\eta_{\text{out}}^t] [\beta_3^t] \sum_{j \in J^t} \sum_{k \in K^{tj} \neq 0} \psi^{tjk} \bar{H}_k^{tj}$$
(4.102)

If we use \bar{A}_n to represent the version of A_n with all columns removed except for those corresponding to the relevant charging and discharging injections ($p_{\rm sc}$ for n=2,4,6 and $p_{\rm sd}$ for n=3,5,7), then we can express the cost of initial and terminal stored energy f_s from (4.12) as

$$f_s(s_0, p_{\text{sc}}, p_{\text{sd}}) = C_{s0}^{\mathsf{T}} s_0 - v_S(x)$$

= $C_{s0}^{\mathsf{T}} s_0 - (C_{\text{ts0}}^{\mathsf{T}} s_0 + C_{\text{tsc}}^{\mathsf{T}} p_{\text{sc}} + C_{\text{tsd}}^{\mathsf{T}} p_{\text{sd}})$ (4.103)

where

$$C_{\rm ts0} = A_1^{\mathsf{T}} C_s \tag{4.104}$$

$$C_{\text{tsc}} = \bar{A}_2^{\mathsf{T}} C_s + \bar{A}_4^{\mathsf{T}} C_{\text{sc0}} + \bar{A}_6^{\mathsf{T}} C_{\text{sck}}$$

$$C_{\text{tsd}} = \bar{A}_3^{\mathsf{T}} C_s + \bar{A}_5^{\mathsf{T}} C_{\text{sd0}} + \bar{A}_7^{\mathsf{T}} C_{\text{sdk}}.$$

$$(4.105)$$

$$C_{\text{tsd}} = \bar{A}_3^{\mathsf{T}} C_s + \bar{A}_5^{\mathsf{T}} C_{\text{sd0}} + \bar{A}_7^{\mathsf{T}} C_{\text{sd}k}. \tag{4.106}$$

5 most

In MATPOWER, a MOST optimization problem is executed by calling most with a MOST Data struct as the first argument (md_in). The results are returned in an updated MOST Data struct (md_out). An additional optional input argument can be used to set options (mpopt).

The following sections describe the input data, the MOST options, the MOST Data struct itself, including the results, and some additional considerations.

5.1 Input Data

The MOST Data struct, containing all of the data needed for the problem, is sufficiently complex that it is not typically created directly, but rather is assembled from numerous other files or data structures by the loadmd function.

```
md_in = loadmd(mpc, transmat, xgd, sd, contab, profiles);
```

The following sections describe the input arguments to loadmd and the way they are normally constructed. Except for the transition probability matrices, all parameters which vary from period to period are specified via profiles, as per-period changes applied to a set of base values provided in the other input arguments.

Since the input arguments to loadmd are handled by loadgenericdata (see Section 6.8 for details), they can either take the form of the data structure described in each section below, or a string containing the name of an M-file or MAT-file that returns the required data structure.

5.1.1 mpc - Matpower Case

The mpc argument is a MATPOWER case, specified either as a file name or a struct, to be passed by loadmd as an input to loadcase from Section 9.1.1 in the MATPOWER User's Manual. This case corresponds to the base case from which all other cases, corresponding to different time periods, scenarios and contingency states, are built using change tables and the apply_changes function described in Section 9.3.5 in the MATPOWER User's Manual.

If the problem you are setting up includes storage resources or wind generators, it may be simpler to exclude these from the gen matrix in mpc and add them later using the addstorage and addwind functions described below in Sections 6.2 and 6.3.

5.1.2 transmat – Transition Probability Matrices

In the general case of a stochastic model with multiple base scenarios per period, transmat is a cell array of length n_t containing the transition probability matrices Φ^t of (4.54). That is, transmat{t} contains the $n_{J^t} \times n_{J^{(t-1)}}$ matrix of transition probabilities from period t-1 to period t. The first element transmat{1} is a column vector of transition probabilities from period 0 ($n_{J^t} = 1$) to period 1.

For deterministic models or secure models with contingencies but only a single base scenario per period, transmat can simply be an integer n_t specifying the number of periods in the planning horizon and it will be expanded internally to a cell array of 1's with the appropriate length. If the problem is also single period, transmat is optional, with a default value of 1.

5.1.3 xgd - Extra Generator Data (xGenData)

The optional xgd argument is an xGenData struct containing base values for all of the per-generator data required for the problem that are not included in mpc, that is, in the standard MATPOWER case data. This includes unit commitment (UC) data, reserve offer data, ramping costs, and more. Table 5-1 presents the details of the xGenData struct, whose fields are all $n_q \times 1$ vectors of per generator values.

An xGenData struct is typically created from a data file or struct in the xGenDataTable format via the loadxgendata function described in Section 6.11. In this context, all fields are optional and loadxgendata will provide defaults for anything not explicitly specified. The addstorage and addwind functions described in Sections 6.2 and 6.3 also return xGenData by calling the loadxgendata function internally.

Table 5-1: ${\sf Fields}^*$ of ${\sf xGenData}$ struct (${\sf xgd}$)

name	$default^{\dagger}$	description
CommitSched	С	0 or 1, UC status to use for non-UC runs
InitialPg	P	active power dispatch at time $t = 0$
TerminalPg		active power dispatch at time $t = n_t + 1$ (only included if explicitly specified)
RampWearCostCoeff	0	quadratic coefficient for $C^i_{\delta}(\cdot)^{\ddagger}$ in (4.10)
PositiveActiveReservePrice	0	linear coefficient for $C_{R+}^{ti}(\cdot)^{\ddagger}$ in (4.9)
PositiveActiveReserveQuantity	R	max upward reserve quantity $R_{\text{max}+}^{ti}$ in (4.19)
NegativeActiveReservePrice	0	linear coefficient for $C_{R-}^{ti}(\cdot)^{\ddagger}$ in (4.9)
NegativeActiveReserveQuantity	R	max downward reserve quantity $R_{\text{max}-}^{ti}$ in (4.20)
PositiveActiveDeltaPrice	0	linear coefficient for $C_{P+}^{ti}(\cdot)^{\ddagger}$ in (4.7)
NegativeActiveDeltaPrice	0	linear coefficient for $C_{P-}^{ti}(\cdot)^{\ddagger}$ in (4.7)
${\tt PositiveLoadFollowReservePrice}$	0	linear coefficient for $C_{\delta+}^{ti}(\cdot)^{\ddagger}$ in (4.11)
${\tt PositiveLoadFollowReserveQuantity}$	R	max upward ramp reserve $\delta_{\text{max}+}^{ti}$ in (4.23)
${\tt NegativeLoadFollowReservePrice}$	0	linear coefficient for $C_{\delta-}^{ti}(\cdot)^{\ddagger}$ in (4.11)
${\tt NegativeLoadFollowReserveQuantity}$	R	max downward ramp reserve δ_{\max}^{ti} in
CommitKey		(4.24) required for problems with UC -1 – offline, unit forced off 0 or 1 – available for UC decisions 2 – must run, unit forced on
${\tt InitialState}^\S$	$\pm\infty^\P$	if positive (negative), number of uptime
		(downtime) periods at time $t = 0$
${\tt MinUp}^\S$	1	minimum up time in number of periods
$ exttt{MinDown}^{ exttt{S}}$	1	minimum down time in number of periods

^{*} All fields are $n_g \times 1$ vectors of per-generator values.

[†] These are defaults provided by loadxgendata. If gen is provided, either directly or as the gen field of mpc, then P = gen(:, PG), C = gen(:, GEN_STATUS) and R = 2*(gen(:, PMAX) - MIN(0, gen(:, PMIN))), otherwise C = 1, R = 0 and no default is provided for P (corresponding field is not optional).

[‡] Each of these costs $C(\cdot)$ is presented in the formulation as a general function, but is implemented as a simple linear function of the form C(x) = ax, where the linear coefficient being supplied is a. The only exception is the ramping cost, which has the quadratic form $C_{\delta}^{i}(x) = ax^{2}$.

[§] Requires that CommitKey be present and non-empty.

[¶] Sign is based on C^{\dagger} , i.e. $+\infty$ for C = 1, $-\infty$ for C = 0.

5.1.4 sd - Storage Data (StorageData)

The optional sd argument is a StorageData struct containing base values for all of the storage unit data required for the problem that are not included in the standard MATPOWER case mpc or in the xGenData.

This includes bounds on stored energy (capacities), efficiencies, loss factors, initial and terminal values, prices used to value leftover storage, and more. Table 5-2 presents the details of the StorageData struct, whose fields are all $n_s \times 1$ vectors of per storage unit values, except where indicated otherwise.

A StorageData struct is typically created from data files or structs in StorageDataTable format via the loadstoragedata function described in Section 6.10. The addstorage function from Section 6.2 also returns StorageData by calling the loadstoragedata function internally.

5.1.5 contab – Contingency Table

The optional contab argument is a contingency table with a master set of contingencies used for security throughout entire horizon. It is a matrix in the form of a change table recognized by apply_changes, described in Section 9.3.5 in the MATPOWER User's Manual. The probabilities defined in this contingency table correspond to the conditional probabilities ψ_0^{tjk} of contingency k occurring conditioned on being in base scenario j. While the MOST Data struct (md) itself allows for contingencies to be defined independently for all scenarios and time periods, loadmd applies a single set of contingencies and conditional probabilities (single contab) to all.

Table 5-2: Fields* of StorageData struct (sd)

name	default	description
UnitIdx		
ExpectedTerminalStorageAim	$none \ none^\dagger$	corresponding row index into gen matrix target value for expected final stored energy at
Expectedielminaistoragenim	none	end of last period, overrides any values pro-
		vided for both ExpectedTerminalStorageMin and
		ExpectedTerminalStorageMax
ExpectedTerminalStorageMax	$none^{\dagger}$	upper bound $S_{\max}^{n_t i}$ on expected final stored energy
Expectediciminals for agenax	100100	at end of last period in (4.36)
ExpectedTerminalStorageMin	$none^{\dagger}$	lower bound $S_{\min}^{n_t i}$ on expected final stored energy at
		end of last period in (4.36)
InitialStorage	none	value for initial (expected) stored energy s_0
${\tt InitialStorageCost}$	$none^{\ddagger}$	cost C_{s0} associated with starting with amount s_0 at
		time $t = 0$
${\tt InitialStorageLowerBound}$	$none^{\ddagger}$	lower bound S_{\min}^{0i} on inital (expected) stored energy
		$s_0 \text{ in } (4.38)$
${\tt InitialStorageUpperBound}$	$none^{\ddagger}$	upper bound S_{max}^{0i} on inital (expected) stored en-
-		ergy s_0 in (4.38)
InEff¶	1	input efficiency η_{in}^{ti}
OutEff¶	1	output efficiency η_{out}^{ti}
LossFactor¶	0	fraction of stored energy lost per hour η_{loss}^{ti}
$ exttt{MaxStorageLevel}^\P$	none	stored energy maximum limit S_{max}^{ti}
${\tt MinStorageLevel}^\P$	none	stored energy minimum limit S_{\min}^{ti}
${ t rho}^\P$	1	ρ^{ti} parameter controlling weighting of worst case
		$(\rho^{ti}=1)$ and expected values $(\rho^{ti}=0)$ for defining
		storage constraints in (4.32) – (4.35)
TerminalStoragePrice		prices C_s for contributions to terminal storage from
	- C	charging/discharging in non-terminal states
TerminalChargingPrice0	C_s §	prices $C_{\rm sc0}$ for contributions to terminal storage
	~ °	from charging in terminal end-of-horizon base states
TerminalDischargingPriceO	C_s §	prices $C_{\rm sd0}$ for contributions to terminal storage
		from discharging in terminal end-of-horizon base
	~ 8	states
TerminalChargingPriceK	C_s §	prices $C_{\mathrm{sc}k}$ for contributions to terminal storage
	C 8	from charging in terminal contingency states
${ t Terminal Discharging Price K}$	C_s §	prices $C_{\mathrm{sd}k}$ for contributions to terminal storage
		from discharging in terminal contingency states

^{*} All fields are $n_s \times 1$ vectors of per storage unit values, except where indicated otherwise. If no default is specified, it means the field is required.

[†] If the most.storage.terminal_target option is set to 0, the ExpectedTerminalStorage* parameters are optional and ignored; if set to 1, at least one of them is required; if set to -1, the presence of any of the optional ExpectedTerminalStorage* parameters will turn the most.storage.terminal_target option on.

[‡] If the most.storage.cyclic option is set to 1, InitialStorageCost is required and the default values of the initial storage bounds InitialStorageLowerBound and InitialStorageUpperBound are taken from MinStorageLevel(:, 1) and MaxStorageLevel(:, 1), respectively, otherwise InitialStorageCost is optional and both initial storage bounds default to InitialStorage.

[¶] Can also be a scalar, in which case the value will be used for all storage units.

[§] That is, the default is taken from TerminalStoragePrice.

5.1.6 profiles - Profiles for Time-Varying Parameters

Profiles are used to specify how parameters vary from period to period and are defined in terms of changes to a base value. There are currently three different types of data that can be changed by a profile, corresponding to the base values provided by the mpc, xgd and sd arguments to loadmd.

A profile is a struct that specifies, for a given set of changes to be applied across time periods and scenarios, the type of data, the table or field, the elements in that table or field, the method of modification and the values to be applied. Table 5-3 summarizes the structure of the profile struct.

Table 5-3: Fields of Profle Struct (profile)

name	description			
type	string defining type of target data structure modified by the profile 'mpcData' - parameters in fields of mpc, e.g. bus, gen, gencost, etc.* 'xGenData' - parameters in fields of xGenData, e.g. reserve offers, commitment parameters, etc.			
	'StorageData' - parameters in fields of StorageData, e.g. storage capacities, efficiencies, etc.			
table	numeric scalar or string identifying the table or field; valid values depend on type type = 'mpcData' - numeric values defined in Table 9-2 in the MATPOWER User's Manual			
	type = 'xGenData' - string-valued field names defined in Table 5-1 type = 'StorageData' - string-valued field names defined in Table 5-2			
rows	vector of indices of rows (first dimension) of array to be modified, or area indices for area-wide modifications; 0 means "apply to all"			
col	column index or other ID of parameter to modify as defined in Table 9-4 in the MATPOWER User's Manual; ignored unless type = 'mpcData'			
chgtype values	MATPOWER User's Manual; ignored unless type = 'mpcData' method of modification, see Table 9-3 in the MATPOWER User's Manual $n_1 \times n_2 \times n_3$ numeric array containing the new values or scale/shift factors n_1 - corresponds to number of time periods n_t n_2 - corresponds to number of scenarios n_j^{\max} n_3 - corresponds to number of elements indicated by rows A singleton dimension in values not matching with $n_t = 1$ or $n_j^{\max} = 1$ or length(profile.rows) = 1 is interpreted as "apply to all" whenever the parameter being modified allows such an expansion.			

^{*} Possible modifications are as implemented by Matpower's apply_changes function. See Section 9.3.5 in the Matpower User's Manual.

Section 6.7 describes idx_profile which defines a number of constants that are useful for specifying profiles. The apply_profile function from Section 6.4 is used internally by loadmd to apply the profiles. And getprofiles from Section 6.6 is used to load a profile or set of profiles from a struct, MAT-file or M-file function.

5.2 MOST Options

In addition to making use of the verbose option and the solver-specific options, such as those under the fields cplex, glpk, gurobi, etc. as documented in Appendix C in the MATPOWER User's Manual, there are also a number of options specific to MOST that appear under a most field in the standard MATPOWER options struct. These can be classified into two main categories and are described in Tables 5-4 and 5-5. The first consists of options related to how most is run, such as the solver to use and the phases of the problem building and solving to be included. The second is all of the options controlling various details of the model to be built and solved.

Table 5-4: MOST Run Options

name	default	description
most.solver	'DEFAULT'	solver option passed in opt.alg to miqps_matpower or qps_matpower, see miqps_matpower or qps_matpower for details
most.skip_prices	0	skip price computation stage for mixed integer prob- lems, see miqps_matpower for details
most.price_stage_warn_tol	10^{-7}	tolerance on the objective function value and primal variable relative match required to avoid mis-match warning message, see miqps_matpower for details
most.build_model	1	toggle building of MIQP model 0 – do not build MIQP, assume it has already been built
most.solve_model	1	 1 - build MIQP, both constraints and standard costs (not coordination cost[†]) and store in md_out.QP toggle solving of MIQP model 0 - do not solve MIQP, assume it is just being built; requires 'most.build_model' set to 1
most.resolve_new_cost	0	 1 - solve MIQP; if coordination cost[†] exists, update it; requires either 'most.build_model' set to 1 or md_in.QP must contain previously built model toggle solving pre-built MIQP with updated coordination cost[‡] 0 - build full MIQP from scratch, then solve 1 - solve pre-built MIQP with updated coordination cost[†]

[†] Coordination costs are related to a price coordination scheme employed in a decomposition used for solving the non-linear AC formulation (not yet implemented).

[‡] Requires 'most.solve_model' set to 1.

Table 5-5: MOST Model Options

name	default	description
most.dc_model	1	power balance model 0 – use simple total power balance constraint \sum generation = \sum demand 1 – use DC power flow network model
${\tt most.q_coordination}$	0	create q^{tijk} variables for reactive power coordination (0 or 1)
${\tt most.security_constraints}$	-1	include contingency constraints for security $-1 - \text{if contingencies specified}$ $0 - \text{never}$ $1 - \text{always}$
${\tt most.storage.terminal_target}$	-1	constrain expected terminal storage to a target range [†] -1 – if target range specified 0 – never 1 – always
most.storage.cyclic	0	use cyclic storage constraints $(4.37)^{\dagger}$ $0 - off$, initial storage s_0^i is a fixed parameter, no constraint on final expected storage $s_F^{n_t i}$ $1 - on$, initial storage s_0^i is an optimization variable constrained to equal final expected storage $s_F^{n_t i}$
most.uc.run	-1	flag to indicate whether to perform unit commitment -1 - perform unit commitment if and only if md_in.UC.CommitKey is present and non- empty 0 - do not perform unit commitment 1 - do perform unit commitment
most.uc.cyclic	0	commitment restrictions (e.g. min up and down times) roll over from end of horizon back to beginning (0 or 1)
most.alpha	0	α , for contingency states, fraction of period spent in base state before contingency occurs (0–1)

 $^{^{\}dagger}$ The most.storage.terminal_target and most.storage.cyclic options cannot be used simultaneously (i.e. at least one of them must be set to 0).

5.3 MOST Data struct

5.3.1 Input Data

The input to the most function takes the form of a MOST Data struct, a single MATLAB struct md, with the primary input fields described in Tables 5-6 through 5-9. As described previously in Section 5.1, a MOST Data struct is typically not constructed directly, but rather assembled from various other inputs by the loadmd function. However, some of the features, such as fixed zonal reserve requirements, binary transition masks for load-following ramp, or dynamic linear time-invariant system constraints, are only available by modifying portions of the MOST Data struct directly.

Table 5-6: Input Data Fields of md

name	type^*	default	description
cont(t,j).contab	Ι	empty	changes table † defining contingencies for period $t,$ scenario j
Delta_T	I	1	length of time step in hours
idx.nt	I		number of periods in scheduling horizon
IncludeFixedReserves	Ι	0	1 or 0, indicating whether to enable fixed zonal reserves (4.8) , $(4.16)-(4.18)$
<pre>InitialPg(i)</pre>	I		$n_g \times 1$, injection of generator i at $t = 0$
mpc	Ι		base system data, standard MATPOWER case struct; with baseMVA, bus, gen, branch and gencost fields
offer(t)	Ι		struct with offer data for period t , see Table 5-8 for details of sub-fields
OpenEnded	Ι	1	ignore terminal dispatch ramp constraints, $depre-cated$
<pre>RampWearCostCoeff(i,t)</pre>	Ι	0	$n_g \times n_t$, cost of ramping of generator i from period $t-1$ to t , coefficient C^i_{δ} for square of dispatch difference in (4.10)
Storage	В		struct with parameters for storage units, see Table 5-9 for the input fields
TerminalPg(i)	Ι		$n_g \times 1$, injection of generator i at $t = n_t$, deprecated, untested
tstep(t)	В		$n_t \times 1$ struct of parameters related to period t
.OpCondSched(j).tab	Ι		changes table defining modifications from \mathtt{mpc} for each base scenario j in period t
.TransMask	Ι		an $n_{j(t)} \times n_{j(t-1)}$ matrix of binary transition masks $\zeta^{tj_2j_1}$ from scenario j_1 in period $t-1$ to j_2 in period t , see Section 6.5
.TransMat	Ι		Φ^t , an $n_{j(t)} \times n_{j(t-1)}$ matrix of transition probabilities $\phi^{tj_2j_1}$ from scenario j_1 in period $t-1$ to j_2 in period t , see Section 5.1.2

^{*} I = input, O = output, B = both, opt = taken from Matpower options.

† See Section 5.1.5 for details. Note that, while loadmd assigns the same contab to all t and j, it is possible to set different contab values manually and they will be respected by most.

‡ See Appendix B in the MATPOWER User's Manual for details.

Table 5-7: Additional Input Data Fields of md

name	type*	default	description
CoordCost	I	empty	user supplied coordination costs for AC version
.Huser	I	Chipty	sparse matrix of quadratic coefficients
.Cuser	Ī		vector of linear coefficients
.cuser	Ī		scalar constant term
dstep(t)	Ī	empty	$n_t^{ m ds} imes 1$ struct with parameters for optional dy-
db ocp (v)	1	cmpeg	namic system model, (4.48) – (4.52)
. A	I		$A_{\rm ds}^t$, from $(4.49)-(4.50)$
.B	I		$B_{\mathrm{ds}}^{\mathrm{ds}}$, from (4.49)
.C	I		$C_{\rm ds}^{\rm ds}$, from $(4.51)-(4.52)$
.D	I		D_{ds}^{t} , from (4.51)
.ymin	I		y_{\min}^{t} , lower bound on output from (4.51) – (4.52)
.ymax	I		y_{max}^t , upper bound on output from (4.51) – (4.52)
.zmin	I		z_{\min}^t , lower bound on z^t from (4.48)
.zmax	I		z_{max}^t , upper bound on z^t from (4.48)
<pre>FixedReserves(t,j,k)</pre>	I	empty	zonal reserve input parameters for period t , sce-
			nario j , contingency k , in form of reserves field
			of mpc from Table 7-1 in the MATPOWER User's
			Manual, with cost, qty, zones, req sub-fields.
UC	В		struct with unit commitment parameters
. CommitKey(i,t)	I	empty	optional $n_g \times n_t$ vector specifying availability of
			unit i for commitment at time t
			-1 – offline, unit forced off
			0 or 1 – available for UC decisions
			2 – must run, unit forced on
.CommitSched(i,t)	В		$n_g \times n_t$ matrix UC status (0 or 1) of unit i at
			time t , input for non-UC runs, result for UC runs
.InitialState(i) †	I	empty	$n_g \times 1$ vector of initial states, if positive (negative),
			number of uptime (downtime) periods at time $t =$
			0
$.\texttt{MinUp(i)}^\dagger$	I	empty	$n_g \times 1$ vector, minimum up time in number of
			periods
$.\texttt{MinDown(i)}^\dagger$	I	empty	$n_g \times 1$ vector, minimum down time in number of
			periods
z1	I	empty	initial state z^1 of optional dynamic system

 $^{^*}$ I = input, O = output, B = both, opt = taken from Matpower options. † Requires that CommitKey be present and non-empty.

Table 5-8: Fields of Offer struct md.offer(t)

name	description
PositiveActiveReservePrice [†]	linear coefficient of $C_{RP+}^{ti}(\cdot)$ in (4.6)
${\tt PositiveActiveReserveQuantity}^{\dagger}$	max upward reserve quantity $R_{P_{\text{max}+}}^{ti}$ in (4.19)
$ exttt{NegativeActiveReservePrice}^\dagger$	linear coefficient of $C_{RP-}^{ti}(\cdot)$ in (4.6)
$ exttt{NegativeActiveReserveQuantity}^\dagger$	max downward reserve quantity $R_{P_{\text{max}-}}^{ti}$ in (4.20)
Positive $ t Active Delta Price^\dagger$	linear coefficient of $C_{P+}^{ti}(\cdot)$ in (4.6)
$ exttt{NegativeActiveDeltaPrice}^\dagger$	linear coefficient of $C_{P_{-}}^{ti}(\cdot)$ in (4.6)
${\tt PositiveLoadFollowReservePrice}^{\dagger}$	linear coefficient of $C_{\delta+}^{ti}(\cdot)$ in (4.6)
${\tt PositiveLoadFollowReserveQuantity}^{\dagger}$	max upward ramp reserve $\delta_{\text{max}+}^{ti}$ in (4.23)
$ exttt{NegativeLoadFollowReservePrice}^\dagger$	linear coefficient of $C_{\delta}^{ti}(\cdot)$ in (4.6)
${\tt NegativeLoadFollowReserveQuantity}^{\dagger}$	max downward ramp reserve $\delta_{\text{max}-}^{ti}$ in (4.24)
gencost [‡]	energy offers in the form of generator cost functions

 $^{^{\}dagger}$ $n_g \times 1$ vector of values for each generator at time t. ‡ Deprecated. Use profiles instead.

Table 5-9: Input Fields of md.Storage

name	type*	default	description [†]
UnitIdx(i)	I		corresponding gen matrix row index
<pre>ExpectedTerminalStorageAim(i)</pre>	Ī		target value for expected final stored en-
1 0			ergy at end of last period for storage
			unit i , overrides any values provided for
			both ExpectedTerminalStorageMin and
			ExpectedTerminalStorageMax
<pre>ExpectedTerminalStorageMax(i)</pre>	Ι		upper bound $S_{\min}^{n_t i}$ on expected final stored
			energy in (4.36)
<pre>ExpectedTerminalStorageMin(i)</pre>	I		lower bound $S_{\max}^{n_t i}$ on expected final stored
-			energy in (4.36)
<pre>InitialStorage(i)</pre>	В		initial (expected) stored energy s_0 in MWh
<pre>InitialStorageCost(i)</pre>	I		cost C_{s0} associated with starting with
			amount s_0 at time $t = 0$
${\tt InitialStorageLowerBound(i)}$	I		lower bound S_{\min}^{0i} on inital (expected)
			stored energy s_0 in (4.38)
${\tt InitialStorageUpperBound(i)}$	Ι		upper bound S_{max}^{0i} on inital (expected)
			stored energy s_0 in (4.38)
InEff(i,t) [‡]	Ι	1	input efficiency η_{in}^{ti}
OutEff(i,t) [‡]	Ι	1	output efficiency η_{out}^{ti}
LossFactor(i,t) [‡]	Ι	0	fraction of stored energy lost per hour η_{loss}^{ti}
$ ext{MaxStorageLevel(i,t)}^{\ddagger}$	Ι		stored energy maximum limit S_{max}^{ti}
${\tt MinStorageLevel(i,t)^{\ddagger}}$	Ι		stored energy minimum limit S_{\min}^{ti}
rho(i,t)	Ι		$ \rho^{ti} $ parameter controlling weighting of
			worst case $(\rho^{ti} = 1)$ and expected values
			$(\rho^{ti} = 0)$ for defining storage constraints
	-		in (4.32)–(4.35)
TerminalStoragePrice(i)	Ι		prices C_s for contributions to terminal
			storage from charging/discharging in non-
m : 101 : D : 0(1)	т	~ 8	terminal states
TerminalChargingPriceO(i)	Ι	C_s §	prices $C_{\rm sc0}$ for charging in terminal end-
m : 101 : D : 1/(·)	т	C 8	of-horizon base states
TerminalChargingPriceK(i)	Ι	C_s §	prices $C_{\text{sc}k}$ for charging in terminal con-
TorminolDiachongingDri0(i)	I	C_s §	tingency states
TerminalDischargingPriceO(i)	1	\cup_s °	prices $C_{\rm sd0}$ for discharging in terminal end-of-horizon base states
TorminalDischargingDriceV(;)	I	C_s §	
TerminalDischargingPriceK(i)	1	\cup_s	prices $C_{\text{sd}k}$ for discharging in terminal
			contingency states

^{*} I = input, O = output, B = both, opt = taken from Matpower options.
† All fields have n_s rows, where row i refers to storage unit i. See also Table 5-2.
‡ Automatically expanded from scalar, $n_s \times 1$ or $1 \times n_t$ vector to a full $n_s \times n_t$ matrix.
§ That is, the default is taken from TerminalStoragePrice.

5.3.2 Output Data

Additional fields are initialized or added to the MOST Data struct by most and returned in the updated output struct. Some simply record the values of corresponding options found in the MATPOWER options struct passed in, while others contain computed results. The output fields added or updated by most are summarized in Tables 5-10 through 5-13.

Table 5-10: Output Data Fields of md

name	type*	description
alpha	opt	α , copy of most.alpha option
${\tt CostWeights(k,j,t)^{\dagger}}$	О	ψ^{tjk} , probability of contingency k in scenario j at time t
CostWeightsAdj(k,j,t) [†]	O	ψ_{α}^{tjk} , same as ψ^{tjk} , but adjusted for α as in (4.1)
DCMODEL	opt	copy of most.dc_model option
<pre>flow(t,j,k) .mpc</pre>	O	case data for period t , scenario j , contingency k MATPOWER case struct, ‡ prices and gen costs are probability-weighted
.PLsh		vector needed to compute branch flow results
idx	В	dimensions of variables and constraints, see Table 5-11
QCoordination	opt	copy of most.q_coordination option
QP	B^\P	quadratic program problem setup and results, see Table 5-12
results	O	results, see Table 5-13
SecurityConstrained	opt	copy of most.security_constraints option
StepProb(t)	O	γ^t , probability of making it to period t
Storage	В	γ^t , probability of making it to period t
$. {\tt ExpectedStorageDispatch(i,t)}$	O	$n_s \times n_t$, expected dispatch of storage unit i
$. {\tt ExpectedStorageState(i,t)}$	О	$n_s \times n_t$, expected stored energy in storage unit i at end period t
$. { t Force Cyclic Storage}$	opt	copy of most.storage.cyclic option
$. {\tt ForceExpectedTerminalStorage}$	opt	copy of most.storage.terminal_target option
$. ext{InitialStorage(i)}$	В	$n_s \times 1$, initial (expected) stored energy s_0 in MWh, computed as output when most.storage.cyclic option is on
tstep(t)	В	$n_t \times 1$ struct of parameters related to period t
. E [§]	Ο	E^t , used to compute expected injections in period t
.G [§]	O	G^t
. H^\S	O	H^t
.Li [§]	O	L_I^t
.Lf§	O	$L_F^{\stackrel{t}{t}}$
$.{ m Mg}^{\S}$	O	M_q^t
. M \mathbf{h}^\S	O	M_b^g
$.\mathrm{Ng}^\S$	O	N_g^{T}
. Nh [§]	O	$N_h^{ ilde{t}}$
<pre>UC.CommitSched(i,t)</pre>	В	$n_g \times n_t$ matrix UC status (0 or 1) of unit <i>i</i> at time <i>t</i> , input for non-UC runs, result for UC runs

^{*} I = input, O = output, B = both, opt = taken from Matpower options.

† Note index order - (:,:,t) refers to period t.

‡ See Appendix B in the Matpower User's Manual for details.

The QP field is either contructed by most or taken as an input, based on the value of the most.build_model option described in Table 5-4.

[§] Used to compute expected inital and final storage amounts for period t. See (4.82)–(4.89) for details.

Table 5-11: Fields of Index struct md.idx

name	type*	description
nt	I	number of periods in scheduling horizon
nj(t)	O	number of base scenarios for period t , computed from length of
		<pre>tstep(t).OpCondSched(j)</pre>
nc(t,j)	O	number of contingencies in period t , scenario j
nb(t,j,k)	O	number of buses in period t , scenario j , contingency k
${\tt nb_total}$	O	total number of buses summed over all flows
ng	O	number of gens in mpc.gen
ny(t,j,k)	O	number of gens with piecewise linear costs in period t , scenario j ,
		contingency k
$nf_{-}total$	O	total number of flows (periods $t \times \text{scenarios } j \times \text{contingencies } k$)
ns	O	number of storage units
${\tt ns_total}$	O	$ ext{ns} imes ext{nf_total}$
ntramp	O	number of periods of load-following reserves, always equal to nt - 1
		since OpenEnded has been deprecated
nyt	O	n_t^{ds} , number of time periods in the horizon of the dynamic system
		model
nzd	O	size of state vector for dynamical system (4.49) - (4.50)
nyo	O	number of outputs of dynamical system (4.51) - (4.52)
nvars	O	total number of variables

^{*} I = input, O = output, B = both, opt = taken from Matpower options. † Used to compute expected inital and final storage amounts for period t. See (4.82)–(4.89) for details.

Table 5-12: Fields of QP struct md.QP

name	type*	description
A §	В	linear constraint matrix
1§	В	linear constraint lower bound
\mathbf{u}^\S	В	linear constraint upper bound
\mathbf{x}^{\S}	O	full optimization variable x
f§	O	value of objective function at solution (same as md.results.f)
\mathtt{vtype}^\S	В	string containing variable types
x0 [§]	В	variable initial value
\mathtt{xmin}^\S	В	variable lower bound
${\tt xmax}^{\S}$	В	variable upper bound
Н§	В	quadratic cost coefficient matrix^{\dagger}
C_{\S}	В	linear cost coefficient vector [†]
С	В	constant cost term [†]
H1	В	quadratic cost coefficient matrix [‡]
C1	В	linear cost coefficient vector [‡]
c1	В	constant cost term [‡]
Cfstor	В	linear cost coefficients of full x to reflect expected value of storage in
		terminal states
\mathtt{opt}^\S	В	options struct for qps_matpower or miqps_matpower, set by MOST
c		run options and solver-specific Matpower options via mpopt2qpopt
$\mathtt{exitflag}^\S$	О	1 = converged successfully, 0 or negative value = solver specific failure
e		code
\mathtt{output}^{\S}	О	struct with solver-specific fields and alg field specifying solver that was used
\mathtt{lambda}^\S	O	Lagrange and Kuhn-Tucker multipliers on constraints
.mu 1§	0	lower (left-hand) limit on linear constraints
.mu_u§	0	upper (right-hand) limit on linear constraints
.lower§	Ö	lower bound on optimization variables
.upper§	Ö	upper bound on optimization variables
· upper		appor bound on optimization variables

 $^{^*}$ I = input, O = output, B = both, opt = taken from Matpower options. The QP struct and its fields are either contructed by most or taken as an input, based on the value of the most.build_model option described in Table 5-4.

[†] Including user defined coordination costs from md.CoordCost. ‡ Excluding user defined coordination costs from md.CoordCost.

 $[\]S$ See input and output arguments for qps_matpower or miqps_matpower for details.

Table 5-13: Fields of Results struct md.results

name	type*	description
f	О	value of objective function $f(x)$ in (4.6) at solution (same as md.QP.f)
Pc(i,t)	O	$n_q \times n_t$, active power contract quantity, p_c^{ti}
<pre>Rpp(i,t)</pre>	O	$n_q \times n_t$, upward active contingency reserve quantity r_+^{ti}
Rpm(i,t)	O	$n_q \times n_t$, downward active contingency reserve quantity r^{ti}
Rrp(i,t)	O	$n_q \times n_t$, upward load-following ramping reserve quantity δ_+^{ti}
Rrm(i,t)	O	$n_q \times n_t$, downward load-following ramping reserve quantity δ^{ti}
Sp	O	$n_s \times n_t$, endogenously computed upper stored energy bounds s_+^{ti}
Sm	O	$n_s \times n_t$, endogenously computed lower stored energy bounds s^{ti}
<pre>GenPrices(i,t)</pre>	O	$n_q \times n_t$, expected energy price
<pre>CondGenPrices(i,t)</pre>	O	$n_q \times n_t$, expected energy price, conditional on making it to time t
<pre>RppPrices(i,t)</pre>	O	$n_q \times n_t$, price on upward active contingency reserve
<pre>RpmPrices(i,t)</pre>	O	$n_q \times n_t$, price on downward active contingency reserve
<pre>RrpPrices(i,t)</pre>	O	$n_q \times n_t$, price on upward load-following ramping reserve
<pre>RrmPrices(i,t)</pre>	O	$n_q \times n_t$, price on downward load-following ramping reserve
<pre>ExpectedRampCost(i,t)</pre>	O	$n_q \times n_t$, expected ramping cost (wear and tear)
<pre>ExpectedDispatch(i,t)</pre>	O	$n_q \times n_t$, expected generator dispatch
Z	O	$n_z \times n_t^{\text{ds}}$, dynamic system model state z
Y	O	$n_y \times n_t^{\text{ds}}$, dynamic system model output
SetupTime	O	time to construct model in seconds
SolveTime	O	time to solve model in seconds

^{*} I = input, O = output, B = both, opt = taken from Matpower options.

5.4 Additional Considerations

The current version of MOST has a number of modeling limitations relative to MAT-POWER. The following is a list of MATPOWER features that are not yet supported by MOST:

- branch angle difference limits
- branch flow soft limits
- DC transmission lines
- full non-linear AC network modeling
- interface flow limits

6 Additional Functions

6.1 addgen2mpc

```
[new_mpc, idx] = addgen2mpc(mpc, gen, gencost, gen_type)
```

Appends a set of generators to those contained in an existing MATPOWER case struct. The existing case in mpc is a standard MATPOWER case with additional fields, genfuel containing a cell array of string-valued fuel types (one for each generator), and i<type> containing (for each fuel type) a vector of indices of the generators of type <type>. The gen and gencost inputs are the standard MATPOWER generator and generator cost matrices and gen_type is a string or cell array of strings of fuel types for the generators to be appended.

It returns the updated case struct in new_mpc, with the new generators appended to the gen, gencost and genfuel fields and updated i<type> fields, along with a vector idx of indices of the newly added generators.

While there are no canonical definitions for generator types, Table 6-1 contains some strings that have been used by convention, where 'ess' and 'wind' are used explicitly by some functions in MOST.

Table 6-1: Typical Generator Types

type string	description
'biomass'	biomass
'coal'	coal
'dl'	dispatchable load
'ess'	energy storage system
'hydro'	hydro
'ng'	natural gas, combustion turbine
'ngcc'	natural gas, combined cycle
'nuclear'	nuclear
'oil'	oil
'refuse'	refuse
'solar'	solar PV
'syncgen'	synchronous condensor
'wind'	wind
'na'	none
'unknown'	unknown

6.2 addstorage

```
[idx, new_mpc] = addstorage(storage, mpc)
[idx, new_mpc, new_xgd, new_sd] = addstorage(storage, mpc)
[idx, new_mpc, new_xgd, new_sd] = addstorage(storage, mpc, xgd)
[idx, new_mpc, new_xgd, new_sd] = addstorage(storage, mpc, xgd, sd)
```

Given a StorageUnitData struct (storage), or the name of a function or MAT-file containing such a struct, this function adds the specified storage units, modeled as additional special generators, to the existing gen and gencost matrices of the MATPOWER case (mpc) and to the existing xGen and StorageData structs, providing a convenient way to specify in one place all of the parameters for a set of storage units.

The parameters for the storage units to be added are specified in a StorageUnitData struct, which is a single struct with the four fields described in Table 6-2. Return values include a vector idx of generator indices for the newly added storage units, along with updated versions of the mpc, xgd and sd structs specified by the inputs..

Table 6-2: Fields of StorageUnitData struct (storage)

name	default	description
gen gencost xgd_table sd_table	none zero cost none none	rows to be appended to the gen matrix* in mpc rows to be appended to the gencost matrix* in mpc xGenDataTable struct† corresponding to units to be added StorageDataTable struct‡ corresponding to units to be added

^{*} See Tables B-2 and B-4 in Appendix B of the MATPOWER User's Manual for details on the format.

6.3 addwind

```
[idx, new_mpc] = addwind(wind, mpc)
[idx, new_mpc, new_xgd] = addwind(wind, mpc)
[idx, new_mpc, new_xgd] = addwind(wind, mpc, xgd)
```

Given a WindUnitData struct (wind), or the name of a function or MAT-file containing such a struct, this function adds the specified wind generators to the existing gen and gencost matrices of the MATPOWER case (mpc) and to the existing xGen struct, providing a convenient way to specify in one place all of the parameters for a set of wind generators.

[†] See loadxgendata in Section 6.11 and Table 6-6 for details of the xGenDataTable struct.

[‡] See loadstoragedata in Section 6.10 and Table 6-5 for details of the StorageDataTable struct.

The parameters for the wind generators to be added are specified in a WindUnitData struct, which is a single struct with the four fields described in Table 6-3. Return values include a vector idx of generator indices for the newly added wind generators, along with updated versions of the mpc and xgd structs specified by the inputs.

Table 6-3: Fields of WindUnitData struct (wind)

name	default	description
gen gencost xgd_table	$none \\ zero\ cost \\ none$	rows to be appended to the gen matrix* in mpc rows to be appended to the gencost matrix* in mpc xGenDataTable struct† corresponding to units to be added

^{*} See Tables B-2 and B-4 in Appendix B of the MATPOWER User's Manual for details on the format.

6.4 apply_profile

```
chgtabs = apply_profile( profile, chgtabsi )
xgd = apply_profile( profile, xgdi, dim )
sd = apply_profile( profile, sdi, dim )
```

The apply_profile function applies a single profile of a given type to the provided input. See Section 5.1.6 and Table 5-3 for details on the profile struct.

For profiles of type 'mpcData', the output is an $n_t \times n_j^{\text{max}}$ cell array of change tables in the format expected by MATPOWER's apply_changes function.²² The second input is also $n_t \times n_j^{\text{max}}$ cell array. Each element can be either empty or contain a change table to which the new changes are appended.

For profiles of type 'xGenData' the second argument is the xGenData struct to be modified (xgdi) and the output xgd is a modified version of the same struct. The the third argument dim is a positive integer indicating the number of elements corresponding to the third dimension of profile.values. This allows this dimension to be expanded to the appropriate size if it is specified as a singleton dimension in profile.values.

Profiles of type 'StorageData' are completely analogous, taking a StorageData struct (sdi) as the second input and returning a modified version of it in sd.

6.5 filter_ramp_transitions

```
md = filter_ramp_transitions(md0, threshold)
```

[†] See loadxgendata in Section 6.11 and Table 6-6 for details of the xGenDataTable struct.

²²See Section 9.3.5 in the MATPOWER User's Manual.

The filter_ramp_transitions function creates a binary valued transition mask $\zeta^{tj_2j_1}$ for ramping reserves based on a given probability threshold. Only transitions with probabilities greater than or equal to a given threshold value are included, where the probability of the transition from state j_1 to j_2 is taken to be the conditional probability Φ^t from (4.54), specified in the transmat argument to loadmd, multiplied by the conditional probability of being in state j_1 , given that you've made it to period t.

6.6 getprofiles

```
profiles = getprofiles(profilesi);
profiles = getprofiles(profilesi, profiles0);
profiles = getprofiles(profilesi, idx);
profiles = getprofiles(profilesi, profiles0, idx);
```

Loads a profile or set of profiles from a struct, MAT-file or M-file (profilei), optionally using the *n*-dimensional index vector idx to modify any non-zero values in the rows fields so that the corresponding rows field in the returned profiles is equal to idx(rows). This makes it easy to use profiles defined for a particular set of generators, such as those added to a case as a group by addwind or addstorage.

The optional profiles0 argument allows the user to provide an existing profile struct to which the new profiles are appended.

6.7 idx_profile

```
[PR_REP, PR_REL, PR_ADD, PR_TCONT, PR_TYPES, PR_TMPCD,...
PR_TXGD, PR_TCTD, PR_TSTGD, PR_CHGTYPES] = idx_profile;
```

This function defines constants that are useful in defining profiles.

6.8 loadgenericdata

```
var = loadgenericdata(varfile, vartype)
var = loadgenericdata(varfile, vartype, fields)
var = loadgenericdata(varfile, vartype, fields, varname)
var = loadgenericdata(varfile, vartype, fields, varname, args)
```

The loadgenericdata function loads data from a variable, M-file or MAT-file and checks that it matches a specified type. The first argument, varfile, is a variable

value description name PR_REP 1 replace old values with new ones 2 multiply old values by scale factors PR_REL 3 add shift factor to old values PR_ADD PR_TCONT* 1 PR_TYPES listlist of profile types PR_TMPCD vector of valid table types for 'mpcData' listlist of valid table types for 'xGenData' $PR_{-}TXGD$ listlist of valid table types for 'ContingencyData' PR_TCTD* listPR_TSTGD list of valid table types for 'StorageData' listlist of valid change types PR_CHGTYPES list

Table 6-4: Constants Defined by idx_profile

containing the data structure or a string containing the name of a function M-file or a MAT-file on the Matlab path. If no file extension is provided, it will attempt to load a MAT-file with the specified name and, if not found, will call a function by that name to get the data. The function M-file should return a single argument containing the data. A MAT-file should either contain a single variable with the desired data or provide the variable name in varname.

The second argument, vartype, is a string or cell array of strings with, in order of priority, the data structure type to be returned. Valid values are 'struct', 'cell' and 'array'.

The third argument, fields, is optional and contains a string or cell array of strings containing a list of required fields in case the vartype is 'struct'. If a required field is missing it will throw an error.

The varname and args arguments are also optional. varname is a string containing the name of the variable to extract when loading a MAT-file. If not provided, the default is to extract the first variable, regardless of name. And args is a scalar or cell array of values that are passed as input arguments to the function, in the case where varfile is a function name.

6.9 loadmd

```
md = loadmd(mpc, transmat, xgd, sd, contab, profiles)
```

The loadmd function provides the canonical way of loading a MOST Data struct. For details please see Sections 5.1.1–5.1.6.

^{*} Related to functionality not yet implemented.

6.10 loadstoragedata

```
sd = loadstoragedata(sd_table)
sd = loadstoragedata(sd_table, gen)
sd = loadstoragedata(sd_table, mpc)
```

The loadstoragedata function provides the canonical way of loading additional parameters for storage resources into a StorageData struct, described in Section 5.1.4 and summarized in Table 5-2. It takes a StorageDataTable struct as input, either directly or as the name of a function or MAT-file that returns such a struct. If the optional second argument is provided, either a MATPOWER gen matrix or a MATPOWER case file mpc, the number of storage units is checked for consistency.

The StorageDataTable struct is used as a convenient way to define the StorageData struct using a table format for the data and is summarized in Table 6-5. It has two mandatory fields, colnames and data. The data field is a $n_s \times N$ matrix, where n_s is the number of storage units and N is the number of fields in the StorageData being defined. The colnames field is an N dimensional cell array of strings with field names corresponding to the columns in data. The number of columns in the table and their order are determined by the user, depending on the fields for which they want to specify non-default values.

Table 6-5: Fields of StorageDataTable struct (sd_table)

name	default	description
colnames	none	N element cell array of StorageData field names * corresponding
		to the columns of the data field †
data	none	$n_s \times N$ matrix of storage parameters [†]
${ t MinStorageLevel}^{\ddagger}$	none	stored energy minimum limit S_{\min}^{ti}
MaxStorageLevel [‡]	none	stored energy maximum limit S_{\max}^{ti}
OutEff [‡]	1	output efficiency η_{out}^{ti}
${\tt InEff^\ddagger}$	1	input efficiency $\eta_{\rm in}^{ti}$
${ t LossFactor}^{\ddagger}$	0	fraction of stored energy lost per hour η_{loss}^{ti}
$ exttt{rho}^{\ddagger}$	1	ρ^{ti} parameter controlling weighting of worst case ($\rho^{ti} = 1$) and
		expected values ($\rho^{ti} = 0$) for defining storage constraints in
		(4.32)-(4.35)

^{*} See Table 5-2 for a list of valid field names.

There are six additional optional scalar fields that can be used instead of the data table if a single value is to be assigned uniformly to all of the storage units. An example StorageDataTable struct is created by the following code.

[†] n_s is the number of storage units and N is the number of fields in the StorageData being defined by the given StorageDataTable.

 $[\]ddagger$ Values in these scalar fields are overridden by any corresponding values in the data table.

```
= 0.9;
storage.sd_table.OutEff
storage.sd_table.InEff
                            = 0.9;
storage.sd_table.LossFactor = 0.02;
storage.sd_table.rho
                            = 0;
storage.sd_table.colnames = { % indented to align with data cols
    'InitialStorage', ...
        'InitialStorageLowerBound', ...
            'InitialStorageUpperBound', ...
                'InitialStorageCost', ...
                    'TerminalStoragePrice', ...
                        'MinStorageLevel', ...
                            'MaxStorageLevel', ...
};
storage.sd_table.data = [
            80 45 43 0
    40 0
                            40;
    30 0
            60 47 45 0
                            30;
            100 46 44 0
                            50;
];
```

See also the addstorage function in Section 6.2 for a potentially more convenient way to specify all of the parameters for your storage resources in a single file or struct.

6.11 loadxgendata

```
xgd = loadxgendata(xgd_table)
xgd = loadxgendata(xgd_table, gen)
xgd = loadxgendata(xgd_table, mpc)
```

The loadxgendata function provides the canonical way of loading extra generator data into an xGenData struct described in Section 5.1.3 and summarized Table 5-1. It takes an xGenDataTable struct as input, either directly or as the name of a function or MAT-file that returns such a struct. If the optional second argument is provided, either a MATPOWER gen matrix or a MATPOWER case file mpc, the generator status and limits are used to set certain default values as indicated in Table 5-1.

The xGenDataTable struct is used as a convenient way to define the xGenData struct using a table format for the data and is summarized in Table 6-6. It has two fields, colnames and data. The data field is a $n_g \times N$ matrix, where n_g is the number of generators and N is the number of fields in the xGenData being defined. Those that are not defined in the xGenDataTable struct are assigned default values

by loadxgendata. The colnames field is an N dimensional cell array of strings with field names corresponding to the columns in data. The number of columns in the table and their order are determined by the user, depending on the fields for which they want to specify non-default values.

Table 6-6: Fields of xGenDataTable struct (xgd_table)

name	default	description
colnames	none	N element cell array of xGenData field names *corresponding to the columns of the data field †
data	none	$n_g \times N$ matrix of extra generator parameters [†]

^{*} See Table 5-1 for a list of valid field names.

An example xGenDataTable struct is created by the following code.

6.12 mostver

```
mostver
vnum = mostver
v = mostver('all')
```

Called with no output arguments, mostver prints the version number and release date of the current MOST installation. Otherwise, if called with no input arguments, it returns the current version as a string and with any true input argument, such as the string 'all', it returns a struct with the fields Name, Version, Release and Date (all strings).

 $^{^{\}dagger}$ n_g is the number of generators and N is the number of fields in the xGenData being defined by the given xGenDataTable.

7 Tutorial Examples

7.1 Single Period Problems

7.1.1 Deterministic Economic Dispatch

With and without fixed zonal reserves. With and without commitment.

7.1.2 Deterministic DC OPF

With and without fixed zonal reserves. With and without commitment.

7.1.3 Secure DC OPF

With and without commitment.

7.1.4 Secure Stochastic DC OPF

With and without commitment.

7.2 Multiperiod Problems

7.2.1 Deterministic Multiperiod OPF

With ramp constraints.

7.2.2 Deterministic Unit Commitment

With and without DC network constraints. Startup/shutdown costs, min up/down time constraints, ramp constraints, ramp reserve cost, storage.

7.2.3 Secure Stochastic Unit Commitment

With DC network constraints, startup/shutdown costs, min up/down time constraints, ramp constraints, ramp reserve cost, storage.

8 Acknowledgments

This work was supported in part by the Consortium for Electric Reliability Technology Solutions (CERTS) and the Office of Electricity Delivery and Energy Reliability, Transmission Reliability Program of the U.S. Department of Energy under the National Energy Technology Laboratory Cooperative Agreement No. DE-FC26-09NT43321.

The authors would like to thank the following people, in no particular order, for their various contributions to MOST and the SuperOPF project upon which it is based: Robert J. Thomas, Timothy D. Mount, C. Lindsay Anderson, Alberto Lamadrid, Daniel Muñoz-Álvarez, James S. Thorp, William D. Schulze, Jie Chen, Hongye Wang, Wooyoung Jeon and Surin Maneevitjit.

Appendix A MOST Files and Functions

This appendix lists all of the files and functions that MOST provides. In most cases, the function is found in a MATLAB M-file of the same name in the top-level of the MOST distribution²³, where the .m extension is omitted from this listing. For more information on each, at the MATLAB prompt, simply type help followed by the name of the function. For documentation and data files, the filename extensions are included.

A.1 MOST Functions and Documentation

Table A-1: MOST Functions and Documentation

name	description	
docs/		
CHANGES	MOST change history	
${\tt MOST-manual.pdf}^*$	MOST User's Manual	
addgen2mpc	appends generators to existing case, see Section 6.1	
addstorage	appends storage units to existing case, see Section 6.2	
addwind	appends wind generators to existing case, see Section 6.3	
${ t apply_profile}$	applies a single profile to the specified data, see Section 6.4	
filter_ramp_transitions	creates binary valued transition mask $\zeta^{tj_2j_1}$ for ramping reserves based on a probability threshold, see Section 6.5	
getprofiles	loads profiles from a struct or file, see Section 6.6	
idx_profile	defines constants for use with profiles, see Section 6.7	
loadgenericdata	loads data from a variable, M-file or MAT-file and checks	
	that it matches a specified type, see Section 6.8	
loadmd	loads a MOST Data struct, see Section 6.9	
loadstoragedata	loads parameters for storage units, see Section 6.10	
loadxgendata	loads extra generator data, see Section 6.11	
md_init	data structure initialization	
most	top-level solver, see Chapter 5	
mostver	prints/returns version info for MOST, see Section 6.12	
${\tt mpoption_info_most}$	option information for MOST	
plot_gen	create plots of generator results	
plot_storage	create plots of storage unit results	
plot_uc_data	plot generator commitment summary from raw data	
plot_uc	plot generator commitment summary from md	

^{*} While the MOST User's Manual is listed here with other documentation, it is actually located in <MATPOWER>/docs, not <MATPOWER>/most/docs.

²³That is, in the <MATPOWER>/most directory.

A.2 Automated Test Suite

Table A-2: MOST Test and Example Data

name	description
t/	
c118swf	118-bus test case, used by t_most_w_ds
eg_case3	sample 3-bus Matpower case
${\tt eg_contab}$	sample contingency table
${\sf eg_load_profile}$	sample load profile
${\sf eg_storage}$	sample StorageUnitData
$eg_transmat$	sample transition probability data
${\sf eg_wind_profile}$	sample wind profile
eg_wind	sample WindUnitData
eg_xgd	$\operatorname{sample} \operatorname{xGenData}$
t_case3_most	3-bus Matpower test case
t_case3a_most	another 3-bus Matpower test case
t_case30_most	30-bus Matpower test case
$t_{most_suc_soln.mat}$	solution data for t_most_suc
$t_{most_uc_soln.mat}$	solution data for t_most_uc
t_most_w_ds_z.mat	solution data for t_most_w_ds

Table A-3: MOST Tests

name	description
t/	
${\tt test_most}$	runs full MOST test suite
$t_most_3b_1_1_0$	3-bus, single period, no contingencies
$t_most_3b_1_1_2$	3-bus, single period, 2 contingencies
t_most_3b_3_1_0	3-bus, 3 periods, no contingencies
$t_most_3b_3_1_2$	3-bus, 3 periods, 2 contingencies
t_most_30b_1_1_0_uc	30-bus, single period, no contingencies, w/unit commitment
t_most_30b_1_1_0	30-bus, single period, no contingencies
$t_most_30b_1_17$	30-bus, single period, 17 contingencies
t_most_30b_3_1_0	30-bus, 3 periods, no contingencies
$t_most_30b_3_1_17$	30-bus, 3 periods, 17 contingencies
$t_{most_fixed_res}$	with fixed zonal reserve requirements
t_most_sp	single period continuous problems
t_most_spuc	single period mixed-integer problems, i.e. w/UC
t_most_suc	multiperiod with stochastic unit commitment
t_most_uc	multiperiod with deterministic unit commitment
$t_most_w_ds$	with dynamic linear system constraints
${\tt uniformwindprofile}$	creates a profile for uniformly distributed wind

Appendix B Release History

The full release history can be found in <MATPOWER>/most/docs/CHANGES.

B.1 Version 1.0b1 – released Mmm DD, 2016

Add release date.

The MOST 1.0b1 User's Manual is available online.²⁴

New Features

• Fill in details ...

Bugs Fixed

• Fill in details ...

²⁴http://www.pserc.cornell.edu/matpower/docs/MOST-manual-1.0b1.pdf

References

- [1] R. D. Zimmerman, C. E. Murillo-Sánchez, and R. J. Thomas, "MATPOWER: Steady-State Operations, Planning and Analysis Tools for Power Systems Research and Education," *Power Systems, IEEE Transactions on*, vol. 26, no. 1, pp. 12–19, Feb. 2011. 1, 1.2
- [2] C. E. Murillo-Sánchez, R. D. Zimmerman, C. L. Anderson, and R. J. Thomas, "Secure Planning and Operations of Systems with Stochastic Sources, Energy Storage and Active Demand," *Smart Grid, IEEE Transactions on*, vol. 4, no. 4, pp. 2220–2229, Dec. 2013, http://dx.doi.org/10.1109/TSG.2013.2281001. 1, 1.2, 3
- [3] R. D. Zimmerman, C. E. Murillo-Sánchez, and R. J. Thomas, "MATPOWER's Extensible Optimal Power Flow Architecture," *Power and Energy Society General Meeting*, 2009 IEEE, pp. 1–7, July 26–30 2009. 1
- [4] R. D. Zimmerman and C. E. Murillo-Sánchez, MATPOWER User's Manual, [Online]. Available: http://www.pserc.cornell.edu/matpower/ 1, 3
- [5] The BSD 3-Clause License. [Online]. Available: http://opensource.org/licenses/BSD-3-Clause. 1.1
- [6] A. J. Lamadrid, S. Maneevitjit, T. D. Mount, C. E. Murillo-Sánchez, R. J. Thomas, R. D. Zimmerman, "A 'SuperOPF' Framework", CERTS Report, December 2008. [Online]. Available: http://certs.lbl.gov/pdf/ superopf-framework.pdf 3
- [7] C. E. Murillo-Sánchez, R. D. Zimmerman, C. L. Anderson, and R. J. Thomas, "A Stochastic, Contingency-Based Security-Constrained Optimal Power Flow for the Procurement of Energy and Distributed Reserve," *Decision Support Systems*, Vol. 56, Dec. 2013, pp. 1-10, http://dx.doi.org/10.1016/j.dss.2013.04.006.3