

# LAB 4-C

## 7-SEGMENT

### OBJECTIVES:

- To interface seven-segment to the AVR simulator.

### MATERIAL:


- Atmel Studio or the assembler of your choice.
- [https://lcgamboa.github.io/js/picsimlab.html?..../picsimlab\\_examples/](https://lcgamboa.github.io/js/picsimlab.html?..../picsimlab_examples/) (Simulator)

### WEB SITES:

- [www.microchip.com](http://www.microchip.com) for Atmel Studio Software

### ACTIVITY 1

- a) Connect a common cathode 7-segment directly to PORTD.



- b) Write the following program in the AVR Studio, build and download to the picsimlab.

```
LDI    R20, 0xFF
OUT   DDRD, R20
LDI    R20, 0b00000111
OUT   PORTD, R20
HERE: RJMP HERE
```

### ACTIVITY 2

Modify the previous program to display 9 on the 7-segment.

## LAB 4-C

### 7-SEGMENT

---

```
.INCLUDE "m328pdef.inc"
.ORG 0x0000
LDI R20, 0xFF
OUT DDRD, R20 ; Set PORTD as Output

LDI R20, 0x6F ; Load hex code for '9' (Binary 01101111)
OUT PORTD, R20 ; Output to 7-segment
```

HERE; RJMP HERE

#### ACTIVITY 3

Use a **look-up table** to write a subroutine that displays the value stored in R21 on the 7-segment.

```
.INCLUDE "m328pdef.inc"
.CSEG
.ORG 0x0000

LDI R16, LOW(RAMEND)
OUT SPL, R16
LDI R16, HIGH(RAMEND)
OUT SPH, R16
```

```
LDI R16, 0xFF
OUT DDRD, R16
; Example: Display '5'
LDI R21, 5
RCALL DISPLAY_DIGIT
```

## LAB 4-C

### 7-SEGMENT

---

HERE: RJMP HERE

LAB 4-C

7-SEGMENT

DISPLAY\_DIGIT:

LDI ZL, LOW(2\*SEG\_TABLE) ; Load Z pointer with table address

LDI ZH, HIGH(2\*SEG\_TABLE)

ADD ZL, R21 ; Add offset (the number to display)

LDI R16, 0

ADC ZH, R16 ; Handle carry for high byte

LPM R16, Z ; Load bit pattern from Flash

OUT PORTD, R16 ; Send to 7-segment

RET

; -----

; Look-up Table (0-9 Common Cathode Codes)

; -----

SEG\_TABLE:

.DB 0x3F, 0x06, 0x5B, 0x4F, 0x66 ; 0, 1, 2, 3, 4


.DB 0x6D, 0x7D, 0x07, 0x7F, 0x6F ; 5, 6, 7, 8, 9

#### ACTIVITY 4


- Connect two 7-segments to the same port of AVR, as shown below.

# LAB 4-C

## 7-SEGMENT



b) Display 23 by scanning on those two 7-segments.



.INCLUDE "m328pdef.inc"

.EQU DIGIT\_1\_PIN = 0 ; PORTB.0 for Left Digit

## LAB 4-C

### 7-SEGMENT

---

```
.EQU DIGIT_2_PIN = 1 ; PORTB.1 for Right Digit
```

```
.ORG 0x0000
```

```
; 1. Configure Ports
```

```
LDI R16, 0xFF
```

```
OUT DDRD, R16 ; PORTD as Output (Segments)
```

```
OUT DDRB, R16 ; PORTB as Output (Control)
```

```
LOOP_SCAN:
```

```
; -----
```

```
; Display '2' on Left Digit (Digit 1)
```

```
; -----
```

```
LAB 4-C
```

```
7-SEGMENT
```

```
LDI R16, 0x5B ; Segment code for '2'
```

```
OUT PORTD, R16
```

```
CBI PORTB, DIGIT_1_PIN ; Enable Digit 1 (Low)
```

```
SBI PORTB, DIGIT_2_PIN ; Disable Digit 2 (High)
```

```
RCALL DELAY_SHORT ; Small delay for visibility
```

```
; -----
```

```
; Display '3' on Right Digit (Digit 2)
```

```
; -----
```

```
LDI R16, 0x4F ; Segment code for '3'
```

```
OUT PORTD, R16
```

```
SBI PORTB, DIGIT_1_PIN ; Disable Digit 1 (High)
```

## LAB 4-C

### 7-SEGMENT

---

```
CBI PORTB, DIGIT_2_PIN ; Enable Digit 2 (Low)
```

```
RCALL DELAY_SHORT ; Small delay
```

```
RJMP LOOP_SCAN ; Repeat
```

```
; -----
```

```
; Short Delay Subroutine
```

```
; -----
```

```
DELAY_SHORT:
```

```
LDI R17, 20 ; Adjust this value for scan speed
```

```
D1: LDI R18, 255
```

```
D2: DEC R18
```

```
BRNE D2
```

```
DEC R17
```

```
BRNE D1
```

```
RET
```