```matlab
%%Frequency Response of Second Order System
s = tf('s');
R1 = (356/(s^2+22*s+356));
figure(1);
bode(R1);
```

Bode Diagram