




- 15 Front Blower Motor (Heater Blower Case)
- 17 Blower Resistor
- 18 No. 2 Four Wheel Drive Control ECU
- 19 Deceleration Sensor
- I11 Cooler Stabilizer Amplifier Assembly
- 112 Cooler Stabilizer Amplifier Assembly
- I13 No. 1 Heater Control Indicator Light Assembly
- 114 Rear Heater Blower Switch
- 115 Heater Blower Switch Assembly
- I16 No. 1 Cooler Thermistor
- I17 DLC3
- 119 Stop Light Switch Assembly
- I20 Diode (Door Courtesy)
- I21 Diode (Interior Light)
- 124 Diode (Transfer L4 Position Switch)
- 126 Wiper Lock Switch (Limit Switch Assembly)
- 128 Turn Signal Flasher Assembly
- I42 Preheating Timer Assembly
- I43 Accelerator Pedal Sensor Assembly
- I45 Diode (Sub Tank Relay)
- 149 Motor Antenna Control Relay
- 150 Clutch Switch Assembly
- I51 Airbag Sensor Assembly
- I54 No. 5 Junction Connector
- I56 No. 7 Junction Connector
- 187 Front Blower Motor (Heater Blower Case)
- 188 Cooler Stabilizer Amplifier Assembly
- 192 Preheating Timer Assembly
- 193 No. 5 Junction Connector
- 194 No. 7 Junction Connector






90980-11118 (Before Aug. 2016 Production 1GR-FE, From Aug. 2016 Production 1GR-FE w/o ABS, Before Aug. 2016 Production 1VD-FTV)



90980-11118 (Before Aug. 2016 Production 1HZ, From Aug. 2016 Production 1HZ w/o ABS)



90980-11665

(From Aug. 2016 Production w/ ABS, From Aug. 2016 Production 1VD-FTV)

