

^{* 1 :4-}Door

^{* 8 :}Except Pick-Up Body Type

^{*10 :1}GR-FE

^{*11 :1}HZ


^{*12 :1}VD-FTV


^{*13 :}Pick-Up Body Type


^{*14 :2-}Door Pick-Up Body Type


^{*15 :4-}Door Pick-Up Body Type,Except Pick-Up Body Type

L31 Door Control ECU with Receiver Assembly











L31 Door Control ECU with Receiver Assembly ACT+ ACT-20 10 ≥ В В **>>** UI3 IS1 (*6) (*9) (7*) (9, (9*) ≥ (1) ≥ ≥ 6 PI2 1 RS1 P3 Front Door Lock Actuator Assembly LH R2 Rear Door Lock Actuator Assembly RH Q2 Rear Door Lock Actuator Assembly LH **Ľ-**∖ ۲-L-B **V**II3 (*5)


- * 1 :4-Door
- * 2 :2-Door
- * 3 :w/ Power Window
- * 4 :w/o Power Window
- * 5 :4-Door Pick-Up Body Type * 6 :4-Door Except Pick-Up Body Type
- * 7 :2-Door Except Pick-Up Body Type
- * 8 :Except Pick-Up Body Type * 9 :Except 2-Door Pick-Up Body Type






90980-12413

90980-12414





90980-12473

90980-10907