54 LAND CRUISER (Cont. next page) Power Source (Diesel) (From Aug. 2016 Production) 1 2 3 4 30A AM1 B-L AI3 AI3 AI7 AI2 (\*13) (\*14) (\*6) (\*7) 50A AM1 NO.2 L-R Al4 Al1 140A ALT (\*1) 100A ALT (\*2) 50A AM1 NO.3 \* 1 :1VD-FTV \*10 :Australia \* 2 :1HZ \*11 :Except Australia R-B 3B**≪** \*12 :1HZ 12V Battery Type \* 3 :1HZ 24V Battery Type \*13 :LHD 1VD-FTV \*14 :RHD 1VD-FTV \* 4 :12V Battery Type w/ One Battery \* 5 :12V Battery Type w/ Two Batteries 80A GLOW1 \* 6 :LHD 1HZ \*15 :Middle East \* 7 :RHD 1HZ \*17 :From Sep. 2022 Production W-R \* 8 :1VD-FTV, 1HZ 12V Battery Type \* 9 :1HZ 12V Battery Type w/ One Battery \*18 :Except Middle East 80A GLOW2 50A ALT MAIN R-B (\*3) (\*3) Al1 Al4 15A EFI MAIN (\*8) (\*8) 10A A/C 15A STOP B-L Al1 W-R (\*3) 15A EFI MAIN2 B-L 15A TRAILER STOP (\*4,\*5) 20A DEFOG 10A HORN FL MAIN 3.0W 7.5A OBD2 30A ABS SOL FL MAIN 15A A/F 30A STOP 7.5A ALT-S Al1 Al1 (\*8) (\*8) 15A TURN&HAZ W(\*3) B(\*3) (\*1 \*11,\*12 \*1 \*18 \*17) 50A AM2 (\*5) L(\*3) L(\*3) L(\*1 \*10) L(\*1 \*10) (\*1 \*15 \*17) (\*1 \*15 \*17) 50A HEAD R AI4 **(** W-L 50A MAIN1 B-R W-B W-L (RHD) Al1 <del>《</del> (\*2) (°5) B-DG W-B 50A ABS MTR (LHD)

DA E ¥c/

FA

54 LAND CRUISER (Cont'd) (Cont. next page)



