: Engine Room R/B Assembly | Front Fender Apron LH

(12V Battery Type Before Aug. 2016 Production)

- * 1:HORN Relay * 2:A/C COMP Relay * 3:A/F Relay (1GR-FE)
- * 4:EFI MAIN Relay (1VD-FTV)

 * 5:EDU2 Relay (1VD-FTV)

 * 5:EDU3 Relay (1VD-FTV)


- * 5:ST Relay

 * 6:C/OPN Relay (1VD-FTV)

 * 7:SUB PMP Relay (1GR-FE)

 MAIN2 Relay (1VD-FTV)

 * 8:GLOW1 Relay



: Engine Room R/B Assembly | Front Fender Apron LH

(12V Battery Type From Aug. 2016 Production)

- * 1:HORN Relay
- * 5:ST Relay

- * 5:ST Relay

 * 8:GLOW1 Relay

 * 9:A/F Relay (1GR-FE, 1VD-FTV)


 * 10:A/C COMP Relay

 * 11:C/OPN Relay (1GR-FE, 1HZ)
 EDU1 Relay (1VD-FTV)

 * 12:SUB PMP Relay (1GR-FE)
 EDU2 Relay (1VD-FTV)

 * 13:EFI MAIN Relay (1GR-FE)
 MAIN Relay (1VD-FTV)

 * 14:MAIN2 Relay (1VD-FTV)




① : Engine Room R/B Assembly

Front Fender Apron LH

(12V Battery Type)

Unit A



① : Engine Room R/B Assembly Front Fender Apron LH

(24V Battery Type)

