41 LAND CRUISER (Cont. next page) *3:LHD 1GR-FE *4:RHD 1GR-FE, 1HZ *5:RHD 1GR-FE * 8 :1GR-FE * 9 :1VD-FTV *10 :1HZ 12V Battery Type * 6 :1HZ * 7 :RHD 1GR-FE,1HZ 24V Battery Type 4WD (Before Aug. 2016 Production) *13 :w/ ABS *14 :w/o ABS 2 3 4 15A ECU IG I70(A) No. 19 Junction Connector I61(C) No. 11 Junction Connector (RHD *10) 17 (A)(LHD) 10 (C)(RHD) B-Y B-Y (*10 *13) (*10 *13) B-Y P-E (*10 *14) (RHD *10) 5 Al6 (LHD) 5 Al2 (RHD) 25 Al3 (*10) 17 Al3 (*7) 48 AI3 --- 7 Al6 (LHD) --- 8 Al2 (RHD) 6 Al6 3 Al2 6 CA2 5 AC8 (4 AC1 ((0.1) (0.1) (0.1) Brake Actuator Assembly<33-3> ф Ф (*10) 1 IC1 (3) W-B W-B

