


- T8 Fuel Pump (Sub)
- T9 Fuel Sender Gage Assembly (Rear)
- T10 Trailer Socket
- T11 Back Buzzer Assembly
- T12 License Plate Light Assembly RH
- T13 License Plate Light Assembly RH
- T14 Rear Combination Light Assembly RH
- T15 License Plate Light Assembly LH
- T16 License Plate Light Assembly LH
- T17 Rear Combination Light Assembly LH
- T18 Rear Fog Light Socket & Wire
- T19 Fuel Sender Gage Assembly (Rear)
- U1 Front Door Courtesy Light Switch Assembly LH
- U2 Rear Door Courtesy Light Switch Assembly LH
- V1 Rear Differential Lock Position Switch
- V2 Differential Lock Shift Actuator
- V3 Rear Speed Sensor (Skid Control Sensor Wire)
- Y5 No. 1 Room Light Assembly
- Y7 Tire Pressure Warning ECU and Receiver
- Y10 Tire Pressure Warning ECU and Receiver
- i1 Outer Rear View Mirror Assembly LH
- j1 Outer Rear View Mirror Assembly RH

Position of Parts in Body (LHD 4-Door Pick-Up)





90980-10395