



TRACK · SYNC · EXECUTE

App Walkthrough & Terminology Guide

A page-by-page tour of every screen, per user role — each part named with what it does — plus the production flow and a glossary, so we share one vocabulary.

What GRYNX is

GRYNX is the factory's production-workflow system. A sales order becomes a **PPC request**; the admin approves it into a **job** (with a printable barcode **job card**); **Purchase** logs the raw material; the job then flows through the department **pipeline** — advanced by **scanning** its card at each station — through **QC** and **FG Stock** (which adds serial numbers) until it is **closed**. Everything stays searchable by job, serial, date and raw-material batch. **Maintenance** runs alongside: anyone can raise a ticket that the crew resolves.

The production flow

```
SALES ORDER
|
v
PPC raises REQUEST --(Admin: Approve / Request-Change / Edit->PPC confirm)--> JOB CREATED + job card printed
|
v
PURCHASE logs raw material (item . vendor . batch)
|
v  each station SCANS the card on arrival -> job advances, previous step marked done
DESIGN -> LASER -> ALLOY/MS PROD -> CNC/VMC -> POWDER -> QC --approve--> FG STOCK
                                     | add serial numbers
                                     v
                                     request closure --Admin approve--> CLOSED

MAINTENANCE (any user raises a ticket -> crew assigned -> resolved & closed) runs in parallel.
Everything searchable by job card / serial / date / raw-material batch.
```

Who sees what

ROLE	EXAMPLE USER	LANDS ON	WHAT THEY DO
SuperUser	admin	View As panel	Test every screen as any role
Admin	AASHISH	Admin Home	Approve PPC requests, view any job's history, manage
PPC	Deepak	PPC Request	Raise production requests for approval
Dept Head / Floor	per department	Station Home	Scan job cards to advance them through the pipeline
QC	qc	QC Inspection	Approve to FG, or send for rework
FG Stock	fg	FG Stock	Assign serials, request closure
Purchase	purchase	Purchase	Log raw material (item · vendor · batch)
Maintenance	maint	Maintenance	Assign + resolve machine/facility tickets

Note: every user signs in with their Login ID + PIN. The **SuperUser** (Administrator) can open any of these screens via **View As** to test them.

EVERYONE

1. Login

First screen. Sign in with your Login ID + 6-digit PIN, or biometrics once enrolled on the device.

GRYNX

TRACK. SYNC. EXECUTE.

D-LYFT

WELCOME

SIGN IN

Enter your login ID & PIN

LOGIN ID

6-DIGIT PIN

ENTER →

NEW HERE? [CREATE AN ACCOUNT](#)

[FORGOT PIN?](#)

GRYNX V0.2.0


● ONLINE

ENCRYPTED · TLS

1. **GRYNX wordmark + tagline** — The app brand — “Track. Sync. Execute.”
2. **D-LYFT logo** — The company the app belongs to.
3. **Login ID** — Your username (case-insensitive). Remembered for next time.
4. **PIN boxes** — Your 6-digit PIN. Each digit masks the moment you type the next.
5. **Enter** — Signs you in and routes you to your home screen by role.
6. **Sign in with biometrics** — Face ID / fingerprint — appears after you enable it on this device.
7. **Theme picker (top-right)** — Accent colour + Day/Night mode (login screen only).

2. Admin Home


The factory admin's control centre. Opens every module; the footer scanner pulls up any job's history.



1. **Top bar** — Logos, your identity (name · role · ID), notification bell (with unread count), lock/sign-out.
2. **Navigation rows** — Create Job, Job Status, Departments, Approvals, Maintenance — each opens that module.
3. **Stats strip** — Total Jobs / In Progress / Completed / Alerts. Tap it for the Admin Overview.
4. **SCAN (bottom-bar hero)** — Scan any job card to open its full history (read-only lookup).
5. **Status (right)** — Live ONLINE/OFFLINE indicator (encrypted connection).

3. Job Status

Every real job, grouped by state. This is the live board, not a mock — it reflects the database.



1. **Stage shortcuts** — Jump straight to PPC Request / QC / FG screens.
2. **Needs Attention** — Jobs that need an admin action (e.g. closure requested).
3. **Active Jobs** — All live jobs with their status badge (Approved / In Production / In QC / In FG Stock).
4. **Completed** — Closed jobs with their closure date.
5. **A job row** — Tap to open that job's full history (next screen).

4. Job History (Job Detail)

The complete story of one job — where it is, who touched it, the raw material it's made from, and its serials.

GRYNX

D-lyft

AASHISH



AT-N-072-100626-007
ALLOY TRUSS · 72 UNITS

In Production

PIPELINE

0 / 7 DEPARTMENTS

1

DESIGN

2

LASER / CUTTING

3

ALLOY PRODUCTION

4

CNC / VMC

5

POWDER COAT

CURRENT DESIGN	PRIORITY NORMAL
START 10 JUN	UPDATED —

■ PRINT JOB CARD

 STATIONS ADVANCE THIS JOB BY SCANNING ITS BARCODE — ADMINS DON'T COMPLETE STEPS.

TIMELINE

● Accepted

DESIGN

10 JUN 12:52 PM

● Created

AT-N-072-100626-007

10 JUN 12:52 PM

GRYNX V0.2.0


 ONLINE

ENCRYPTED · TLS

1. **Header** — Job ID (the printed label) · product · quantity, plus the live status chip.
2. **Pipeline stepper** — The departments the job flows through. Ticked = done, amber = current stage.
3. **Meta cells** — Current department, Priority, Start date, last Update / Close date.
4. **Print Job Card** — Reprint the barcode job card.
5. **Raw Material** — Genealogy — items, vendor and batch logged by Purchase for this job.
6. **Serial Numbers** — The FG serial numbers assigned to the finished units.
7. **Timeline** — Every event (accepted / completed / created ...) with real timestamps.

5. Create Job (hub)

The job entry point. Start a fresh job, or pick up a request PPC already raised.



1. **+ Create a new job** — Build a job from scratch (opens the Create Job form).
2. **PPC Requests list** — Pending requests PPC submitted. Tap one to review it as a job sheet.

6. PPC Request — Review (Job Sheet)

A PPC request opens as a read-only job sheet. Review first; edit only if needed.

GRYNX

D-lyft

AASHISH

8+

←

PPC REQUEST PR-0008

EDIT

ALLOY TRUSS

PENDING REVIEW

MODEL	SIZE	QTY
JTX	3M	24
TOTAL		24

PRODUCT	LINES
Alloy Truss	1
START	TARGET
—	—

✓ APPROVE & CREATE JOB

↩ REQUEST CHANGE

GRYNX V0.2.0

● ONLINE

ENCRYPTED · TLS

1. **Status chip** — Where the request stands (Pending review / Awaiting confirm / Changes requested).
2. **Line table** — Model · Size · Qty for each line, plus the total.
3. **Edit (top)** — Switch to the form to modify — your edit is sent to PPC as a proposal to confirm.
4. **Approve & Create Job** — Turns the request into a live job (and a printable card).
5. **Request Change (RC)** — Sends it back to PPC with a note for them to fix & resubmit.

7. Create Job (form)

The shared form. Admin "Create Job" makes a job directly; PPC "Submit Request" raises a request for approval.

GRYNX

D-lyft

AASHISH

8+

🔔

🔑

←

CREATE JOB

CREATE A NEW PRODUCTION JOB

JOB ID

[PRODUCT] [U/N] [QTY] [DDMMYY] [NO]

AT-N-000-100626-001

PRODUCT

ALLOY TRUSS

▼

MODELS & QUANTITY

EXPAND [+]

MODEL

QUANTITY

NO MODELS YET – SEARCH THE CATALOGUE OR
CREATE A CUSTOM ONE

+ ADD MODEL

TOTAL 0

PRIORITY

🔥

URGENT

≡

NORMAL

PIPELINE

🔗

8 DEPARTMENTS

EDIT >

SCHEDULE

START DATE & TIME

10-06-2026

09:00 AM

TARGET COMPLETION

15-06-2026

06:00 PM

📄


CREATE JOB

🕒 JOB SHEET WITH BARCODE GENERATED ON CREATION.

1. **Job ID** — Auto-generated preview of the job code (product · priority · qty · date).
2. **Product** — The product family (Alloy Truss, MS Truss ...).
3. **Models & Quantity** — Add model types + sizes + quantities (search the catalogue or add custom).
4. **Priority** — Urgent or Normal.
5. **Pipeline** — The ordered departments the job will pass through (editable).
6. **Schedule** — Start date/time and target completion.
7. **Create Job / Submit Request** — Creates the job (admin) or submits the request (PPC).

8. Departments

A heat-map of every department and its current load. Tap a row to drill into that department.




DEPARTMENTS			
MANAGE. TEAMS. ROLES.			
DESIGN	08 00	GOOD	→
PURCHASE	02 01	GOOD	→
LASER / CUTTING	04 01	DELAY	→
MS PRODUCTION	06 00	GOOD	→
ALLOY PRODUCTION	03 00	GOOD	→
CNC / VMC	02 02	ALERT	→
MNTR	05 00	GOOD	→
POWDER COAT	01 00	GOOD	→
QC	03 00	GOOD	→
FG STOCK	07 00	GOOD	→
MAINTENANCE	02 00	GOOD	→

GRYNX V0.2.0 ONLINE ENCRYPTED · TLS

1. **Department row** — Name + live load indicator.
2. **Open** — Drill into a department's queue and team.

9. Maintenance

Raise and track machine/facility issues. Anyone can report; the maintenance crew and admin act on it.



1. **Report an Issue** — Raise a ticket (category, priority, location, description, optional photo).
2. **Ticket list** — Each ticket: location/machine, ticket no, category, assignee, priority.
3. **Stats** — Counts by state (open / assigned / in progress ...).

10. Maintenance Ticket

The full lifecycle of one ticket — assign, work, and close with a remark, with a photo and a thread.

GRYNX

D-lyft

AASHISH





←

MT-0007

HIGH

ELECTRICAL · PANEL A

○

○

○

○

○

OPENASSIGNEDIN PROGRESSCOMPLETED VERIFIED

LOCATION

PANEL A

CATEGORY

ELECTRICAL

REPORTED

RAMESH (LASER)

ASSIGNED

UNASSIGNED

ISSUE

Sparks from breaker



ASSIGN

UPDATE

CLOSE

ACTIVITY

●

 Reported

— Sparks from breaker

GRYNX V0.2.0


● ONLINE

ENCRYPTED · TLS

1. **Status stepper** — open → assigned → in progress → closed.
2. **Issue + photo** — The reported problem and the photo of it.
3. **Assign / Update / Close** — Head assigns a tech; tech logs ETA + parts; head closes with a remark.
4. **Timeline** — Threaded history of the ticket.

11. Notifications


Your alert feed. Tapping a notification opens exactly the thing it's about.



1. **Unread count + Mark all read** — Live unread badge (also on the bell); clear them all.
2. **A notification** — Tap to jump straight to its source — a PPC request, a printable job card, or a maintenance ticket.

12. Admin Scan → History


Reached from the footer SCAN button. The camera opens immediately; scan a job card to view its history.



1. **Viewfinder** — Point at the job-card QR/barcode — it resolves to that job.
2. **Enter code manually** — Type the job code instead (camera stops); tap outside to return to the camera.

13. SuperUser · View As


The testing account. Open any role or department's screen and operate it as that user.



1. **Role views** — Admin Home, Create Job, PPC Request, Maintenance.
2. **Stations / departments** — Open any station/department home (QC, FG, Purchase, each production station).
3. **Footer “VIEW AS ↔”** — The connection pill doubles as a universal escape back to this panel.

14. Purchase

Logs the raw material each job is made from — the start of the traceability chain.



1. **Active jobs** — Jobs needing raw material; the badge shows how many materials are logged.
2. **Log raw material** — Item, type, vendor, batch ref, quantity — recorded against the job.
3. **Genealogy** — Later searchable by batch ("what did we make from batch X?").

15. PPC Request

The same form as Create Job, but it submits a request the admin reviews and approves.

GRYNX

D-lyft

Deepak
(PPC)

8+

PPC REQUEST

RAISE A PRODUCTION PLANNING REQUEST

REPORT

MY REQUESTS →

REQUEST ID [PRODUCT] [U/N] [QTY] [DDMMYY] [NO]
AT-N-000-100626-001

PRODUCT
ALLOY TRUSS

MODELS & QUANTITY EXPAND [+]

MODEL	QUANTITY
NO MODELS YET — SEARCH THE CATALOGUE OR CREATE A CUSTOM ONE	
+ ADD MODEL	
TOTAL 0	

PRIORITY
URGENT NORMAL

PIPELINE
8 DEPARTMENTS EDIT >

SCHEDULE
START DATE & TIME
10-06-2026 09:00 AM
TARGET COMPLETION
15-06-2026 06:00 PM

✓ SUBMIT REQUEST


ADMIN REVIEWS AND APPROVES TO CREATE THE JOB.

GRYNX V0.2.0 ONLINE ENCRYPTED · TLS

1. **Form** — Product, models & quantities, priority, schedule — see Create Job.
2. **Submit Request** — Sends it to the admin (does NOT create a job directly).
3. **My Requests (top)** — Your inbox of raised requests and what they need.

PPC 16. PPC Inbox (My Requests)


Where PPC acts on the admin's response to each request.



1. **CONFIRM** — Admin proposed edits — confirm them to send back for approval.
2. **FIX** — Admin requested a change (RC) — edit and resubmit.
3. **WITH ADMIN** — Submitted and awaiting the admin's decision.

17. Station Home


A production station's screen. See the jobs heading your way and scan them in.



1. **Station name** — Which station you're operating (derived from your role / View As).
2. **At station / Incoming** — Jobs in progress here, and jobs arriving next.
3. **REPORT (header)** — Raise a maintenance issue from where you are.
4. **Scan Job Card (hero)** — The big bottom button — opens the camera to scan a card as it arrives, advancing the job.

18. Scan (advance)


The arrival scan. Scanning a card moves the job to your station and marks the previous step done.



1. **Viewfinder** — Point at the job card as it ARRIVES at your station.
2. **Confirm** — Review the move (completes X → now at Y) and confirm.
3. **Enter code manually** — Type the code if the camera can't read it.

QC 19. QC Inspection

The quality gate. Approve a job to release it to FG, or send it for rework.



1. **Queue** — Jobs currently at QC awaiting inspection.
2. **Approve** — Passes the job → arms FG Stock.
3. **Rework** — Flags a problem and escalates.

20. FG Stock

Finished-goods. Assign serial numbers and request closure once the job is complete.

The screenshot shows a mobile application interface for 'FG STOCK'. At the top, there is a header bar with 'GRYNX' and 'D-Lyft' logos, followed by 'FG Stock' and a notification icon with a red '3'. Below the header, there is a sub-header with a back arrow, 'FG STOCK', and a 'REPORT' button. The main content area displays two job entries, each with a bold ID and a status: 'AT-N-030-080626-003' and 'AT-N-030-080626-004', both showing 'ALLOY TRUSS · 30 UNITS · 0 SERIALS'. At the bottom, there is a status bar with 'GRYNX V0.2.0', an 'ONLINE' indicator, and 'ENCRYPTED · TLS'.

GRYNX D-Lyft FG Stock

← FG STOCK 2 TO RECEIVE / SERIALISE REPORT

AT-N-030-080626-003
ALLOY TRUSS · 30 UNITS · 0 SERIALS

AT-N-030-080626-004
ALLOY TRUSS · 30 UNITS · 0 SERIALS

GRYNX V0.2.0 ONLINE ENCRYPTED · TLS

1. **Queue** — Jobs received at FG.
2. **Add serial numbers** — Type/paste the serials for the finished units.
3. **Request closure** — Asks the admin to approve and close the job.

Glossary — shared terminology

- **Job / Job Card / Job ID** — a production order and its printable barcode card. The Job ID (e.g. AT-N-072-100626-007) is the human label.
- **jobNo** — the opaque internal code also encoded in the barcode (used by the scan engine).
- **PPC Request** — a production-planning request (raised by PPC) that becomes a job when the admin approves it.
- **Pipeline** — the ordered list of departments a job passes through.
- **Step / Station** — one department's stage within the pipeline.
- **Scan (advance)** vs **Scan (lookup)** — a floor scan MOVES the job to that station; an admin scan only OPENS its history.
- **RC (Request Change)** — the admin sends a PPC request back for changes (with a note).
- **Propose / Confirm** — the admin edits a request → it goes to PPC to confirm before approval (round-trip).
- **Closure** — FG's request to mark a job finished; the admin approves it to CLOSE the job.
- **Genealogy / Traceability** — linking a finished job back to its raw-material batch and forward to its serials.
- **View As** — the SuperUser testing mode that opens any role/department screen.