




HVPP JP




USB-HUB





DC5V-DC12V



D0D1 D2 D3 D4 MOSI8535 MISO8535 SCK8535 PPC0(BS2) SWCLK(XTAL1) PPC1(RB) PPC2(OE) PPC3(WR) PPC4(BS1) PPC5(XA0) PPC6(XA1) PPC7(PAGEL) VTG TRST(RESET)

