

# **Understanding Amplifiers**

ROBIN GETZ
ENGINEER
ANALOG DEVICES



#### Communication, but further ...

- ▶ Various forms of communication have evolved over the millennia.
- ▶ The spoken word can be transmitted from one person, and heard or received by another.
- ▶ In modern times town criers hold an annual contest to discover who can shout a comprehensible message over the greatest distance [1]. However, while the world record is for loudest crier is 112.8 decibels, it can only be understood at less than 100 meters.
- ▶ RF can do better!




http://bernews.com/2017/04/town-crier-competition-2017-results/

▶ American Guild Of Town Criers Website, 1997 http://www.americantowncriers.com/



## **RF Amplifiers in Wireless Signal Chains**



## **RF Amplifiers**

- ► The op-amps of the RF World
- ▶ Usually Fixed gain (specified in dB)
- Single-Ended Inputs and Outputs
- $\frac{Z_{in}}{Z_{out}} = 50 \text{ Ohms (with internal or external matching)}$
- Power Supply fed via inductor into RF Output
- ► Key Specs
  - IP3 Distortion (dBm)
  - Noise Figure (dB)
  - Power Consumption




Figure 32. Evaluation Board, 1805 MHz to 2170 MHz



## **RF Amplifiers vs. Op Amps**

- ▶ RF Amps
  - Input and Output Impedance is 50-1000 Ω
  - Fixed Gain (usually)
  - Specify Noise as Noise Figure (dB)
    - usually in a 50Ω system
  - Specify power-handling capability as P1dB
  - Specify Intermodulation Distortion
    - IP2, IP3
  - DC Specs (e.g. offset voltage) are N/A

#### **FUNCTIONAL BLOCK DIAGRAM**





Figure 1.

- ► Op Amps
  - High Input Impedance
  - Very Low Output Impedance
  - Gain set using Feedback
  - Specify Noise in nV/√Hz
  - Specify Voltage Swing (rail-to-rail, etc.)
  - Specify Harmonic Distortion
    - THD
  - Offset Voltage, Bias Current, Offset Current








Impedance Matching and RF Power Transfer


### **Power Transmission**

► What is the Load Impedance for maximum power transfer?





# **Conditions for optimum power transfer**




◆Surprise! It's 50 Ohms ◆Matching Load to Source Resistance facilitates max power transfer





# **RF Amplifier Specifications**

# What are the Critical RF Amplifier Specifications?









# **Distortion**

#### **Distortion**




- ▶ In wireless systems, simple harmonics (i.e. 2nd, 3rd, 4th, etc) generally fall in another band and are eliminated by band filters.
- ➤ Of much greater concern are the harmonics which are produced when two signals intermodulate with one another or when a wideband carrier intermodulates with itself)
- IMD products are produced by all active components (mixers, amps, ADCs, DACs)



- ► Third Order IMD Products (close to carrier, nF<sub>1</sub>+-mF<sub>2</sub>, n+m=3) are most troublesome
  - In Transmitters: IMD causes interference in adjacent channels
  - In Receivers: Blocker inter-mod products can fall on the desired signal and de-sensitize the receiver
- ► Second Order IMD Products (F2-F1, n=m=1) cause problems in Direct Conversion Receivers
  - Example: Two RF tones 20 kHz apart produce a 20 kHz product close to baseband

# Third Order Products (IMD3) – A Closer Look

► Focus on Power of Fundamentals (dBm) and distance to IMD3 products (dBc)







#### The Two Tone IMD Test

1000


MHz






- Regular harmonics at 1998,2000,2997,3000 MHz, etc, fall out of band and can generally be filtered away.
- Third Order Intermodulation Distortion (IMD) Products at
  - $2xF_1-F_2$  (998 MHz)
  - $\bullet$  2xF<sub>2</sub>-F<sub>1</sub> (1001)
- IMD Products fall in band and cannot be filtered.
- ◆ IMD performance is closely related to Adjacent Channel Power Ratio



























# What is happening here?






- ► Theoretical Power Level at which 3<sup>rd</sup> order IMD products become as large as the fundamental.
- ▶IP3 can be input-referred or output-referred
  - OIP3 = IIP3 + Gain
- ▶The IP3 spec allows us to estimate the size of third order IMD3 products at any RF power level.
- ▶ Because IMD products change 3dB for each 1dB change in the fundamentals, distortion can be reduced by reducing fundamental power but this will also reduce signal-to-noise ratio (SNR)
- ▶ Balancing IMD and SNR is one of the toughest challenges facing RF circuit designers.



## **Why IP3 Matters in Receivers**



- ► Multiple IMD Risks from adjacent channels in LNA
- ► Solution: Amplifiers in Receivers must have both Low Noise Figure and High IP3



## **Newer spec : Noise Power Ratio (NPR)**

- ▶ NPR is a dynamic test that is used to assess the performance of receiver components (mixer, ADC, amplifiers, etc) with a fully loaded Gaussian noise source.
- ➤ The noise level is adjusted such that the converter is loaded just below the point of clipping with a Nyquist-limited noise source.
- ► Then a narrow band of noise is removed with a deep notch filter.
- ➤ The noise within the notch is measured using FFT techniques to determine the ratio of noise density in the notch to the noise density without the notch.
- ▶ The results are expressed in decibels.




Figure 16. Typical NPR Response for a 12-Bit Converter



# Gain Block Performance generally rolls off vs. Frequency (use selection tables carefully)

#### **KEY SPECIFICATIONS**

◆ Frequency Range: 50 MHz - 4 GHz

◆ Gain: 15.3 dB

♦ OP1dB: 19 dBm @ 900 MHz

◆OIP3: 43 dBm @ 900 MHz

Noise Figure. 3.7 dB @ 900 MHz


♦ 5 V Current: 83 mA

◆ Package: SOT-89

#### **FEATURES**

- Highest Dynamic Range Gain Blocks
- Matched 50 Ω Input and Output
- Internal Active Bias
- Temperature and Frequency Stable









# **Output Swing and P1dB**




# **Output Compression (P1dB) and Output Saturation**

- ◆Sweep input power to device until output power is 1 dB lower than it should be
- **◆P1dB** is expressed in dBm and can be input or output referred.

(include "-1" because gain is decreased by 1 dB at compression)

◆Psat is a lesser used spec that expresses max Pout






## 1/4 Watt, 1/2 Watt and 1 Watt Amplifiers

- ► Wattage is OP1dB expressed in Watts
  - 1 Watt Amplifier → 30 dBm OP1dB
  - ½ Watt Amplifier → +27 dBm OP1dB
  - ¼ Watt Amplifier → +24 dBm OP1dB
- ► Wattage designation of an RF Amplifier does <u>not</u> refer to power consumption (e.g. V<sub>s</sub> x I<sub>sv</sub>) but higher wattage amplifiers tend to have higher power consumption




# Relationship between IP3 and P1dB




 OIP3 is typically 10 dB higher than OP1dB but many RF Amplifiers incorporate internal distortion compensation....



#### **OP1dB to OIP3 Delta**






- ▶ In a classic transistor amplifier, OIP3 is typically about 10 dB greater than OP1dB.
- ▶ Many RF Amplifiers employ internal harmonic cancellation circuits to improve OIP3
- ▶ OP1dB remains constant so OIP3-OP1dB can be >> 10 dB.
- ► Harmonic Cancellation Algorithm is optimized for a particular power level and tends to degrade at higher frequencies
- ► Many people pick Amplifiers based on OP1dB (in dBm or Watts)
- ▶ Think "back-off from OIP3" not "back-off from P1dB" when selecting operating point



#### Cascaded IP3 and P1dB of RF Signal Chains



- ◆ IP3 becomes more critical as gain and signal level increases (towards end of chain)
- ◆ IP3 at start of signal chain can be critical if large blockers are present
- ◆ All calculations must be performed in linear domain (i.e. IP3 and P1dB in Watts)






ACLR/ACPR/ACP and how it relates to IP3?

# ACP/ACPR/ACLR


- ► ACPR: Adjacent Channel Power Ratio
- ► ACLR: Adjacent Channel Leakage Ratio
- ► ACP: Adjacent Channel Power

- ♦ WCDMA/3G Test Model 1-64
- ◆ Channel BW = 3.84 MHz
- ♦ Channel Spacing = 5 MHz




Date: 9.NOV.2009 18:14:08








Date: 9.NOV.2009 18:36:37






Date: 9.NOV.2009 18:35:59






Date: 9.NOV.2009 18:35:30






Date: 9.NOV.2009 18:35:01






Date: 9.NOV.2009 18:34:31






Date: 9.NOV.2009 18:34:05

38






Date: 9.NOV.2009 18:33:38






Date: 9.NOV.2009 18:16:08






Date: 9.NOV.2009 18:15:16






Date: 9.NOV.2009 18:14:41






Date: 9.NOV.2009 18:14:08






Date: 9.NOV.2009 18:13:38






Date: 9.NOV.2009 18:12:07






Date: 9.NOV.2009 18:11:19






Date: 9.NOV.2009 19:14:23






Date: 9.NOV.2009 18:10:08






Date: 9.NOV.2009 18:12:07






Date: 9.NOV.2009 18:11:19






Date: 9.NOV.2009 19:14:23






Date: 9.NOV.2009 18:10:08





Date: 9.NOV.2009 18:09:34

## **Typical ACP Profiles vs. Pout**





## **Power Consumption**

- ▶ 100 mA Amplifier with 5 V supply will consume 0.5 W
- ► Since signal chain contains multiple amplifiers, power budget rises fast
- ► For RF Amps that can operate at lower supply voltage (e.g. 3.3V), there is a double benefit because supply current also reduces.
- ► People typically trade-off supply current and OIP3 (higher I<sub>SY</sub> is ok if the OIP3 is correspondingly lower)
- ▶ It is very common to describe a device in terms of its OP1dB, expressed in watts (e.g. a ½ Watt device or a 1 Watt device). So a ½ Watt device does not have a power consumption of ½ Watts (but it can deliver ½ Watts when driven into compression



## **ACP and Supply Voltage**




Figure 2. ACPR vs. Output Power, Single Carrier W-CDMA, TM1-64 at 2140 MHz





## Noise

## **Working with Noise Specifications**


$$N_1 = kT$$
 (-173.8 dBm/Hz)

## Output Noise Floor (dBm/Hz) = $N_1$ (dBm/Hz) + Gain(dB) + Noise Figure (dB)

- ► Noise is either specified as
  - Noise Figure (dB)
  - Noise Factor (no units) (Noise Figure = 10 log (Noise Factor)
  - Noise Spectral Density or Noise Floor (dBm/Hz)
  - Noise Spectral Density (nV/√Hz)
- ▶ Noise figure expresses degradation in SNR (not just the increase in noise)
- ▶ Noise spectral density (NSD) in  $nV/\sqrt{Hz}$  is the voltage equivalent of power spectral density (N<sub>0</sub>) in dBm/Hz
- ▶ RF Engineers always think about power (even when they shouldn't!)



# **Cascaded Noise Performance of RF Signal Chains**




- ◆ Noise Figure of first stage dominates overall noise figure
- ◆ Influence of NF of second and third stages is diminished by gain of first stage
- ◆ All calculations must be performed in linear domain (i.e. using Noise Factor instead of Noise Figure)




## ADIsimRF - Signal Chain Simulator

- Cascaded noise, distortion and gain calculations for RF components
- Contains device data for RF components, ADCs and DACs
- Useful tool for calculating cascaded performance and deciding how well devices fit together
- www.analog.com/adisimrf





## **Distortion and Noise Contribute to Output Spectral Quality**



▶Increasing output power improves SNR at the cost of degraded Adjacent Channel Power Ratio



## **Noise and ACPR**




Figure 2. ACPR vs. Output Power, Single Carrier W-CDMA, TM1-64 at 2140 MHz



## **RF Amplifier Specs - Conclusions**

- ▶ IP3 is critical in transmitters because it predicts spectral distortion for a particular output power level
- ▶IP3 is critical in receivers because it predicts blocker immunity at a particular input level.
- ▶OIP3 vs. Output Power is supposed to be constant and it often is not.
- ► (WCDMA) ACP is a useful metric for comparing amplifiers, even in non-WCDMA systems.
- ▶ IP3 and ACP are closely correlated
- ► Noise affects ACP at low power levels
- ►Systems with signals that have high peak-to-average ratio operate massively backed off from OP1dB → IP3/ACP are more important than P1dB
- ▶ Delta between OIP3 an OP1dB is supposed to be constant at 10 dB and it often is not
- ► Everyone trades off IP3/P1dB and Power Consumption
- ▶When a someone asks for a ½ Watt PA, you need to say "let's talk" because their needs may be satisfied by a cheaper ¼ Watt PA with high IP3 with lower power consumption.



## Some examples

### HMC7748

- ▶ 2 GHz to 6 GHz
- ▶ 58 dB typical small signal gain
  - Increasing the volts by 794.32 times
  - Increasing the power (Watts) by 630957.34 times
- ▶ 43 dBm typical saturated output power (19.95W)
- ▶ 48 dBm typical output IP3
- ▶ 6 dB maximum noise figure
- ▶ Operates from 12 V and 28 V supplies
- ▶ Built-in bias sequencing
- ► Enable pin to provide shutdown capability

#### **FUNCTIONAL BLOCK DIAGRAM**





Figure 1.






Table 3. Pin Function Descriptions

Table 5.1 in Function Descriptions					
Pin No.	Mnemonic	Description			
J1	RF IN	RF Input. RF IN has a frequency range of 2 GHz to 6 GHz, and input signals of $-10$ dBm and a maximum of $-8$ dBm.			
J2	RF OUT	RF Output. RF OUT has a frequency range of 2 GHz to 6 GHz.			
J3	28V	28 V, 4 A Supply.			
J4	GND	Ground Connection.			
J5	12V	12 V, 0.7 A Supply.			
J6	EN	Enable. Pull this pin to ground to enable the PA.			


Figure 3. S-Parameters vs. Frequency at 25°C




## Some examples

### ADL5606

- ▶ Operation from 1800 MHz to 2700 MHz
- ► Gain of 24.3 dB at 2140 MHz
- ▶ OIP3 of 45.5 dBm at 2140 MHz
- ▶ P1dB of 30.8 dBm at 2140 MHz
- ▶ Noise figure of 4.7 dB at 2140 MHz
- ► Power supply: 5 V



### **FUNCTIONAL BLOCK DIAGRAM**








Figure 40. 16-Lead Lead Frame Chip Scale Package [LFCSP] 4 mm × 4 mm Body and 0.75 mm Package Height (CP-16-20) Dimensions shown in millimeters




### Make it easier to use: EVAL-CN0417-EBZ




- ▶ Stick it on a PCB with SMA connectors
- ► Add a 2400 2500 SAW Filter








## P1dB (measured)



- ▶ No compression up to:
  - ▶ 0 dBm (input)
  - ► 21.26 dBm (output)
- ► P1dB =
  - ► 5.5 dBm (input)
  - ► 25.76 dBm (output)




### Power?



▶ Power it from USB connector (no bias – T, works with any radio, including the PLUTO-SDR)


dBm	mW	Volts <sub>rms</sub>	Volts <sub>pp</sub>
-10	0.1	70.711 <u>mV</u>	199.970 <u>m\</u>
0	1	223.607 <u>mW</u>	632.360 <u>m</u> . <u>V</u> .
5	3.16	0.398 <u>∨</u>	1.125 📉
10	10	0.707 ⊻	2.000 📈
15	31.6	1.257 🖳	3.556 \
20	100	2.236 🖳	6.324 📉
25	316	3.976 v	11.246 <u>V</u>



- ► The output stage (RFOUT) is connected to Vcc through the inductor L1.
- ► From a DC perspective, inductors become short circuits, and RFOUT is sitting at 5.0V,
- ▶ allowing a 10V<sub>peak-peak</sub> swing from the amplifier.



http://www.analog.com/ad9361 http://www.analog.com/ad9364 http://www.analog.com/ad9363



## Performance Data (meets or exceeds AD9363 specs)

### ► Tx:


EVM (64 QAM, LTE10) of -40dB




AD9362	l without	amp	with an	mp		
output	power	evm	power	evm	Gain	EVM loss
0	-34.4	-36	-17	-36	17.4	0
-5	-39.1	-40.9	-17	-38	22.1	2.9
-10	-43.2	-40.1	-22.6	-37	20.6	3.1
-15	-48.7	-40	-27.5	-37.6	21.2	2.4
-20	-53.5	-39.6	-32.3	-37.9	21.2	1.7
-25	-55.6	-37.9	-37.4	-37.1	18.2	0.8
-30	-63.5	-35.3	-42	-35	21.5	0.3



## **Thermal issues**









## Spectra is a scarce resource, that everyone needs to respect

- ▶ The RF spectrum needs to be shared.
- ▶ Just because you don't want to send a signal, doesn't mean you aren't.
- ▶ Just because you don't want someone else to receive your signal, doesn't mean they will not.
- ▶ This can have large safety, security, or economic impact.



https://en.wikipedia.org/wiki/File:United\_States\_Frequency\_Allocations\_Chart\_2016\_-\_The\_Radio\_Spectrum.pdf



## Regulation? (FCC is local, but most countries have similar organizations)

- ▶ In the US, in the 2.4–2.4835 GHz band, which is described by FCC sections 15.247 and 15.249:
  - The permitted peak transmit power measured at the antenna input of a frequency hopping system with at least 75 hopping frequencies is +30 dBm.
  - For systems with less than 75 but at least 15 hopping frequencies, a peak transmit power of +21 dBm is allowed.
  - For systems that don't hop, 0 dBm is allowed. (spec'ed as 50 mV/m), for those with a ham license.
- ▶ End users assemble intentional radiators
  - End users may need certification
    - If a individual or company wants to bring a product to the US market which includes a wireless transmitter, they must have the transmitter tested in a laboratory that is authorized by the FCC.





- ▶ If you are contacted by the FCC (or anyone else) about a matter of spectrum interference, immediately stop using the device, don't use it again.
- ► Home-built or used transmitters, like all Part 15 transmitters, are not allowed to cause interference to licensed radio communications and must accept any interference that they receive.
- ▶ If the Commission determines that the operator of a transmitter has not attempted to ensure compliance by employing good engineering practices then that operator may be fined up to \$10,000 for each violation and \$75,000 for a repeat or continuing violation.



### Willful interference to communications

https://www.fcc.gov/general/jammer-enforcement

#### ▶ The Communications Act of 1934

- Section 301 requires persons operating or using radio transmitters to be licensed or authorized under the Commission's rules (47 U.S.C. § 301)
- Section 302(b) prohibits the manufacture, importation, marketing, sale or operation of these devices within the United States (47 U.S.C. § 302a(b))
- Section 333 prohibits willful or malicious interference with the radio communications of any station licensed or authorized under the Act or operated by the U.S. Government (47 U.S.C. § 333)
- Section 503 allows the FCC to impose forfeitures for willful or repeated violations of the Communications Act, the Commission's rules, regulations, or related orders, as well as for violations of the terms and conditions of any license, certificate, or other Commission authorization, among other things.
- Sections 510 allows for seizure of unlawful equipment (47 U.S.C. § 510)

#### ▶ The Commission's Rules

- Section 2.803 prohibits the manufacture, importation, marketing, sale or operation of these devices within the United States (47 C.F.R. § 2.803)
- Section 2.807 provides for certain limited exceptions, such as the sale to U.S. government users (47 C.F.R. § 2.807)

### ► The Criminal Code (Enforced by the Department of Justice)

- Title 18, Section 1362 prohibits willful or malicious interference to US government communications; subjects the operator to possible fines, imprisonment, or both (18 U.S.C. § 1362)
- Title 18, Section 1367(a) prohibits intentional or malicious interference to satellite communications; subjects the operator to possible fines, imprisonment, or both (18 U.S.C. § 1367(a))

### ► Check out:

https://www.fcc.gov/enforcement





# Thanks

