REVISION HISTORY					
NUMBER	DATE	DESCRIPTION	NAME		

# **Contents**

1	Prerequisites					
	1.1	JACK Audio Connection Kit	1			
	1.2	liblo - Lightweight OSC Implementation	1			
2	osc	OSC Settings				
3	Messages sent by silentjack					
	3.1	/silentjack/started	2			
	3.2	/silentjack/not_connected	3			
	3.3	/silentjack/connected	3			
	3.4	/silentjack/level	3			
	3.5	/silentjack/silent	4			
	3.6	/silentjack/run_cmd	4			
	3.7	/silentjack/grace	4			
	3.8	/silentjack/settings	5			
	3.9	/silentjack/quit	5			
4	Mes	Messages received by silentjack				
	4.1	/silentjack/get_settings	6			
	4.2	/silentjack/set_trigger_level	6			
	4.3	/silentjack/set_silence_period	6			
	4.4	/silentjack/set_grace_period	7			
	4.5	/silentjack/set_verbose	7			
	4.6	/silentjack/quit	7			
5	Test	it	7			
	5.1	Application Notes	8			

The program **silentjack** can be used to listen to **JACK** ports and detect if the audio signal is below or above a defined level (dB) for a defined time interval. A fork of silentjack was made in order to sense and control the program via the UDP protocol **OSC**. The library **liblo** is used to implement OSC in silentjack.

silentjack OSC is a derivate of "silentjack - Silence / Dead Air Detector" http://www.aelius.com/njh/silentjack/

## 1 Prerequisites

#### 1.1 JACK Audio Connection Kit

http://www.jackaudio.org

### 1.2 liblo - Lightweight OSC Implementation

```
git clone git://liblo.git.sourceforge.net/gitroot/liblo/liblo
```

See example programs oscsend and oscdump

A small modification will make the oscdump tool ready for shell hacks. https://gist.github.com/7890/8d83f887b9dc771dcb00

Many applications are possible without using the OSC features of silentjack simply by using the run command on silence feature.

However with the OSC modification, silentjack becomes even more powerful. Once started, it is a fully controllable network node that does inter-process communication (IPC) via OSC.

It provides a way of reconfiguring running instances of silentjack. As an example, the trigger level or silence period of a running silentjack instance could be configured by a scheduler. This allows to taylor sensing of a source to specific needs based on time (i.e. on a per-radio-show basis).

```
$ silentjack -h
silentjack version 0.3 OSC
Usage: silentjack [options] [COMMAND [ARG]...]
Options: -c <port> Connect to this port
          -n <name> Name of this client (default 'silentjack')
          -1 <db>
                    Trigger level (default -40 decibels)
          -p <secs> Period of silence required (default 1 second)
          -d <db>
                    No-dynamic trigger level (default disabled)
          -P <secs>
                     No-dynamic period (default 10 seconds)
                     Grace period (default 0 seconds)
          -q <secs>
                     Enable verbose mode
          \nabla v
                     Enable quiet mode
          -q
          -o <port>
                     Set OSC port for listening (default 7777, ? for random)
          -H <port>
                     Set OSC host to send to (default 127.0.0.1)
          -0 <port>
                     Set OSC port to send to (default 7778)
          -X
                      Disable all OSC functions
                      Show help
```

# 2 OSC Settings

The following three settings define how OSC messages are processed.

• Port to start OSC Server and listen for incoming messages

• Host and port to send outgoing messages to (report to this address)

The default settings are

- Start OSC Server on port 7777
- Report to 127.0.0.1, port 7778

Example command line call with alternative OSC settings

```
$ silentjack -o 9999 -H 10.10.10.255 -O 10000
```

#### Note

The OSC telling and answering mechanism is different from other implementations

- · Messages are not sent back to the host and port of the requester by default
- · There is no pub/sub mechanism and therefore no subscribers list to serve

This allows the following scenarios

- · A requesting process can be decoupled from the node that receives the answer
- · Address of report host can be a broadcast address to serve all on subnet

There is a seperate -V (verbose) command line switch for OSC.

Most of the settings like silence/grace period, trigger level, verboseness can be read and set while the program is running via OSC.

# 3 Messages sent by silentjack



#### **Important**

for all patterns, a client name silentjack is used. The patterns will differ if silentjack is started for instance with -n sj1. An answer would look like /sj1/... in that case.

#### 3.1 /silentjack/started

```
Message Pattern:
        /silentjack/started ssiifi
Parameters:
       s: jack_client_name
        s: osc_server_port
        i: silence_period
                                [sec]
        i: grace_period
                                [sec]
        f: trigger_level
                                [dB]
        i: is_verbose
Sent on event:
        silentjack ready for service after startup.
Sent if:
    not matter if verbose
```

```
Example:
/silentjack/started ssiifi "silentjack" "7777" 5 0 -40.000000 1
```

### 3.2 /silentjack/not\_connected

```
Message Pattern:
    /silentjack/not_connected ss

Parameters:
    s: jack_client_name
        s: osc_server_port

Sent on event:
        silentjack is not yet or not any longer connected to any jack source port.
        Message is repeated every second.

Sent if:
        verbose ('-V')

Example:
        /silentjack/not_connected ss "silentjack" "7777"
```

#### 3.3 /silentjack/connected

```
Message Pattern:
    /silentjack/connected ss

Parameters:
    s: jack_client_name
    s: osc_server_port

Sent on event:
    silentjack was just connected to a jack source port.
    Message is sent once on connect and is followed by '/silentjack/level' messages.

Sent if:
    verbose ('-V')

Example:
    /silentjack/connected ss "silentjack" "7777"
```

### 3.4 /silentjack/level

```
Message Pattern:
    /silentjack/level ssiif

Parameters:
    s: jack_client_name
    s: osc_server_port
    i: is_above_threshold
    i: seconds_in_period [sec]
    f: level

Sent on event:
    silentjack just made another evaluation of the audio signal.
    This happens once per second and only if connected and
```

```
not in grace period.

Sent if:
    verbose ('-V')

Example:
    /silentjack/level ssiif "silentjack" "7777" 0 4 -8.267532
```

## 3.5 /silentjack/silent

```
Message Pattern:
    /silentjack/silent ssf

Parameters:
    s: jack_client_name
    s: osc_server_port
    f: level [dB]

Sent on event:
    silentjack detected silence (max silence was reached).

Sent if:
    verbose ('-V')

Example:
    /silentjack/silent ssf "silentjack" "7777" -45.267532
```

## 3.6 /silentjack/run\_cmd

```
Message Pattern:
    /silentjack/run_cmd sss(s*)

Parameters:
    s: jack_client_name
    s: osc_server_port
    s: command
        (s: param 1)
        (s: param n)

Sent on event:
        silentjack runs a command (after silence detected) if silentjack
        was started with a command argument (last option).

Sent if:
        no matter if verbose

Example:
        /silentjack/run_cmd sssss "silentjack" "7777" "/usr/local/bin/myscript.sh"
```

### 3.7 /silentjack/grace

```
Message Pattern:
    /silentjack/grace ssi

Parameters:
    s: jack_client_name
```

```
s: osc_server_port
i: seconds_in_grace_period [sec]

Sent on event:
    silentjack is in grace period.
    The message is repeated until the period is over.

Sent if:
    verbose ('-V')

Example:
    /silentjack/grace ssi "silentjack" "7777" 9
```

### 3.8 /silentjack/settings

```
Message Pattern:
       /silentjack/settings ssiifi
Parameters:
       s: jack_client_name
       s: osc_server_port
       i: silence_period
                               [sec]
       i: grace_period
                               [sec]
                               [dB]
       f: trigger_level
       i: is_verbose
Sent on event:
        silentjack was reconfigured or requested to tell the current configuration.
Sent if:
       no matter if verbose
Example:
       /silentjack/settings ssiifi "silentjack" "7777" 5 10 -40.000000 1
```

## 3.9 /silentjack/quit

```
Message Pattern:
    /silentjack/quit ss

Parameters:
    s: jack_client_name
        s: osc_server_port

Sent on event:
        silentjack is about to quit.
        This is normally caused by CTRL+C or sending the message '/silentjack/quit'.

Sent if:
        no matter if verbose

Example:
        /silentjack/quit ss "silentjack" "7777"
```

## 4 Messages received by silentjack



#### **Important**

all get/set methods have a free-defined string as an additional argument ( $req\_id$ ). The string will be repeated in the requested answer from silentjack.

### 4.1 /silentjack/get\_settings

```
Message Pattern:
    /silentjack/get_settings

Parmeters:
    s: req_id

Action:
    request silentjack to tell current settings.

Reply:
    /silentjack/settings ssiifis

    s: jack_client_name
    s: osc_server_port
    i: silence_period [sec]
    i: grace_period [sec]
    f: trigger_level [dB]
    i: is_verbose
    s: req_id
```

### 4.2 /silentjack/set\_trigger\_level

```
Message Pattern:
    /silentjack/set_trigger_level f

Parameters:
    f: trigger_level [db]
    s: req_id

Action:
    request silentjack to reconfigure trigger level.

Reply:
    /silentjack/settings ssiifis
```

### 4.3 /silentjack/set\_silence\_period

```
Message Pattern:
    /silentjack/set_silence_period i

Parameters:
    i: silence_period [sec]
    s: req_id
Action:
```

```
request silentjack to reconfigure silence period.

Reply:
/silentjack/settings ssiifis
```

## 4.4 /silentjack/set\_grace\_period

```
Message Pattern:
    /silentjack/set_grace_period i

Parameters:
    i: grace_period [sec]
    s: req_id

Action:
    request silentjack to reconfigure grace period.

Reply:
    /silentjack/settings ssiifis
```

### 4.5 /silentjack/set\_verbose

```
Message Pattern:
    /silentjack/verbose i

Parameters:
    i: is_verbose
    s: req_id

Action:
    request silentjack to be or not to be verbose OSC-wise (0/1).

Reply:
    /silentjack/settings ssiifis
```

## 4.6 /silentjack/quit

```
Message Pattern:
    /silentjack/quit

No Parameters

Action:
    request silentjack to quit.

Reply:
    /silentjack/quit ss
    s: jack_client_name
    s: osc_server_port
```

## 5 Test it

```
$ silentjack -n "stream_silence_listener" -1 -50 -p 30 -g 60 -V -c "mpg123-6153:left"
```

This will start an instance of silentjack in OSC verbose mode (-V) named stream\_silence\_listener (-n) and connect it to output port of mpg123 (-c) or any other JACK source of your choice. Since no specific arguments for OSC are given, the standard values are used: silentjack will receive messages on port 7777, and will report any events or answers to requests to localhost, port 7778.

If the audio level falls below -50 dB (-1) for at least 30 seconds (-p). When silence is detected, evaluation will start again after a grace period of 60 seconds (-g).

The oscdump program is an example client of liblo and can be found there. It will dump all messages sent by silentjack.

```
$ oscdump 7778
```

Messages to control a running silentjack can be sent for instance with oscsend.

```
$ oscsend localhost 7777 /stream_silence_listener/set_trigger_level fs -10 "foo"
```

### 5.1 Application Notes

In order to detect a faulty audio signal in means of a missing left or right channel, use two instances of silentjack, one per channel. silentjack can be used for any audio routing logic that depends on available / not available signals in an automatic way, for instance to drive fade-in / fade-out by precedence rules over an array of inputs.