REV	Description	DATE	ВУ
Initial	Initial relase.	9/10/11	29
1. P. P. S.	1. [P2] Added jumper to connect PWR_EN pullup to VDD_VRTC as VDD_IO does not come up before PWR_EN. 2. [P2] Added jumper to connect I2C pullups to VDD_IO. 3. [P3] Added jumper to connect I2C pullups to VDD_IO. 3. [P3] Made R189 DNI as USB cable insertion would cause Processor reset. 4. [P10] Made R163 as DNI as FT2232 was keeping Processor in reset. 5. [P8] Made R162 4.75K. 7. [P8] Changed U9 to TPS2051 with active HI enable. 8. [P8] Changed R146 to 0 ohm 9. [P8] Changed R199 to DNI. 10. [P9] Changed R144 to DNI. 11. [P9] Change R143 to DNI. 12. [P8] Change R200 to installed.	10/1/11	9



Texas instruments incorporated
WW Statego Markeing
12500 TIBIN
Delas, TX 72243
TI - Proprietary Information
TI - Proprietary Information

BeagleBone
Cover Page
Size Document Number
B < Doc>
Date: Monday, October 03, 2011

Modified by: G. Coley

A 4



















