If you use new batteries in SDM660 or MSM8998 platform, should do as below,

- 1. Send the batteries to our HW battery profile team (should do by your HW team)
- 2. One vendor's battery, we will give you 2 format battery profile, one is *.csv and the other is *.dtsi
- *.csv is used in UEFI and WP platform and *.dtsi is used in kernel
- 3. Add battery profile in UEFI

Take the .csv file and rename the file to BATTERY.PROVISION and then replace the original

BATTERY.PROVISION file in UEFI build

BATTERY.PROVISION path: boot_images\QcomPkg\Drivers\QcomChargerDxe\BATTERY.PROVISION

If you have more than one battery profile, please copy and add it to BATTERY.PROVISION one by

one

The max number in SW, we support 8 battery profile #define MAX_NUM_OF_BATT_PROFILE 8 // Number profile that can exists in profile file

4. Add battery profile in Kernel

Just need to add the *.dtsi in kernel\arch\arm64\boot\dts\qcom