- Close Window
- Print This Page
- Expand All | Collapse All

## how to get the MSM chip SN

**Solution Number** 

00031446

## **Please Note:**

If Qualcomm documentation is referenced in this solution, your access to it is based on your company's

Language Key Words

## **Detail Information**

Solution Title
Solution Details

how to get the MSM chip SN

1. Check if you have /dev/mem , if not, check your kernel config CONFIG\_DEVMEM is enable or not

See drivers/char/mem.c #ifdef CONFIG\_DEVMEM

[1] = { "mem", 0, &mem\_fops, &directly\_mappable\_cdev\_bdi },

#endif

2. Toolbox has r only if you build eng builds see system/core/toolbox/r.c

0x00058008 QFPROM\_RAW\_SERIAL\_NUM is defined in 80-NT665-2X MSM8952 HARDWARE

REGISTER DESCRIPTION.pdf

See the sample output on my 8952 devices;

root@msm8952\_64:/ # /system/bin/r 0x00058008

00058008: 0026b5bc root@msm8952\_64:/#

Applicable Products

AMSS8952