How to avoid device reboot when get the output of "cat /d/gpio"?

We can get GPIO configuration by "cat /d/gpio", but when you execute this command, sometimes system will reboot, the reason is that this command will access all GPIOs registers, but some of the GPIOs are protected by TZ, AP has no permission to access these GPIOs, so trigger a xpu error.

You can use following patch to get the status of the GPIOs which only requested in kernel:

```
@@ -579,16 +579,20 @@ static void msm gpio dbg show one(struct seg file *s, seg printf(s, "
%-8s: %-3s %d", g->name, is_out ? "out": "in", func); seq_printf(s, " %dmA", msm_regval_to_drive(
drive)); seq_printf(s, " %s", pulls[pull]);
+ seq_puts(s, "\n");
}
static void msm_gpio_dbg_show(struct seq_file *s, struct gpio_chip *chip)
unsigned gpio = chip->base;
unsigned i;
+ const char *label;
for (i = 0; i < chip->ngpio; i++, gpio++)
+ label = gpiochip_is_requested(chip, i);
+ if (!label)
+ continue;
msm_gpio_dbg_show_one(s, NULL, chip, i, gpio);
- seq_puts(s, "\n");
}
}"
```

If you want to use this interface to get the status of the GPIOs which used in other subsystem, you need to know the GPIOs which protected in TZ and remove it because AP has no permission to get the status. Here taking sdm670 as an example, from below doc, it knows which QUPV3 is protected by tz trustzone_images/core/settings/buses/qup_accesscontrol/qupv3/config/670/QUPAC_Access.c

```
const QUPv3_se_security_permissions_type qupv3_perms_default[] = {
/* PeriphID, ProtocolID, Mode, NsOwner,bAllowFifo,bLoad,bModExcl */
{ QUPV3_0_SE0, QUPV3_PROTOCOL_SPI, QUPV3_MODE_GSI, AC_TZ, FALSE, TRUE, TRUE }
, // NFC eSE
/*QUPV3_0_SE1*/
```

```
/*QUPV3 0 SE2*/
{ QUPV3 0 SE3, QUPV3 PROTOCOL I2C, QUPV3 MODE GSI, AC HLOS, TRUE, TRUE,
FALSE }, // NFC
/*QUPV3 0 SE4*/
/*QUPV3 0 SE5*/
{ QUPV3 0 SE6, QUPV3 PROTOCOL UART 4W, QUPV3 MODE FIFO, AC HLOS, TRUE,
TRUE, FALSE }, // Cherokee BT HCI
/*QUPV3 0 SE7*/
{ QUPV3_1_SE0, QUPV3_PROTOCOL_SPI, QUPV3_MODE_GSI, AC_HLOS, TRUE, TRUE,
FALSE }, // WCD9340
{ QUPV3_1_SE1, QUPV3_PROTOCOL_I2C, QUPV3_MODE_GSI, AC_HLOS, FALSE, TRUE,
FALSE }, // Legacy touch
{ QUPV3 1 SE2, QUPV3 PROTOCOL I2C, QUPV3 MODE FIFO, AC HLOS, TRUE, TRUE,
FALSE }, // Haptics (sensors hub)
/*QUPV3 1 SE3*/
{ QUPV3_1_SE4, QUPV3_PROTOCOL_UART_2W, QUPV3_MODE_FIFO,AC_HLOS, TRUE,
FALSE, FALSE }, // Debug
/*QUPV3_1_SE5*/
/*QUPV3 1 SE6*/
{ QUPV3_1_SE7, QUPV3_PROTOCOL_SPI, QUPV3_MODE_GSI, AC_TZ, FALSE, TRUE, TRUE }
, // Fingerprint
};
from below doc, it knows which gpio are binding(protected in TZ) in one QUPV3 trustzone_images/
core/settings/buses/qup_accesscontrol/qupv3/config/670/QUPAC_Private.c
const QUPv3_se_resource_type qupv3_se_hw[] = {
{ QUPV3 0 SE0, (uint8*)0x880000, "gcc qupv3 wrap0 s0 clk" }, // { 0, 1, 2, 3 }
{ QUPV3_0_SE1, (uint8*)0x884000, "gcc_qupv3_wrap0_s1_clk" }, // { 17, 18, 19, 20 }
{ QUPV3_0_SE2, (uint8*)0x888000, "gcc_qupv3_wrap0_s2_clk" }, // { 27, 28, 29, 30 }
{ QUPV3_0_SE3, (uint8*)0x88c000, "gcc_qupv3_wrap0_s3_clk" }, // { 41, 42, 43, 44 }
{ QUPV3_0_SE4, (uint8*)0x890000, "gcc_qupv3_wrap0_s4_clk" }, // { 89, 90, 91, 92 }
{ QUPV3_0_SE5, (uint8*)0x894000, "gcc_qupv3_wrap0_s5_clk" }, // { 85, 86, 87, 88 }
{ QUPV3_0_SE6, (uint8*)0x898000, "gcc_qupv3_wrap0_s6_clk" }, // { 45, 46, 47, 48 }
{ QUPV3_0_SE7, (uint8*)0x89c000, "gcc_qupv3_wrap0_s7_clk" }, // { 93, 94, 95, 96 }
{ QUPV3_1_SE0, (uint8*)0xa80000, "gcc_qupv3_wrap1_s0_clk" }, // { 65, 66, 67, 68 }
{ QUPV3_1_SE1, (uint8*)0xa84000, "gcc_qupv3_wrap1_s1_clk" }, // { 4, 5, 6, 7 }
{ QUPV3_1_SE2, (uint8*)0xa88000, "gcc_qupv3_wrap1_s2_clk" }, // { 53, 54, 55, 56 }
{ QUPV3_1_SE3, (uint8*)0xa8c000, "gcc_qupv3_wrap1_s3_clk" }, // { 31, 32, 33, 34 }
{ QUPV3_1_SE4, (uint8*)0xa90000, "gcc_qupv3_wrap1_s4_clk" }, // { 49, 50, 51, 52 }
{ QUPV3_1_SE5, (uint8*)0xa94000, "gcc_qupv3_wrap1_s5_clk" }, // {105,106,107,108 }
{ QUPV3_1_SE6, (uint8*)0xa98000, "gcc_qupv3_wrap1_s6_clk" }, // { 31, 32, 33, 34 }
{ QUPV3_1_SE7, (uint8*)0xa9c000, "gcc_qupv3_wrap1_s7_clk" }, // { 81, 82, 83, 84 } };"
```

Please remove these GPIOs in msm_gpio_dbg_show, For example if GPIO0, GPIO1, GPIO2, GPIO3, GPIO135, GPIO136, GPIO137, GPIO138 are used in TZ side, then we need to ignore these GPIOs as following code:

```
--- a/drivers/pinctrl/gcom/pinctrl-msm.c
+++b/drivers/pinctrl/qcom/pinctrl-msm.c
@@ -522,8 +522,9 @@ static void msm_gpio_dbg_show(struct seq_file *s, struct gpi
unsigned i;
for (i = 0; i < chip->ngpio; i++, gpio++) {
- msm_gpio_dbg_show_one(s, NULL, chip, i, gpio);
- seq_puts(s, "\n");
+ if (i != 0 && i != 1 && i != 2 && i != 3 && i != 135 && i != 136 && i != 137 && i != 138)
+ msm_gpio_dbg_show_one(s, NULL, chip, i, gpio);
+ seq_puts(s, "\n");
}
}
+ msm_gpio_dbg_show_one(s, NULL, chip, i, gpio);
+ seq_puts(s, "\n");
}
}
```

this cannot provide an official patch because different customer uses different gpio setting, so please change it by yourself or ignore this panic