

PMI632 Battery Temperature Sensing and Compensation Configuration

80-P3255-39 B July 20, 2018

Confidential and Proprietary – Qualcomm Technologies, Inc.

NO PUBLIC DISCLOSURE PERMITTED: Please report postings of this document on public servers or websites to: DocCtrlAgent@qualcomm.com.

Restricted Distribution: Not to be distributed to anyone who is not an employee of either Qualcomm Technologies, Inc. or its affiliated companies without the express approval of Qualcomm Configuration Management.

Not to be used, copied, reproduced, or modified in whole or in part, nor its contents revealed in any manner to others without the express written permission of Qualcomm Technologies, Inc.

All Qualcomm products mentioned herein are products of Qualcomm Technologies, Inc. and/or its subsidiaries.

Qualcomm and Qualcomm Battery Gauge are trademarks of Qualcomm Incorporated, registered in the United States and other countries. Other product and brand names may be trademarks or registered trademarks of their respective owners.

This technical data may be subject to U.S. and international export, re-export, or transfer ("export") laws. Diversion contrary to U.S. and international law is strictly prohibited.

Qualcomm Technologies, Inc. 5775 Morehouse Drive San Diego, CA 92121 U.S.A.

Revision history

Revision	Date	Description
А	May 2018	Initial release
В	July	Updated section 2.6



Contents

1 Introduction	4
1.1 Purpose	4
1.2 Conventions	4
1.3 Technical assistance	
2 Overview	5
2.1 Functionality	6
2.2 BATT_THERM_RBIAS pull-up selection	
2.3 Conversion table and thermistor selection	
2.4 Conversion table creation	6
2.5 Relevant files	7
2.6 Example – Update interpolation table for BATT_THERM	
A References	13
A.1 Related documents	13
A.2 Acronyms and terms	13

1 Introduction

1.1 Purpose

This document helps to configure the ADC parameters for Battery temperature sensing and compensation based on the customer-specific battery NTC specification.

Use the attached spreadsheet to generate the conversion table and JEITA ADC codes.

1.2 Conventions

Function declarations, function names, type declarations, attributes, and code samples appear in a different font, for example, op armog armog.

Code variables appear in angle brackets, for example, <number>.

Commands to be entered appear in a different font, for example, copy a:*.* b:.

Button and key names appear in bold font, for example, click **Save** or press **Enter**.

Shading indicates content that is added or changed in this revision of the document.

1.3 Technical assistance

For assistance or clarification on information in this document, submit a case to Qualcomm Technologies, Inc. (QTI) at https://createpoint.qti.qualcomm.com/.

If you do not have access to the CDMATech Support website, register for access or send email to support.cdmatech@qti.qualcomm.com.

2 Overview

The Qualcomm[®] Battery Gauge[™] module monitors battery temperature using a dedicated BATT_THERM pin via VADC. Information about the battery's temperature is used by the Qualcomm Battery Gauge for the following purposes:

- Improve SoC accuracy by adjusting the Qualcomm Battery Gauge models based on the temperature
- Accommodate charger operation with respect to JEITA requirements


Previous scheme

- Thermistors require a type of bias to generate a voltage
- Past designs have used external dedicated or shared pull-ups
- Adds a pull-up for each thermistor
- Requires package pin for LDO output
- Consumes power-on all thermistors whenever LDO is on

PMI632 scheme

Optimizing cost and performance, PMI632 features internal pull-up resistors.

- Three pull-up values (30K, 100K, 400K)
- Trimmed to within 0.5% accuracy Better tolerance than discrete R
- Low temperature coefficient (< 100 ppm/C) Better than discrete R
- Bias source is a calibrated internal LDO No package pin
- LDO is automatically controlled by ADC hardware
- Each thermistor is only biased when measured Saves power



2.1 Functionality

The Qualcomm Battery Gauge uses a ratiometric conversion. The advantage of this design is that the pull-up used to bias the thermistor is the same regulator internal to the PMIC that supplies the ADC. This design allows a more robust measurement scheme and simplifies thermistor modeling. The BATT_THERM_BIAS control is also automatically handled by hardware.

2.2 BATT_THERM_RBIAS pull-up selection

Due to the ratiometric nature of the temperature measurement scheme, a pull-up resistor must be chosen to match the thermistor's resistance value at its center range point (25°C). Temperature accuracy measurements are out of specification if the pull-up resistor is not chosen correctly.

2.3 Conversion table and thermistor selection

It is recommended to choose a thermistor with a beta value on the lower end of the supported range. This selection improves accuracy over the entire temperature range as a lower beta value varies less over temperature.

To convert from voltage measurements to temperature readings, the PMIC uses a linear approximation. This approximation uses the conversion table, which is an array of a mapping of {mV, °C}.

To function correctly, the conversion table must be programmed into the Qualcomm Battery Gauge for the thermistor value selected. Failure to do this can result in inaccurate temperature measurement.

2.4 Conversion table creation

- 1. Download the attached spreadsheet.
- 2. Enter NTC resistor/beta values based on the battery datasheet.

Thermistor							
NTC Resistor =	100	kΩ	1%	enter NTC	Resistor /E	Beta based on Batter	y datasheet
@	25	°C					
NTC Beta =	4250	K	1%				

3. Chose the pull-up value closest to the NTC resistor.

Temperature	100K pull-up	400K pull-up	30K pull-up
(°C)	Vtherm (V)	Vtherm (V)	Vtherm (V)
-40	1.840	1.744	1.864
-38	1.835	1.724	1.863
-36	1.828	1.701	1.861
-34	1.821	1.676	1.858
-32	1.813	1.648	1.856
-30	1.803	1.618	1.853

Temperature	100K pull-up	400K pull-up	30K pull-up
(°C)	Vtherm (V)	Vtherm (V)	Vtherm (V)
-28	1.793	1.584	1.850
-26	1.781	1.548	1.846
:	:	:	:
80	0.184	0.050	0.498
82	0.173	0.046	0.474
84	0.163	0.043	0.451
86	0.153	0.041	0.428
88	0.144	0.038	0.407
90	0.136	0.036	0.387
92	0.128	0.034	0.367
94	0.120	0.032	0.349
96	0.114	0.030	0.332
98	0.107	0.028	0.315

4. Enter the JEITA threshold to generate the corresponding ADC code for each pull-up.

IFITA de se ale al d	Temp	ADC code*			
JEITA threshold	(°C)**	100K pull-up	400K pull-up	30K pull-up	
JEITA hot soft	40	25E3	CA8	46D4	
JEITA hot hard	45	20B8	A73	4111	
JEITA cold soft	5	5314	2E5B	65EB	
JEITA cold hard	0	58CD	3624	6865	
	* Choose the ADC code for the same pull-up chose for BAT_THERM_LUT				
	** Enter the JEITA threshold to generate the corresponding ADC code for each pull-up.				

2.5 Relevant files

ADC driver source	kernel/drivers/hwmon/qpnp-adc-common.c kernel/drivers/hwmon/qpnp-adc-voltage.c kernel/include/linux/qpnp/qpnp-adc.h kernel/drivers/power/supply/qcom/qg-util.c
Charger driver source	kernel/drivers/power/supply/qcom/smb5-lib.c
DTSI documentation	For the latest DTSI parameter information, refer to the DTSI binding documentation: kernel/Documentation/devicetree/bindings/hwmon/qpnp-adc-voltage.txt kernel/ Documentation/devicetree/bindings/batterydata/batterydata.txt
DTSI files	kernel/arch/arm64/boot/dts/qcom/pmi632.dtsi
SBL	boot_images/core/systemdrivers/pmic/target/msm8953_pm8953_pmi8950/system/src/pm_sbl_boot_oem.c
Battery profile dtsi	kernel/arch/arm64/boot/dts/qcom/qg-batterydata-mlp356477-2800mah.dtsi

2.6 Example – Update interpolation table for BATT_THERM

1. Add the interpolation table and the new scale function in qpnp-adc-common.c.

```
/* Voltage to temperature */
static const struct qpnp_vadc_map_pt adcmap_batt_therm_pul00_b4250[] = {
                -400},
     {1840,
     {1835,
                -380},
     {1828,
                -360},
     {1821,
                -340},
                -320},
     {1813,
     {1803,
               -300},
     {1793,
               -280},
                -260},
     {1781,
     {1768,
                -240},
     {1753,
                -220},
                -200},
     {1737,
     {1719,
                -180},
     {1700,
                -160},
                -140},
     {1679,
     {1655,
                -120},
                -100},
     {1630,
     {1603,
                -80},
     {1574,
                -60},
     {1543,
                -40},
                -20},
     {1510,
     {1475,
                00},
     {1438,
                20 } ,
     {1400,
                40 } ,
     {1360,
                60},
                80},
     {1318,
                100},
     {1276,
                120},
     {1232,
     {1187,
                140},
     {1142,
                160},
     {1097,
                180},
     {1051,
                200},
     {1005,
                220},
     {960,
                240},
     {915,
                260},
     {871,
                280},
     {828,
                300},
     {786,
                320},
     {745,
                340},
     {705,
                360},
     {666,
                380},
     {629,
                400},
     {594,
                420 },
```

```
{560,
               440},
     {527,
               460},
     {497,
               480},
     {467,
               500},
     {439,
               520},
     {413,
               540},
     {388,
               560},
     {365,
               580},
                   12.26.23.06.09 p.S.T.
     {343,
               600},
     {322,
               620},
     {302,
               640},
     {284,
               660},
     {267,
               680},
     {251,
               700},
     {235,
              720},
     {221,
               740},
     {208,
               760},
               780},
     {195,
     {184,
               800},
     {173,
               820},
     {163,
               840},
     {153,
               860},
     {144,
               880},
     {136,
               900},
               920},
     {128,
               940},
     {120,
               960},
     {114,
     {107,
               980}
};
int32_t qpnp_adc_batt_therm_B4250_pu100 (struct qpnp_vadc_chip *chip,
               int32_t adc_code,
               const struct qpnp_adc_properties *adc_properties,
               const struct qpnp_vadc_chan_properties *chan_properties,
               struct qpnp_vadc_result *adc_chan_result)
{
       int64_t batt_thm_voltage = 0;
       if (!chan_properties || !chan_properties->offset_gain_numerator
!chan_properties->offset_gain_denominator
| | !adc_properties
               | | !adc_chan_result)
               return -EINVAL;
       /* (code * vref_vadc (1.875V) * 1000) / (scale_code * 1000) */
       if (adc_code > QPNP_VADC_HC_MAX_CODE)
               adc_code = 0;
```

Update the enum corresponding to the table in qpnp-adc.h and add a new scale function declaration.

```
enum qpnp_adc_scale_fn_type
SCALE DEFAULT = 0,
SCALE_BATT_THERM_B4250_PU100,
SCALE_NONE,
 * qpnp_adc_batt_therm_B4250_pu100() - Scales the pre-calibrated digital
output
               of an ADC to the ADC reference and compensates for the
               gain and offset. Returns the temperature in decidegC.
               It uses a mapping table computed for a 400K pull-up.
 * @dev:
               Structure device for qpnp vadc
 * @adc_code: pre-calibrated digital output of the ADC.
 * @adc_prop: adc properties of the adc such as bit resolution,
               reference voltage.
 * @chan_prop: individual channel properties to compensate the i/p
scaling,
               slope and offset.
* @chan_rslt: physical result to be stored.
int32_t qpnp_adc_batt_therm_B4250_pu100 (struct qpnp_vadc_chip *dev,
                       int32_t adc_code,
                       const struct qpnp_adc_properties *adc_prop,
                       const struct qpnp_vadc_chan_properties
*chan_prop,
                       struct qpnp_vadc_result *chan_rslt);
```

3. Add a new entry to the mapping table of qpnp-adc-voltage.c and equate it to the enum in qpnp-adc-common.c and qpnp-adc.h.

```
static struct qpnp_vadc_scale_fn vadc_scale_fn[] = {
        [SCALE_USBIN_I] = {qpnp_adc_scale_usbin_curr},
        [SCALE_BATT_THERM_TEMP_QRD] = {qpnp_adc_batt_therm_qrd},
        [SCALE_SMB1390_DIE_TEMP] = {qpnp_adc_scale_die_temp_1390},
+        [SCALE_BATT_THERM_B4250_PU100] =
{        qpnp_adc_batt_therm_B4250_pu100},
};
```

4. Add or modify the VADC channel node in the PMI632.dtsi based on the pull-up value. Select the ADC hardware channel number based on the pull-up.

Internal-pull up	100K PU	400K PU	30K PU	No-Pull up
Hardware channel	0x4a	0x6a	0x2a	0xa

5. Update the pull in the charger peripheral register in the boot_images/core/ systemdrivers/pmic/config/msm8953/pmi632/ pm_config_target_sbl_sequence.c file.

```
INTERNAL_PULL_UP_BAT_THM_NO_PULLUP 0
INTERNAL_PULL_UP_BAT_THM_30K_PULLUP 1
INTERNAL_PULL_UP_BAT_THM_100K_PULLUP 2
INTERNAL_PULL_UP_BAT_THM_400K_PULLUP 3
// MODE - SCHG_Configs : 35
  //sid data
                                   register Mask
                                                    rea
വാ
                   cond start
                                      cond end
{ 2,
                       0x02.
                                               0x1286.
  0xFF,
          PM_SBL_WRITE,
                                                                 0 }
           // Line 43
                        Source:
Write(Nebula.SCHG_BATIF.ADC_INTERNAL_PULL_UP, 0x02) \rightarrow default code
                                                 0x1286,
++{ 2,
            0x01,
 0xFF, PM_SBL_WRITE,
            // Line 43 Source:
```

```
Write(Nebula.SCHG_BATIF.ADC_INTERNAL_PULL_UP, 0 \times 01) \Rightarrow add new line to modify as 0 \times 1 for 30 \text{k} pull up
```

6. Update the JEITA threshold in the battery profile dtsigg-batterydata-mlp356477-2800mah.dtsi

```
qcom, mlp356477_2800mah {
     /* mlp356477_2800mah_averaged_MasterSlave_Aug14th2017 */
    gcom,max-voltage-uv = <4400000>;
    qcom,fg-cc-cv-threshold-mv = <4390>;
     gcom,fastchg-current-ma = <4200>;
    gcom,batt-id-kohm = <82>;
    gcom,battery-beta = <4250>;
    qcom,battery-therm-kohm = <32>;
    gcom,battery-type =
          "mlp356477_2800mah_averaged_MasterSlave_Aug14th2017";
    qcom,qg-batt-profile-ver = <100>;
                                        560000
    qcom,jeita-fcc-ranges = <0</pre>
                                  150
                             4200000
                    151 450
                    451 550 2380000>;
     gcom, jeita-fv-ranges = <0</pre>
                                 150 4150000
                    151 450 4400000
                    451 550 4150000>;
        qcom, jeita-soft-thresholds = <0x5314 0x25e3>;
       gcom, jeita-hard-thresholds = <0x58cd 0x20b8>;
```

7. Change the channel based on pull up in drivers/power/supply/qcom/qg-util.c.

/* No pull up */	VADC_BAT_THERM	0xa
/* PU1 is 30K pull up */	VADC_BAT_THERM_PU1	0x2a
/* PU2 is 100K pull up */	VADC_BAT_THERM_PU2	0x4a
/* PU3 is 400K pull up */	VADC_BAT_THERM_PU3	0x6a

A References

A.1 Related documents

Title	Number
Qualcomm Technologies, Inc.	
PMIC Dump and Register Access Overview	80-NL708-1
SDM632 + PMI632-5 + PM8953 + PM8004-1 Reference Schematic	80-PF078-41
PM8953 + PMI632 Power Management IC Design Guidelines	80-PF457-5A

A.2 Acronyms and terms

Acronym or term	Definition	
ADC	Analog to digital converter	
DTSI	Device tree source include	