Functional Safety of Embedded Systems - Part 4 - Embedded Systems Software / Evaluation and Validation

- reuse of intellectual property (IP) => saves cost & effort
 - embedded operating systems
 - middleware (intermediate layer between the OS and application software)
 - extend communication
 - real time database
 - API (of standard components)

Embedded Operating Systems

General Requirements

- very simple systems => does not need OS
- OS => task switching/dispatching, I/O, scheduling
 - Special processors for this may exist.
- systems with virtual memory => distinguish between address spaces, processes, threads,
- Each process has its own address space, whereas several threads may share an address space.
- RT-OS must have:
 - o communication & synchronization between processes & threads
 - must be small
 - flexibly tailored towards application
 - o configurability (object orientation, aspect-oriented programming, conditional compiling, advanced compile-time evaluation, linker-based removal of unused functions)
- peripheral devices
 - o no hard-disk, no keyboard, no screen, no mouse
 - devices => maybe direct handling by application => OS does not take care about this => drivers in "user space"
 - connect interrupts to any process => use OS service calls
 - => real-time operating systems

Real-Time Operating Systems

"A real-time operating system is an operating system that supports the construction of real-time systems."

- key requirements:
 - timing must be predictable
 - upper bound must be guaranteed
 - scheduling must be deterministic
 - interrupts must be possible to disable
 - prevent unpredictable disk head movement (if HDD is used)
 - manage task scheduling
 - OS must be aware of deadlines
 - manage time (if internal processing is linked to absolute time in physical environment)
 - global clock synchronization

- *Universal Time Coordinated* (UTC): defined by astronomical standards
- international atomic time (temps atomic internationale TAI)
- networked embedded systems: synchronize via network
- sometimes only provision for precise local delay
- o must be fast
- includes OS kernel: manages resources found in every real time operating system
- available RTOS:
 - fast proprietary kernels: not for complex systems, tend to be not predictable
 - real-time extensions to standard OS: => hybrid systems
 - mainstream operating systems
 - RT-kernel for RT-tasks, rest of OS is one of those tasks
 - comforts:
 - standard OS API, GUI, filesystem, enhancement to OS
 - problems in standard-OS don't affect RT-part
 - problems:
 - device drivers (OS brings it's own)
 - RT-tasks generally cannot use the OS
 - research systems that try to overcome those limitations: Melody, Gupta, MARS, Spring, MARUTI, Arts, Hartos, DARK

Virtual Machines

- emulate several processors on single processor => virtual machines
- => timing predictability may be lost
- PikeOS

Resource Access Protocols

Priority Inversion

- cases, where a process needs exclusive access to some resources (shared variables, ...) => critical sections, mutex primitives
- request operation P(S), release operation V(S), => semaphore
- => mutually exclusive access to resources may change the priority of tasks (**priority inversion**) => preemption needed

Priority Inheritance

- deal with priority inversion => **priority inheritance**
- available in many RT-OS
 - tasks are scheduled according to priorities, same priority => first come, first serve
 - when task T1 has high priority and requests access to a critical section occupied by T2 with lower priority, T2 inherits T1s priority
 - when T2 frees the critical section, its priority is reduced back to its normal priority, the task with the highest priority waiting for the critical section get granted
 - priority inheritance is transitive
- This ensures, that the high priority process gets access to the critical section according to its own priority
- priority inheritance can still lead to deadlocks
- alternative approach: **priority ceiling protocol**

ERIKA

- entire application has to be hosted on small micro-controllers
- OS services => reduce to minimum (multi-threading, periodic and aperiodic tasks, shared resources)
- OSEK-group defined minimal set of services: OSEK/VDX
- quasi reference implementation for RT-micro-controller-OS, ERIKA (open source)
 - all kernel objects statically defined at compile-time (no dynamic memory allocation, no dynamic creation of tasks)
 - configuration language OIL
 - provides stack sharing
- Conformance Classes: specify subset of OS-API
 - BCC1: smallest, minimum of 8 tasks with different priority, 1 shared resource
 - BCC2: BCC1 + more than one task with same priority
 - ECC1: BCC1 + extended tasks, that can wait for event to disappear
 - ECC2: multiple activations + extended tasks
 - EDF: earliest deadline first scheduler
 - FRSH: extends EDF with resource reservation scheduler (based on IRIS algorithm)
- API for controlling interrupts, *Interrupt Service Routine* (ISR):
 - o category 1: simple and fast, does not implement call to scheduler
 - category 2: call some primitives that change scheduling behavior, end of this ISR is rescheduling point
- ORTI file/ language => describe where various objects are allocated, generated by OIL compiler

Hardware Abstraction Layer (HAL)

- access hardware through API
- neither OS, nor middleware

Middleware

- provide services to software, that OS does not provide
- e.g. communication over long distances and local communication
- for soft rt-systems OK, for hard rt-systems probably too much overhead

OSEK/VDX COM

- communication standard for OSEK (automotive operating system)
- provides interaction layer as API
- communicates via network layer and data link layer

CORBA (**COmmon Request Broker Architecture**)

- adopted for embedded systems, communication
- object request broker (ORB)
- remote objects => standard interface, send information and parameters about the object to be accessed
- RT-CORBA has predictability
 - end-to-end predictability of timeliness in a fixed priority system
 - addresses priority inversion (bound time, in which this can happen)
 - thread priority management

MPI (message passing interface)

- alternative to CORBA, communication between different processors
- synchronous and asynchronous message passing library, designed for high performance computing
- partitioning of computations/ data among processors explicitly
- synchronization is implied, explicit synchronization is also possible
- much work for programmer due to much explicit stuff
- does not scale well for number of processors
- MPI/RT => real time version, layer between OS and normal MPI
- targets homogeneous processor designs, assumption, that memory access is faster than communication

POSIX Threads (Pthreads)

- API for threads at OS level
- shared memory communication
- multi-core processors, mutual exclusion, completely synchronized

OpenMP

- parallelism is explicit (via "pragma"), computation partitioning, communication, synchronization are implicit
- shared memory hardware

UPnP (Universal Plug 'n' Play)

- extension of plug 'n' play for network connected devices
- only data is transfered
- may target: printers, storage, switches

DPWS (Device Profiles for Web Services)

- more general than UPnP
- "minimal set of implementation constraints to enable secure web service messaging, discovery, description and eventing on resource constrained devices"

JXTA (JuXTApose)

- loose coupling over Internet-based communication
- open-source peer-to-peer protocol specification
- set of XML messages
- creates virtual overlay network

Real-Time Databases

- databases may have time-constraints
 - e.g. soft: flight reservation system
 - e.g. hard: target recognition in military systems
- main memory databases, use of flash memory (predictability)
- reduce ACID requirement (atomicity, consistency, isolation, durability)

Evaluation and Validation

- **validation**: The process of checking whether or not a certain design is appropriate for its purpose, meets all constraints and will perform as expected. => (formal) verification
 - validation and design should be intertwined
- **evaluation**: process of computing quantitative information of some key characteristic of a certain (partial) design.

Multi-Objective Optimization

- Design Evaluation => characterization by several criteria (worst case/ average execution time, energy consumption, code size, dependability, safety)
- Give the designer back a set of "reasonable designs" among which he has to choose.
- try to optimize several solutions with respect to multiple objectives
- => pareto-front/ pareto-equilibrium => will not be optimal for all objectives, but as good as possible for all
- Design Space Exploration on pareto points (DSE) => try to find pareto optimal solution

Relevant Objectives

- 1. Average Performance: simulation
- 2. Worst-Case Performance/Real-Time Behavior: timing analysis
- 3. Energy Power Consumption_
- 4. Temperature/ Thermal Behavior
- 5. Reliability
- 6. Electromagnetic Compatibility
- 7. Numeric Precision
- 8. Testability: cost for testing can be quite large
- 9. Cost: silicon, ...
- 10. Weight, Robustness, usability, extendability, security, safety, environmental friendliness, ...

Performance Evaluation

• predict performance of system

Early Phase

- Estimated Cost and Performance Values: generating sufficiently precise estimates requires considerable effort.
- Accurate Cost and Performance Values: test real software on (near to) real hardware => more precise, but more expensive and more time consuming

WCET Estimation (Worst Case Execution Time)

- WCET: largest amount of time for any input and any initial state
- => often not possible to compute (halting problem)
- => compute good upper bounds for WCET => estimated worst case execution time
 - 1. $WCET_{est} \leq WCET$ (bounds should be safe)
 - 2. $WCET_{ext} WCET \ll WCET$ (bounds should be safe)
- architectural features to reduce average execution time often omitted.
- $BCET \& BCET_{safe}$ are analogously defined
- => bounds must be computed from real machine code
 - 1. executable object file
 - 2. control-flow graph

- 3. loop transformations, recursive functions, virtual loop unrolling
- 4. => CRL (control flow representation language)
- 5. static analysis (reading designers annotations)
- 6. value analysis (possible values for registers and local variables, predict access to memory)
- 7. cache & pipeline analysis (LRU last recent usage, what is in cache
- 8. => derive WCET (store in ILP model, take runtime of block, multiply by frequency of block) => *implicit path enumeration*

Real-Time Calculus (RTC)

• works with rate of incoming events

Energy and Power Models

- closely related (Energy is quadratic function of Power)
- Tiwari:
 - measurements of real systems
 - values are associated with executed instructions
 - => base cost, inter-instruction cost
- Simunic:
 - based on data sheets
 - computes contribution of all components of embedded system
 - information from data sheet may be averaged/less precise
- Russel & Jacome:
 - precise measurement of two fixed configurations
- Lee:
 - o detailed analysis of effects of pipeline
 - no multicycle operations/ pipeline calls
- Steinke:
 - o precise measurement using real hardware
 - consumption of processor and memory
 - included in *energy-aware compiler* from TU Dortmund
- WATTCH power estimation tool
 - estimates power consumption of microprocessor systems at architectural level, without information about circuits or layouts


Thermal Models

- more energy consumption => components get hot
- => failures
- => shortage of system life
- thermal models => laws of physics => thermal conductance/ thermal resistance
- equivalent models to electrical models (masses storing heat are capacitors)
- Tools: HotSpot


Risk and Dependability Analysis

- Embedded systems can cause danger to properties and lives. => Reduce probability of failure.
- Definitions
 - **Service** is delivered by a system as perceived by its users. **Correct Service** is delivered, when the service implements the system function.

- Service Failure, System failure or just Failure occurs, when the service of a system deviates from the correct service.
- Error exist, if there are system states, that lead to a service failure.
- A **Fault** is the reason for an error.
- **Reliability** R(t) is the probability of the time until the first failure occurs (after time t)
- Failure Rate $\lambda(t)$ is the probability of a system failure between time t and $t + \delta t$
- **Mean Time To Failure** (MTTF) is the average time until the next failure, provided the system was initally working.
- Mean Time Between Failures (MTBF) is the average time between to failures.
- **Mean Time To Repair** (MTTR) is the average time until the system is repaired, provided it is initially broken.
- Availability is the probability, that a system is in an operational state.
- Faults can exist, without leading to a service failure
- failure rates typically not constant (bath-tub)



MTBF = MTTF + MTTR



- Fault Tree Analysis (FTA): top-down method of analyzing risk. Starts with possible damage and possible scenarios. Connect them using AND and OR gates.
- Failure Mode and Effect Analysis (FMEA): Starts with components and tries to estimate reliability. => compute reliability of system.

Simulation

- common technique for evaluation and validation
- execute model on general purpose computers
- for Cyber physical systems, limitations exist:
 - Simulation is slower than actual system => timing may not work, when simulation system is directly interfaced with environment.

- Simulations in physical environment may be unsafe (car with simulated control software).
- Huge amounts of Data must be simulated.
- Actual systems are to complex to really simulate.

Rapid Prototyping and Emulation

- **Emulation** is the process of executing a model of the system-under-design, where at least one component is not simulated on some host computer.
- **Fast Prototyping** is the process of executing a model where no component is represented by simulation.

Formal Verification

- verification techniques can be classified by use of type of logic
- Propositional Logic: boolean logic, boolean checkers, tautology checkers, equivalence checkers
- First Order Logic (FOL) includes \exists and \forall => Hoare calculus
- *Higher Order Logic* (HOL) based on lambda-calculus and allows functions to be manipulated like objects.
- *Model Checking*: Need model to be verified and properties to be verified.

Testing

- Expectations for embedded/ cyber-physical systems are higher, as they may be safety-critical.
- Testing of timing-critical applications has to validate timing behavior.
- Testing in final environment may be dangerous (e.g. nuclear power plant).
- Early consideration and planning of testing important, although not common practice.
- SUD => DUT (design under test) => test patters
 - 1. test pattern generation
 - 2. test pattern application
 - 3. response observation
 - 4. result comparision

Test Pattern Generation for Gate Level Models

- Identify set of patterns, that distinguish correct from faulty system. => usually based on *fault modes*
- Many techniques for test pattern generation are based on stuck-at-fault model.

Self-Test Programs

- Hard to access internals of integrated circuits, especially at full speed (testers must be at least as fast as the system).
- Self-Test/ Diagnostic Programs for processors have existed for years.

Fault Coverage

- *fault coverage*: percentage of potential faults that can be found by a test pattern set. Good product quality: fault coverage of 98-99% needed
- correctness coverage: the correct system must be recognized as correct.

Fault Simulation

- Not feasible to predict complete behavior of system in the presence of faults. => Behavior often simulated => fault simulation
 - Know the effect of a fault on all components.
 - Redundant Faults: Do not affect the behavior of the system.
 - Know, whether mechanism for improving fault tolerance actually works.
- Large input space, large number of possible faults => fault simulation is time consuming and expensive.
- Parallel Fault Simulation: Test n different patterns in parallel. n is the machine word size.

Fault Injection

- For actual systems => use fault injection (bring the system into a faulty state).
 - Local faults in the system
 - faults in the environment
- several kinds of fault injection:
 - fault injection at hardware level (pin manipulation, radiation)
 - fault injection at software level (e.g. toggling some memory bits)

Design for Testability (DfT)

• Testing should not come as an afterthought, else testing may be very hard.

Scan Design

- All flip-flops storing states are connected to form serial shift registers.
- JTAG is standard for this.

Signature Analysis

- Responses can be compacted => avoid shifting out the response.
- Response becomes signature. linear feedback shift register (LFSR)

Pseudo-Random Test Pattern Generation

• For large chips this will speed up shifting the test pattern.

Built-In Logic Block Observer (BILBO)

• Proposed as circuit combining test pattern generation, test response compaction and serial scan thing.