	Pin name (function after reset)
TSSPOP2	
-	VBAT
-	PC13
-	PC14- OSC32_IN (PC14)
-	PC15- OSC32_OUT (PC15)
2	PF0-OSC_IN (PF0)
3	PF1-OSC_OUT (PF1)
4	NRST
15	VSSA
5	VDDA
6	PA0
7	PA1
8	PA2
9	PA3
	Pin name (function after reset)
TSSPOP2	
10	PA4
11	PA5
12	PA6
13	PA7
-	PB0
14	PB1
-	PB2
-	PB10
-	PB11
15	VSS
16	VDD
-	PB12
	Pin name (function after reset)
TSSPOP2	
-	PB13
-	PB14
-	PB15
-	PA8
17	PA9
18	PA10
17(4)	PA11
18(4)	PA12
19	PA13
-	VSS
16	VDDIO2
	Pin name (function after reset)
TSSPOP2	
20	PA14
-	PA15
-	PB3
-	PB4
-	PB5
-	PB6
-	PB7
-	PF11 BOOT0
1	PB8 BOOT0

-	PB8
	Pin name (function after reset)
TSSPOP2	
-	PB9
-	VSS
-	VDD

Pin functions
Alternate function
Backup power supply
-
-
-
CRS_ SYNC I2C1_SDA
I2C1_SCL
Device reset input / internal reset output (active low)
Analog ground
Analog power supply
USART2_CTS, TIM2_CH1_ETR, TSC_G1_IO1
USART2_RTS, TIM2_CH2, TSC_G1_IO2, EVENTOUT
USART2_TX, TIM2_CH3, TSC_G1_IO3
USART2_RX, TIM2_CH4, TSC_G1_IO4
Pin functions
Alternate function
SPI1_NSS, I2S1_WS, TIM14_CH1, TSC_G2_IO1, USART2_CK USB_NOE
SPI1_SCK, I2S1_CK, CEC, TIM2_CH1_ETR, TSC_G2_IO2
SPI1_MISO, I2S1_MCK, TIM3_CH1, TIM1_BKIN, TIM16_CH1, TSC_G2_IO3, EVENTOUT
SPI1_MOSI, I2S1_SD, TIM3_CH2, TIM14_CH1, TIM1_CH1N, TIM17_CH1, TSC_G2_IO4, EVENTOUT
TIM3_CH3, TIM1_CH2N, TSC_G3_IO2, EVENTOUT
TIM3_CH4, TIM14_CH1, TIM1_CH3N, TSC_G3_IO3
TSC_G3_IO4
SPI2_SCK, CEC, TSC_SYNC, TIM2_CH3, I2C1_SCL
TIM2_CH4, EVENTOUT, I2C1_SDA
Ground
Digital power supply
TIM1_BKIN, SPI2_NSS, EVENTOUT
Pin functions
Alternate function
SPI2_SCK, TIM1_CH1N, I2C1_SCL
SPI2_MISO, TIM1_CH2N, I2C1_SDA
SPI2_MOSI, TIM1_CH3N
USART1_CK, TIM1_CH1, EVENTOUT, MCO, CRS_SYNC
USART1_TX, TIM1_CH2, TSC_G4_IO1, I2C1_SCL
USART1_RX, TIM1_CH3, TIM17_BKIN, TSC_G4_IO2, I2C1_SDA
CAN_RX, USART1_CTS, TIM1_CH4, COMP1_OUT, TSC_G4_IO3, EVENTOUT, I2C1_SCL
CAN_TX,USART1_RTS, TIM1_ETR, TSC_G4_IO4, EVENTOUT,
IR_OUT, SWDIO USB_NOE
Ground
Digital power supply
Pin functions
Alternate function
USART2_TX, SWCLK
SPI1_NSS, I2S1_WS, USART2_RX, TIM2_CH1_ETR, EVENTOUT, USB_NOE
SPI1_SCK, I2S1_CK, TIM2_CH2, TSC_G5_IO1, EVENTOUT
SPI1_MISO, I2S1_MCK, TIM17_BKIN, TIM3_CH1, TSC_G5_IO2, EVENTOUT
SPI1_MOSI, I2S1_SD, I2C1_SMBA, TIM16_BKIN, TIM3_CH2
I2C1_SCL, USART1_TX, TIM16_CH1N, TSC_G5_I03
I2C1_SDA, USART1_RX, USART4_CTS, TIM17_CH1N, TSC_G5_IO4
-
I2C1_SCL, CEC, TIM16_CH1, TSC_SYNC, CAN_RX

I2C1_SCL, CEC, TIM16_CH1, TSC_SYNC, CAN_RX
Pin functions
Alternate function
SPI2_NSS, I2C1_SDA, IR_OUT, TIM17_CH1, EVENTOUT, CAN_TX
Ground
Digital power supply

Additional functions
WKUP2, RTC_TAMP1, RTC_TS, RTC_OUT
OSC32_IN
OSC32_OUT
OSC_IN
OSC_OUT
RTC_ TAMP2, WKUP1, ADC_IN0,
ADC_IN1
ADC_IN2, WKUP4
ADC_IN3
Additional functions
ADC_IN4
ADC_IN5
ADC_IN6
ADC_IN7
ADC_IN8
ADC_IN9
-
-
-
-
Additional functions
-
-
WKUP7, RTC_REFIN
-
-
-
USB_DM
USB_DP
-
Additional functions
-
-
-
-
WKUP6
-
-
Boot memory selection
Boot memory selection

-
Additional functions
-