



Technical Safety Concept Lane Assistance

Document Version: [Version]
Template Version 1.0, Released on 2017-06-21



Document history

[Instructions: Fill in the date, version and description fields. You can fill out the Editor field with your name if you want to do so. Keep track of your editing as if this were a real world project.

For example, if this were your first draft or first submission, you might say version 1.0. If this is a second submission attempt, then you'd add a second line with a new date and version 2.0]

Date	Version	Editor	Description
5 May 2018	1.0	Jiho Choi	First draft

Table of Contents

[Instructions: We have provided a table of contents. If the table of contents is not showing up correctly in your word processor of choice, please update it. The table of contents should show each section of the document and page numbers or links. Most word processors can do this for you. In Google Docs, you can use headings for each section and then go to Insert > Table of Contents. Microsoft Word has similar capabilities]

Document history

Table of Contents

Purpose of the Technical Safety Concept

Inputs to the Technical Safety Concept

Functional Safety Requirements

Refined System Architecture from Functional Safety Concept

Functional overview of architecture elements

Technical Safety Concept

Technical Safety Requirements

Refinement of the System Architecture

Allocation of Technical Safety Requirements to Architecture Elements

Warning and Degradation Concept

Purpose of the Technical Safety Concept

[Instructions: Answer what is the purpose of a technical safety concept?]

This technical safety concept is to turn functional safety requirements into technical safety requirements and to allocate technical safety requirements to the system architecture.

Inputs to the Technical Safety Concept

Functional Safety Requirements

[Instructions: Provide the functional safety requirements derived in the functional safety concept]

ID	Functional Safety Requirement	A S I L	Fault Tolerant Time Interval	Safe State
Functional Safety Requirement 01-01	The Lane Departure Warning item shall ensure that the lane departure oscillating torque amplitude is below Max_Torque_Amplitude.	С	50 ms	Vibration torque amplitude below Max_Torque_Am plitude.
Functional Safety Requirement 01-02	The Lane Departure Warning item shall ensure that the lane departure oscillating torque frequency is below Max_Torque_Frequency.	С	50 ms	Vibration frequency is below Max_Torque_Fre quency.
Functional Safety Requirement 02-01	The electronic power steering ECU shall ensure that the Lane Keeping Assistance torque is applied only Max_Duration.	В	500 ms	Lane Keeping Assistance torque is zero.

Refined System Architecture from Functional Safety Concept

CAMERA SUBSYSTEM

CAMERA SENSOR

OM

DRIVER STEERING
TORQUE SENSOR

CAR DISPLAY
ECU

LANE
SENSING
FINAL TORQUE
SENSING
TORQUE
SENSING

OM

CAR DISPLAY

LANE
SERVING

CAR DISPLAY

LANE
STEERING
STEERING
TORQUE
ASIL C

ASIL C

ASIL C

TORQUE
STEERING
TORQUE
ASIL C

ASIL C

TORQUE
STEERING
TORQUE
ASIL C

ASIL C

TORQUE
STEERING
TORQUE
ASIL C

ASIL C

TEEM BOUNDARY

[Instructions: Provide the refined system architecture from the functional safety concept]

Functional overview of architecture elements

[Instructions: Provide a description for each functional safety element; what is each element's purpose in the lane assistance item?]

Element	Description
Camera Sensor	A sensor capturing optical images and providing them to the Camera Sensor ECU.
Camera Sensor ECU - Lane Sensing	A module detecting the lane line positions from the Camera Sensor images.
Camera Sensor ECU - Torque request generator	A module calculating the necessary torque to be requested to the Electronic Power Steering ECU.
Car Display	Display warning for the driver.
Car Display ECU - Lane Assistance On/Off Status	A module indicating the on/off status of the Lane Assistance functionality
Car Display ECU - Lane Assistant	A module indicating if the Lane Assistance

Active/Inactive	functionality is active or inactive.
Car Display ECU - Lane Assistance malfunction warning	A module indicating malfunction on the Lane Assistance functionality.
Driver Steering Torque Sensor	A sensor measuring the torque applied to the steering wheel by the driver.
Electronic Power Steering (EPS) ECU - Driver Steering Torque	A module receiving the driver's torque request from the steering wheel.
EPS ECU - Normal Lane Assistance Functionality	A module receiving the Camera Sensor ECU torque request.
EPS ECU - Lane Departure Warning Safety Functionality	A module ensuring the torque amplitude is below Max_Torque_Amplitude and torque frequency is below Max_Torque_Frequency.
EPS ECU - Lane Keeping Assistant Safety Functionality	A module ensuring the Lane Keeping Assistance functionality application is not activate more than Max_duration time.
EPS ECU - Final Torque	A module combining the torque request from the Lane Keeping and Lane Departure Warning functionalities and sends them to the Motor.
Motor	A motor applying the required torque to the steering wheels.

Technical Safety Concept

Technical Safety Requirements

[Instructions: Fill in the technical safety requirements for the lane departure warning first functional safety requirement. We have provided the associated functional safety requirement in the first table below. Hint: The technical safety requirements were discussed in the lesson videos. The architecture allocation column should contain element names such as LDW Safety block, Data Transmission Integrity Check, etc. Allocating the technical safety requirements to the "EPS ECU" does not provide enough detail for a technical safety concept.]

Lane Departure Warning (LDW) Requirements:

Functional Safety Requirement 01-01 with its associated system elements (derived in the functional safety concept)

ID	Functional Safety Requirement	Electronic Power Steering ECU	Camera ECU	Car Display ECU
Functional Safety Requirement 01-01	The lane keeping item shall ensure that the lane departure oscillating torque amplitude is below Max_Torque_Amplitude	X		

Technical Safety Requirements related to Functional Safety Requirement 01-01 are:

ID	Technical Safety Requirement	A S I L	Fault Tolerant Time Interval	Architecture Allocation	Safe State
Technical Safety Requirem ent 01	The LDW safety component shall ensure that the amplitude of the LDW_Torque_Request sent to the Final Electronic Power Steering Torque component is below Max_Torque_Amplitude	С	50 ms	LDW Safety	Lane Departure Warning torque to zero.
Technical Safety Requirem ent 02	As soon as the LDW function deactivates the LDW feature, the LDW Safety software block shall send a signal to the car display ECU to turn on a warning light	С	50 ms	LDW Safety	Lane Departure Warning torque to zero.
Technical Safety Requirem ent 03	As soon as a failure is detected by the LDW function, it shall deactivate the LDW feature and the LDW_Torque_Request shall be set to zero	С	50 ms	LDW Safety	Lane Departure Warning torque to zero.
Technical Safety Requirem ent 04	The validity and integrity of the data transmission for LDW_Torque_Request signal shall be ensured	С	50 ms	Data Transmission Integrity Check	Lane Departure Warning torque to zero.
Technical	Memory test shall be conducted	Α	Ignition	Memory Test	Lane

[Instructions: Fill in the technical safety requirements for the lane departure warning second functional safety requirement. We have provided the associated functional safety requirement in the table below. Hint:. Most of the technical safety requirements will be the same. At least one technical safety requirement will have to be slightly modified because we are talking about frequency instead of amplitude. These requirements were not given in the lessons]

Functional Safety Requirement 01-2 with its associated system elements (derived in the functional safety concept)

ID	Functional Safety Requirement	Electronic Power Steering ECU	Camera ECU	Car Display ECU
Functional Safety Requirement 01-02	The lane keeping item shall ensure that the lane departure oscillating torque frequency is below Max_Torque_Frequency	X		

Technical Safety Requirements related to Functional Safety Requirement 01-02 are:

ID	Technical Safety Requirement	A S I L	Fault Tolerant Time Interval	Architecture Allocation	Safe State
Technical Safety Requirement 01	The Lane Departure Warning safety component shall ensure the frequency of the 'LDW_Torque_Reques' sent to the 'Final electronic power steering Torque' component is below 'Max_Torque_Frequency.'	С	50 ms	LDW Safety	Lane Departu re Warning torque to zero.

Technical Safety Requirement 02	When a failure is detected by the LDW function, it shall deactivate the LDW feature and the 'LDW_Torque_Request' shall be set to zero.	С	50 ms	LDW Safety	Lane Departu re Warning torque to zero.
Technical Safety Requirement 03	When the LDW function deactivates the LDW feature, the 'LDW Safety' software block shall send a signal to the car display ECU to turn on a warning light.	С	50 ms	LDW Safety	Lane Departu re Warning torque to zero.
Technical Safety Requirement 04	The validity and integrity of the data transmission for 'LDW_Torque_Request' signal shall be ensured.	С	50 ms	Data Transmission Integrity Check	Lane Departu re Warning torque to zero.
Technical Safety Requirement 05	Memory test shall be conducted at start up of the EPS ECU to check for any memory problems	А	Ignition cycle	Memory Test	Lane Departu re Warning torque to zero.

Lane Departure Warning (LDW) Verification and Validation Acceptance Criteria:

[OPTIONAL: For each technical safety requirement, identify both the verification and validation acceptance criteria. "Validation" asks whether or not you chose the appropriate parameters. "Verification" involves testing to make sure the vehicle behaves as expected when the parameter value is crossed. There is not necessarily one right answer. Look at your verification and validation acceptance criteria from the functional safety concept for inspiration.]

Lane Keeping Assistance (LKA) Requirements:

[Instructions: Fill in the technical safety requirements for the lane keeping assistance functional safety requirement 02-01. We have provided the associated functional safety requirement in the table below. Hint:. You can reuse the technical safety requirements from functional safety requirement 01-01. But you need to change the language because we are now looking at a different system. The ASIL and Fault Tolerant Time Interval are different as well.]

Functional Safety Requirement 02-1 with its associated system elements (derived in the functional safety concept)

ID	Functional Safety Requirement	Electronic Power Steering ECU	Camera ECU	Car Display ECU
Functional Safety Requirement 02-01	The lane keeping item shall ensure that the lane keeping assistance torque is applied for only Max_Duration	X		

Technical Safety Requirements related to Functional Safety Requirement 02-01 are:

ID	Technical Safety Requirement	A S I L	Fault Tolerant Time Interval	Allocation to Architecture	Safe State
Technical Safety Requireme nt 01	The Lane Keeping Assistance safety component shall ensure the duration of the lane keeping assistance torque is applied for less than Max_Duration	С	500 ms	LKA Safety	Lane Keeping Assistance torque to zero.
Technical Safety Requireme nt 02	When the Lane Keeping Assistance function deactivates, the 'LKA Safety' shall send a signal to the Car Display ECU to turn on a warning light.	С	500 ms	LKA Safety	Lane Keeping Assistance torque to zero.
Technical Safety Requireme nt 03	When a failure is detected, the Lane Keeping Assistance function shall deactivate and the 'LKA_Torque_Request' shall be zero.	С	500 ms	LKA Safety	Lane Keeping Assistance torque to zero.
Technical	The validity and integrity of the	С	500 ms	LKA Safety	Lane


Safety Requireme nt 04	data transmission for 'LKA_Torque_Request' signal shall be ensured.				Keeping Assistance torque to zero.
Technical Safety Requireme nt 05	Memory test shall be conducted at start up of the EPS ECU to check for any memory problems	A	Ignition cycle	Data Transmission Integrity Check	Lane Departure Warning torque to zero.

Lane Keeping Assistance (LKA) Verification and Validation Acceptance Criteria:

[OPTIONAL: For each technical safety requirement, identify both the verification and validation acceptance criteria. "Validation" asks whether or not you chose the appropriate parameters. "Verification" involves testing to make sure the vehicle behaves as expected when the parameter value is crossed. There is not necessarily one right answer. Look at your verification and validation acceptance criteria from the functional safety concept for inspiration.]

Refinement of the System Architecture

[Instructions: Include the refined system architecture. Hint: The refined system architecture should include the system architecture from the end of the technical safety lesson, including all of the ASIL labels.]



Allocation of Technical Safety Requirements to Architecture Elements

[Instructions: We already included the allocation as part of the technical requirement tables. Here you can state that for this particular item, all technical safety requirements are allocated to the Electronic Power Steering ECU]

All technical safety requirements were allocated to the Electronic Power Steering ECU.

Warning and Degradation Concept

[Instructions: We've already identified that for any system malfunction, the lane assistance functions will be turned off and the driver will receive a warning light indication. The technical safety requirements have not changed how functionality will be degraded or what the warning will be.

So in this case, the warning and degradation concept is the same for the technical safety requirements as for the functional safety requirements. You can copy the functional safety warning and degradation concept here.

Oftentimes, a technical safety analysis will lead to a more detailed warning and degradation concept.]

ID	Degradation Mode	Trigger for Degradation Mode	Safe State invoked?	Driver Warning
WDC-01	Turn off Lane Departure Warning functionality	Malfunction_01	Yes	Lane Departure Warning Malfunction Warning on Car Display
WDC-02	Turn off Lane Departure Warning functionality	Malfunction_02	Yes	Lane Departure Warning Malfunction Warning on Car Display
WDC-03	Turn off Lane Keeping Assistance functionality	Malfunction_03	Yes	Lane Keeping Assistance Malfunction Warning on Car Display
WDC-04	Turn off Lane Departure Warning	Malfunction_04	Yes	Lane Departure Warning Malfunction

	functionality			Warning on Car Display
WDC-05	Turn off Lane Keeping Assistance functionality	Malfunction_05	Yes	Lane Keeping Assistance Malfunction Warning on Car Display