1027 PRINTER FUNCTION TEST, PASS # 1

STANDARD CHAR SET

 $!"#$%&'()*+,-./0123456789:;<=>?@ABCDEFGHIJKLMNOPQRSTUVWXYZ[\]^_`abcdefghijklmnopqrstuvwxyz{|}~$

INTERNATIONAL CHAR SET

áùÑÉçôòì£ïüäÖúÜâûîéèñêåàÅ- $^\neg$ ® !"#\$%&'()*+,-./0123456789:;<=>?@ABCDEFGHIJKLMNOPQR STUVWXYZ[\]^_`abcdefghijklmnopqrstuvwxyzÄ|}~

STANDARD CHAR SET WITH UNDER-LINE

_!"#\$%&'()*+,-./0123456789:;<=>?@ABCDEFGHIJKLMNOPQRSTUVWXYZ[\]^ `abcdefghijklmno
pgrstuvwxyz{|}~

DIRECTION PRINT CHECK

END OF TEST

1027 PRINTER FUNCTION TEST, PASS # 2

STANDARD CHAR SET

!"#\$%&'()*+,-./0123456789:;<=>?@ABCDEFGHIJKLMNOPQRSTUVWXYZ[\]^_`abcdefghijklmno
pqrstuvwxyz{|}~

INTERNATIONAL CHAR SET

áùÑÉçôòì£ïüäÖúÜâûîéèñêåàÅ- $^-$ ¨ !"#\$%&'()*+,-./0123456789:;<=>?@ABCDEFGHIJKLMNOPQR STUVWXYZ[\]^_`abcdefghijklmnopqrstuvwxyzÄ|}~

STANDARD CHAR SET WITH UNDER-LINE

!"#\$%&'()*+,-./0123456789:;<=>?@ABCDEFGHIJKLMNOPQRSTUVWXYZ[\]^ `abcdefghijklmno
pqrstuvwxyz{|}~

DIRECTION PRINT CHECK

12345678901234567890123456789012345678901234567890123456789012345678901234567890

END OF TEST