
OKAWA Electric Design

Home > Tools > Filters > RC Low-pass Filter Design Tool > Result

RC Low-pass Filter Design Tool - Result -

Calculated the Transfer Function for the RC Low-pass filter, displayed on graphs, showing Bode diagram, Nyquist diagram, Impulse response and Step response.



Transfer Function:

$$G(s) = \frac{45454.5454545}{s + 45454.545454545}$$

Cut-off frequency fc = 7234.31559509[Hz]



CR Filter

Rise/Fall time of step response
$$R = 2200 \qquad \Omega \quad C = \\ 1.0E-8 \qquad F \\ Stead-state value: 0 \qquad \% \rightarrow 90 \qquad \% \\ Calculate \\ tr = 5.06568720459E-5 \qquad [sec]$$

```
Pole(s)
 p = -7234.31559509[Hz]
     |p| = 7234.31559509[Hz]
```

Phase margin pm = NAN[deg] (f=0[Hz])

The system does not oscillate.

Overshoot (in absolute value) The peak of transient waveform is not detected.

Final value of the step response (on the condition that the system converged when t goes to infinity)

stem converged when t goes to infinity)
$$g(\infty) = 1$$

C= .01u F R= 2.2k

p:pico, n:nano, u:micro, k:kilo, M:mega

Bode diagram Nyquist diagram($f = 0 \rightarrow \infty$)

Frequency analysis

Pole, zero Phase margin Oscillation analysis

Transient analysis


Step response Impulse response

Overshoot


Final value of the step response

Calculate

Frequency analysis




NyquistDiagram




(c)okawa-denshi.jp

Transient analysis


StepResponse





(c)okawa-denshi.jp

ImpulseResponse



(c)okawa-denshi.jp

Top

◆Suggestion box

We'll use your suggestion to improve site quality in future.

Submit

◆Suggestion box

We'll use your suggestion to improve site quality in future.

Disclaimer

4 Submit

©2011 **OKAWA** Electric Design