

# Padbot Kids Robot T2

User Manual


---

# T2 Table of Contents


|                                    |    |
|------------------------------------|----|
| 1. Product Overview .....          | 1  |
| 2. Robot Charging .....            | 2  |
| 3. Power On and Usage .....        | 3  |
| 4. Robot Software User Guide ..... | 4  |
| 5. Robot Functions .....           | 7  |
| 6. Padbot App User Guide .....     | 9  |
| 7. Notes .....                     | 16 |
| 8. After-sales Services .....      | 17 |
| 9. Warranty .....                  | 19 |
| 10. Maintenance Records .....      | 20 |

# T2 Product Overview

## Product Composition



## Accessories



|                     |                               |
|---------------------|-------------------------------|
| Size (W*H*L)        | 16.5*22.5*22 cm               |
| Screen Size         | 5 Inch                        |
| Resolution Ratio    | 800*480                       |
| N.W.                | 1.68 Kg                       |
| Battery Capacity    | 5200 mAh                      |
| Charging Input      | DC 5V                         |
| Charging Time       | 2 H                           |
| Running Time        | 6 H                           |
| Standby Time        | 18 H                          |
| Working Temperature | 20°C ~ 40°C                   |
| Processor           | Quad-core Cortex™-A7          |
| Camera              | 230-degree wide-angle HD 720P |

Note: Please turn on the power switch first, then press and hold the front switch button to turn on the device.


# T2 Robot Charging

## Charging

This product has a built-in lithium battery. Please charge the robot before first use to ensure normal operation.

### Charging Methods:

Connect the charger directly to the robot's charging port.




Charging Port

## T2 Powering On and Usage

### Powering On the Robot


#### 1. Power Switch

The power switch is located at the bottom of the robot. Turn on the power switch, the robot will power on and the screen will light up.



#### 2. Main Switch

The main switch is located at the front of the robot. Pressing it once will turn off the screen; pressing and holding it will bring up the "Restart" option.



### ■ Power On/Off

**Power On:** Slide the switch on the bottom of the robot to ON, and press and hold the round switch on the chest for 3 seconds to turn it on.

**Power Off:** Press and hold the round switch on the chest of the robot for 2 seconds, and the screen of the robot will pop up the word shutdown, click this word to shut down. When the robot is not used for a long time, it is recommended to switch the bottom switch of the robot to OFF.

### ■ Contact Internet (Wi-Fi connection only)

After the robot is turned on successfully for the first time, click other parts of the robot screen except the eyes and mouth, then click the word Wi-Fi on the upper right of the screen to enter the networking list, select the correct wireless network and complete the connection. After being connected to the Internet, the robot can have more interesting experiences.

### ■ Voice Interaction

After the robot is connected to the Internet, it will enter the voice chat interface (the main interface of the robot) by default after returning, and can directly chat with the robot without a wake-up word.

### ■ Dormant State

Quickly press the circular switch on the chest of the robot to enter/exit the dormant state.

### ■ Pause / Terminate Button

Pause Button: Tap the lower part of the robot's head for one second to activate, and the current task can be paused.

Terminate Button: Tap the lower part of the robot's head for three seconds to wake it up, and you can exit the current task and return to the robot's voice chat interface.

### ■ Volume Up / Down

Method 1: Press the volume plus/minus button on the back of the robot's head to adjust the volume.

Method 2: Use voice commands (turn up/down, turn up/down the volume) to adjust the volume.

### ■ Charging

Use the manual charger provided with the product and plug it into a power socket for charging.


(Note: When the circular switch light ring on the chest is working normally, the brightness gradually changes over time, showing a breathing effect, and it changes to a slow flashing state when charging.)

### ■ Battery

This product uses an inductive battery. Buyers can purchase a larger capacity battery from our company for replacement according to their own needs.

## Robot Dance

1. on the voice dialogue interface, users can swipe right on the screen to access the fun game feature.
2. Users can feed the robot, make it dance, video chat with friends and family, take photos, and play puzzle games.





## T2 Robot Functions

### Eating

Setting mealtime in APP or use voice instruction “have a meal, eat, eat a meal, eat something” to enter into eating status.  
After the robot enters the eating page, the user needs to drag the food on the expression with the finger and put it into the robot's mouth. After the robot is full and completes the relevant actions, it will automatically exit the eating page.



### Sleeping

Setting sleeping time in APP or use voice instruction “go to sleep, sleep, do not speak” to turn into sleeping mode.  
Robot will go sleeping after yawning expression, and extinguish screen for a while.  
When the surrounding sound is noisy, the robot will cry. If the user taps the groove on the robot's head three times in a row, the robot's cry will become softer; if the user taps the groove on the robot's head six times in a row, the robot will stop crying.  
When the user lifts the robot, the robot will display an angry expression.



### Get Up

Set the wake-up time through the APP or use voice commands to enter the settings.  
Voice command: "Get up, Wake up" to wake robot up. And robot only react this emoji during sleeping status.  
By using voice instructions “get up, wake up, get out of bed”, robot will wake up instantly.



### Rolling Over、Lying Down、Lean Back、Lifting Up and Shaking

When you placing robot in such status, robot will react accordingly, and will say thank you when you place it upright.

### Screen Interaction

Touch the robot's eyes, face, and mouth, and the robot will show different reactions; if the robot is talking, the user can click other parts of the robot screen except for the eyes, face, and mouth to interrupt the robot's speech.

### Music

Play a song at random: "Sing a song"

Play a specified type of song: "Play a nursery rhyme"

play the specified song: "Play happy new year"

### Weather

Check the current city's weather: "what's the weather like"

Check the weather in a given city: "what's the weather like in Guangzhou"

View the weather at a specified time: "How's the weather like today/how's the weather like tomorrow/ how's the weather like the day after tomorrow"

View the weather in a specified city at a specified time: "What will be the weather in Beijing tomorrow"

### Touch Head Sensor

Touch the groove of the robot's head for one second and lift it up to pause the current task.

Touch the groove on the robot's head for three seconds and lift it up to exit the current task and enter the robot voice chat interface.

If the robot is touched on the head without executing any commands, there will be happy movements.

### Command Instructions

Motion: "Smile", "Forward", "Back", "Head up", "Down", "Fart", "Shake", "Nod", "Check battery", "Turn left", "Turn right", "Photograph", "Shutdown" and so on.

### Dance

Random Dance: "Dance"

### Story

Play a story randomly: "Tell a story"

### Joke

Play a joke randomly: "Tell a joke"

## Download & Installation

### Download Padbot App for iOS

Method 1: Search "padbot t2" in your AppStore and download/install.

Method 2: Scan the QR code below to download and install.



iOS

### Download Padbot App for Android

Method 1: Search "padbot t2" in your app store and download/install.



Method 2: Scan the QR code below to download and install.



Android

## Binding the Robot


After registering and logging in, bind the robot by scanning the QR code displayed on the robot. The first user to bind becomes the Super Administrator.



# T2 PadBot App User Guide

## Robot Homepage


The Robot Homepage displays the robot's status and is the entry point for configuring business functions.




# T2 PadBot App User Guide

## Two-Way Video Control

1. On the robot list page in PadBot T2 App, click the "Call" button to send a face-to-face video call request to the robot. After the robot automatically connects, you can have a remote video call and control the robot's movement.




2. The video interface allows control of the robot's chassis and head movement.




# T2 PadBot App User Guide

## Habits


1. On the robot's home page, click "Habits" to go to the habits page, where you can set the time for your habits.



2. Users can set up reminders on the robot to help children develop consistent habits such as "getting up," "brushing teeth," and "drinking water."




3. By selecting a specific time, users can set a reminder for the robot to notify them when that time arrives.




# T2 PadBot App User Guide

## Limits


1. On the robot's homepage, click “Limits” to go to the Limits page, where you can set the amount of time your child can use the robot.



2. Users can set limits on how long their children can use the robot, such as daily usage windows, session duration, and rest intervals.



3. By selecting a time slot, users can set a time limit for their children to use the robot.







# T2 PadBot App User Guide

## Lock


1. On the robot's homepage, click "Lock" to prevent the robot from performing any actions.



2. Once you select "Lock," the robot will be temporarily disabled until it is unlocked.



3. The robot has been disabled. Users can click "Unlock" to reactivate it.



Before using this product, please read the product manual and the safety precautions mentioned below in detail. Any operation inconsistent with the content of the manual may cause damage to the product.

1. Please place the robot on a flat ground or table for motion-related operations. When it is close to the edge of the table, please keep the robot's motion direction perpendicular to the edge of the table.
2. Do not move the head of the robot artificially, which may cause damage to the robot.
3. Do not let the robot or the adapter come into contact with oil, water and other substances, and do not place the robot in a damp place, otherwise it will easily cause a short circuit in the internal circuit of the robot.
4. Keep away from any fire source and high temperature power supply.
5. This product can only be charged with the adapter provided by our company, and do not use this adapter for other products to avoid danger.
6. Please regularly check whether the adapter, wire, robot shell, panel and other parts are damaged, and stop using it immediately if any damage is found.
7. When the robot breaks down, do not repair it by yourself. Please call our after-sales department for assistance.

## T2 After-sales Services

1. Within one year from the date of purchase of the robot, if there is a performance failure that is not caused by man-made damage, consumers can enjoy free repair services at the repair point with the invoice and three-guarantee certificate.
2. Within 15 days from the date of purchase of the robot, if there is a performance failure that is not caused by man-made damage, the consumer can replace the same robot for free at the original place of purchase with the invoice and the three-guarantee certificate.
3. Within seven days from the date of purchase of the robot, if there is a performance failure that is not caused by man-made damage, consumers can return and exchange the robot for free at the original place of purchase with the invoice and three-guarantee certificate.
4. During the three-guarantee period of the robot accessories, if there is a performance failure that is not caused by man-made damage, consumers can replace the new robot accessories for free at the original place of purchase with the invoice and the three-guarantee certificate. (Battery within six months)

## T2 After-sales Services

**If the robot and accessories have the following conditions, the three guarantees will not be implemented, and repairs will be charged:**

- beyond the validity period of the three guarantees,
- there is no valid invoice and three guarantees certificate,
- the content on the three guarantees certificate does not match the physical identification of the product or has been altered,
- not according to the instructions Damage caused by use/maintenance/maintenance or broken, shattered, etc.

After the user purchases the machine, please fill in all the information on the three-guarantee certificate completely, and it will take effect only after being stamped by the sales unit, and the three-guarantee certificate must not be altered, otherwise it will be invalid.

During the validity period of the three guarantees, consumers can enjoy free repair or return and exchange services in accordance with these regulations. All products of the company provide lifetime maintenance service.

## T2 Warranty

|               |  |                |  |
|---------------|--|----------------|--|
| User Name     |  | Phone Number   |  |
| Zip Code      |  | Invocie Number |  |
| User Adress   |  |                |  |
| Robot Model   |  |                |  |
| Model Code    |  |                |  |
| Vending Unit  |  |                |  |
| Sales Address |  |                |  |
| Sales Date    |  |                |  |

| Repair Date | Fault Description | Processing | Staff | Unit Stamp |
|-------------|-------------------|------------|-------|------------|
|             |                   |            |       |            |
|             |                   |            |       |            |
|             |                   |            |       |            |
|             |                   |            |       |            |
|             |                   |            |       |            |
|             |                   |            |       |            |
|             |                   |            |       |            |
|             |                   |            |       |            |
|             |                   |            |       |            |
|             |                   |            |       |            |
|             |                   |            |       |            |

## Contact Us

Guangdong Padbot Robotics Ltd

Website: [www.padbot.com](http://www.padbot.com)

Email: [padbot@inbot.cn](mailto:padbot@inbot.cn)

Company Tel: 020-38456676 Sales Inquiry: 020-38456676 Ext.2

Guangzhou HQ: Building B8, No. 2 Tengfei 2nd Street, Sino-Singapore Guangzhou Knowledge City, Huangpu District, Guangdong Province.



TikTok



YouTube



Official Website

Due to technical upgrades, customer requirements, or other reasons, product configurations, images, and technical data may change without prior notice. The company is not responsible for inaccuracies or printing errors resulting from such product upgrades or changes.