

JK Flip-Flop in permanent toggle mode.

- HIGH is connected to J and K inputs
- Positive edge of CLK signal triggers