

A 1µA, +2V to +27V SOT23 Precision Current-Sense Amplifier

FEATURES

- Improved Electrical Performance over the MAX9938 and the MAX9634
- ♦ Ultra-Low Supply Current: 1µA
- ♦ Wide Input Common Mode Range: +2V to +27V
- ♦ Low Input Offset Voltage: 100µV (max)
- ♦ Low Gain Error: <0.5%(max)
- ♦ Voltage Output
- ♦ Four Gain Options Available:

TS1100-25: Gain = 27V/V TS1100-50: Gain = 50V/V

TS1100-100: Gain = 100V/V TS1100-200: Gain = 200V/V

♦ 5-Pin SOT23 Packaging

APPLICATIONS

Notebook Computers Current-Shunt Measurement Power Management Systems Battery Monitoring Motor Control Load Protection Smart Battery Packs/Chargers


DESCRIPTION


The voltage-output TS1100 current-sense amplifiers are form-factor identical and electrical improvements to the MAX9938 and the MAX9634 current-sense amplifiers. Consuming a very low 1 μ A supply current, the TS1100 high-side current-sense amplifiers exhibit a 100- μ V (max) Vos and a 0.5% (max) gain error, both specifications optimized for any precision current measurement. For all high-side current-sensing applications, the TS1100 features a wide input common-mode voltage range from 2V to 27V.

The SOT23 package makes the TS1100 an ideal choice for pcb-area-critical, low-current, high-accuracy current-sense applications in all battery-powered, remote or hand-held portable instruments.

All TS1100s are specified for operation over the -40°C to +105°C extended temperature range.

TYPICAL APPLICATION CIRCUIT





PART	GAIN OPTION	
TS1100-25	25 V/V	
TS1100-50	50 V/V	
TS1100-100	100 V/V	
TS1100-200	200 V/V	




ABSOLUTE MAXIMUM RATINGS

RS+, RS- to GND	0.3V to +27V
OUT to GND	0.3V to +6V
RS+ to RS	±28V
Short-Circuit Duration: OUT to GND	Continuous
Continuous Input Current (Any Pin)	±20mA
Continuous Power Dissipation (T _A = +70°C	C)
5-Pin SOT23 (Derate at 3.9mW/°C above	re +70°C) 312mW

Operating Temperature Range	-40°C to +	105°C
Junction Temperature	+	150°C
Storage Temperature Range	-65°C to +	150°C
Lead Temperature (Soldering, 10s)	+	300°C
Soldering Temperature (Reflow)	+	260°C

Electrical and thermal stresses beyond those listed under "Absolute Maximum Ratings" may cause permanent damage to the device. These are stress ratings only and functional operation of the device at these or any other condition beyond those indicated in the operational sections of the specifications is not implied. Exposure to any absolute maximum rating conditions for extended periods may affect device reliability and lifetime.

PACKAGE/ORDERING INFORMATION



Lead-free Program: Silicon Labs supplies only lead-free packaging.

Consult Silicon Labs for products specified with wider operating temperature ranges.

Page 2 TS1100 Rev. 1.1



ELECTRICAL CHARACTERISTICS

 $V_{RS+} = V_{RS-} = 3.6V$; $V_{SENSE} = (V_{RS+} - V_{RS-}) = 0V$; $C_{OUT} = 47nF$; $T_A = -40^{\circ}C$ to $+105^{\circ}C$, unless otherwise noted. Typical values are at $T_A = +25^{\circ}C$. See Note 1

PARAMETER	SYMBOL	CONDITIONS			MIN	TYP	MAX	UNITS	
	Icc	T _A = +25°C			0.68	0.85	μΑ		
Supply Current (Note 2)							1.0		
		V _{RS+} = 25V	$T_A = +25$	5°C			1.0		
		V _{RS+} = 23 V				1.2			
Common-Mode Input Range	V_{CM}	Guaranteed by	CMRR		2		27	V	
Common-Mode Rejection Ratio	CMRR	2V < V _{RS+} < 27V			120	150		dB	
Input Offeet Voltage (Note 2)	Vos	$T_A = +25^{\circ}C$				±30	±100	μV	
Input Offset Voltage (Note 3)							±200		
Gain	G	TS1100-25				25		V/V	
		TS1100-50				50			
		TS1100-100				100			
		TS1100-200				200			
Gain Error (Note 4)	GE	$T_A = +25^{\circ}C$				±0.1	±0.5	%	
Gaill Ellor (Note 4)	GL						±0.6		
Output Posistance (Note 5)	R _{OUT}			TS1100-25/50/100	7.0	10	13.2	kΩ	
Output Resistance (Note 5)				TS1100-200	14.0	20	26.4		
	V _{OL}	Gain = 25					5		
OUT Low Voltage		Gain = 50				10	mV		
		Gain = 100				20			
		Gain = 200				40			
OUT High Voltage (Note 6)	V _{OH}	$V_{OH} = V_{RS-} - V_{OUT}$				0.05	0.2	V	
Output Settling Time	t _S	TS1100-25/50/1		6 final value,		2.2		ms	
Output Octuming Time	us.	TS1100-200 V _{SENSE} = 50mV				4.3		ms	

- Note 1: All devices are 100% production tested at T_A = +25°C. All temperature limits are guaranteed by product characterization.
- **Note 2:** Extrapolated to $V_{OUT} = 0$. Icc is the total current into the RS+ <u>and</u> the RS- pins.
- Note 3: Input offset voltage Vos is extrapolated from Vout with Vsense set to 1mV.
- Note 4: Gain error is calculated by applying two values for V_{SENSE} and then calculating the error of the actual slope vs. the ideal transfer characteristic:

For GAIN = 25, the applied V_{SENSE} is 20mV and 120mV.

For GAIN = 50, the applied V_{SENSE} is 10mV and 60mV.

For GAIN = 100, the applied V_{SENSE} is 5mV and 30mV.

For GAIN = 200, the applied V_{SENSE} is 2.5mV and 15mV.


Note 5: The device is stable for any capacitive load at V_{OUT} .


Note 6: V_{OH} is the voltage from V_{RS} to V_{OUT} with $V_{SENSE} = 3.6 \text{V/GAIN}$.




TYPICAL PERFORMANCE CHARACTERISTICS


 $V_{RS+} = V_{RS-} = 3.6V$; $T_A = +25$ °C, unless otherwise noted.









Input Offset Voltage vs Temperature




Gain Error Histogram



Input Offset Voltage vs Common-Mode Voltage



Supply Current vs Common-Mode Voltage





Page 4 TS1100 Rev. 1.1




TYPICAL PERFORMANCE CHARACTERISTICS

 $V_{RS+} = V_{RS-} = 3.6V$; $T_A = +25$ °C, unless otherwise noted.
















Small-Signal Gain vs Frequency



Common-Mode Rejection vs Frequency






TYPICAL PERFORMANCE CHARACTERISTICS


 $V_{RS+} = V_{RS-} = 3.6V$; $T_A = +25$ °C, unless otherwise noted.

Small-Signal Pulse Response, Gain = 50




200µs/DIV

Large-Signal Pulse Response, Gain = 50




200µs/DIV

Small-Signal Pulse Response, Gain = 25




200µs/DIV

Large-Signal Pulse Response, Gain = 25




200µs/DIV

Small-Signal Pulse Response, Gain = 100



200µs/DIV

Large-Signal Pulse Response, Gain = 100



200µs/DIV


Page 6 TS1100 Rev. 1.1



PIN FUNCTIONS

PIN	LABEL	FUNCTION			
SOT23	LADEL	FUNCTION			
5	RS+	External Sense Resistor Power-Side Connection			
4	RS-	External Sense Resistor Load-Side Connection			
1, 2	GND	Ground. Connect these pins to analog ground.			
3	OUT	Output Voltage. Vout is proportional to Vsense = Vrs+ - Vrs-			

BLOCK DIAGRAM



DESCRIPTION OF OPERATION

The internal configuration of the TS1100 - a unidirectional high-side, current-sense amplifier - is based on a commonly-used operational amplifier (op amp) circuit for measuring load currents (in one direction) in the presence of high-common-mode voltages. In the general case, a current-sense amplifier monitors the voltage caused by a load current through an external sense resistor and generates an output voltage as a function of that load current. Referring to the typical application circuit on Page 1, the inputs of the op-amp-based circuit are connected across an external RSENSE resistor that is used to measure load current. At the non-inverting input of the TS1100 (the RS+ terminal), the applied voltage is ILOAD x RSENSE. Since the RS- terminal is the non-inverting input of the internal op amp, op-amp feedback action forces the inverting input of the internal op amp to the same potential (ILOAD x RSENSE). Therefore, the voltage drop across RSENSE (VSENSE) and the voltage drop across RGAIN (at the RS+ terminal) are equal. To minimize any additional error because of op-amp input bias current mismatch, both RGAINS are the same value.

Since the internal p-channel FET's source is connected to the inverting input of the internal op amp and since the voltage drop across R_{GAIN} is the same as the external V_{SENSE} , op amp feedback action drives the gate of the FET such that the FET's drain-source current is equal to:

$$l_{DS} = \frac{V_{SENSE}}{R_{GAIN}}$$



or

$$I_{DS} = \frac{I_{LOAD} \times R_{SENSE}}{R_{GAIN}}$$

Since the FET's drain terminal is connected to R_{OUT} , the output voltage of the TS1100 at the OUT terminal is, therefore:

$$V_{OUT} = I_{LOAD} \times R_{SENSE} \times \frac{R_{OUT}}{R_{GAIN}}$$

The current-sense amplifier's gain accuracy is therefore the ratio match of R_{OUT} to $R_{\text{GAIN}}.$ For each of the four gain options available, Table 1 lists the values for R_{OUT} and $R_{\text{GAIN}}.$ The TS1100's output stage is protected against input overdrive by use of an output current-limiting circuit of 3mA (typical) and a 7V internal clamp protection circuit.

Table 1: Internal Gain Setting Resistors (Typical Values)

GAIN (V/V)	R _{GAIN} (Ω)	R _{OUT} (Ω)	Part Number
25	400	10k	TS1100-25
50	200	10k	TS1100-50
100	100	10k	TS1100-100
200	100	20k	TS1100-200

To achieve its very-low input offset voltage performance over temperature, VSENSE voltage, and power supply voltage, the design of the TS1100's amplifier is chopper-stabilized, a commonly-used technique to reduce significantly the input offset voltage of amplifiers. This method, however, does employ the use of sampling techniques and therefore residue of the TS1100's 10kHz internal clock is contained in the TS1100's output voltage spectrum.

APPLICATIONS INFORMATION

Choosing the Sense Resistor

Selecting the optimal value for the external RSENSE is based on the following criteria and for each commentary follows:

- 1) RSENSE Voltage Loss
- 2) V_{OUT} Swing vs. Applied Input Voltage at V_{RS+} and Desired V_{SENSE}
- 3) Total ILOAD Accuracy
- 4) Circuit Efficiency and Power Dissipation
- 5) RSENSE Kelvin Connections
- 6) Sense Resistor Composition

1) RSENSE Voltage Loss

For lowest IR voltage loss in RSENSE, the smallest usable value for RSENSE should be selected.

2) V_{OUT} Swing vs. Applied Input Voltage at V_{RS+} and Desired V_{SENSE}

As there is no separate power supply pin for the TS1100, the circuit draws its power from the applied voltage at both its RS+ and RS- terminals. Therefore, the signal voltage at the OUT terminal is bounded by the minimum supply voltage applied to the TS1100.

Therefore,

$$V_{OUT(max)} = V_{RS+(min)} - V_{SENSE(max)} - V_{OH(max)}$$

and

$$R_{SENSE} = \frac{V_{OUT} (max)}{GAIN \times I_{LOAD} (max)}$$

where the full-scale V_{SENSE} should be less than $V_{OUT(MAX)}/GAIN$ at the application's minimum RS+terminal voltage. For best performance with a 3.6V power supply, RSENSE should be chosen to generate a V_{SENSE} of: a) 120mV (for the 25V/V GAIN option), b) 60mV (for the 50V/V GAIN option), c) 30mV (for the 100V/V GAIN option), or d) 15mV (for the 200V/V GAIN option) at the full-scale $I_{LOAD(MAX)}$ current in each application. For the case where the minimum power supply voltage is higher than 3.6V, each of the four full-scale V_{SENSES} above can be increased.

3) Total ILOAD Accuracy

In the TS1100's linear region where $V_{OUT} < V_{OUT(MAX)}$, there are two specifications related to the circuit's accuracy: a) the TS1100's input offset voltage ($V_{OS} = 100\mu V$, max) and b) its gain error (GE(max) = 0.5%).

Page 8 TS1100 Rev. 1.1



An expression for the TS1100's total output voltage (+ error) is given by:

 $V_{OUT} = [GAIN x (1 \pm GE) x V_{SENSE}] \pm (GAIN x V_{OS})$

A large value for RSENSE permits the use of smaller load currents to be measured more accurately because the effects of offset voltages are less significant when compared to larger VSENSE voltages. Due care though should be exercised as previously mentioned with large values of RSENSE.

4) Circuit Efficiency and Power Dissipation

IR losses in RSENSE can be large especially at high load currents. It is important to select the smallest, usable RSENSE value to minimize power dissipation and to keep the physical size of RSENSE small. If the external RSENSE is allowed to dissipate significant power, then its inherent temperature coefficient may alter its design center value, thereby reducing load current measurement accuracy. Precisely because the TS1100's input stage was designed to exhibit a very low input offset voltage, small RSENSE values can be used to reduce power dissipation and minimize local hot spots on the pcb.

5) RSENSE Kelvin Connections

For optimal V_{SENSE} accuracy in the presence of large load currents, parasitic pcb track resistance should be minimized. Kelvin-sense pcb connections




Figure 1: Making PCB Connections to the Sense Resistor.

between RSENSE and the TS1100's RS+ and RS-terminals are strongly recommended. The drawing in Figure 1 illustrates the connections between the current-sense amplifier and the current-sense resistor. The pcb layout should be balanced and symmetrical to minimize wiring-induced errors. In addition, the pcb layout for RSENSE should include good thermal management techniques for optimal RSENSE power dissipation.

6) RSENSE Composition

Current-shunt resistors are made available in metal film, metal strip, and wire-wound constructions. Wire-wound current-shunt resistors are constructed with wire spirally wound onto a core. As a result, these types of current shunt resistors exhibit the largest self inductance. In applications where the load current contains high-frequency transients, metal film or metal strip current sense resistors are recommended.

Internal Noise Filter

power management and motor control applications, current-sense amplifiers are required to measure load currents accurately in the presence of both externally-generated differential and commonmode noise. An example of differential-mode noise that can appear at the inputs of a current-sense amplifier is high-frequency ripple. High-frequency ripple - whether injected into the circuit inductively or capacitively - can produce a differential-mode voltage drop across the external current-shunt resistor (RSENSE). An example of externallygenerated, common-mode noise is the highfrequency output ripple of a switching regulator that can result in common-mode noise injection into both inputs of a current-sense amplifier.

Even though the load current signal bandwidth is DC, the input stage of any current-sense amplifier can rectify unwanted, out-of-band noise that can result in an apparent error voltage at its output. This rectification of noise signals occurs because all amplifier input stages are constructed with transistors that can behave as high-frequency signal detectors in the same way pn-junction diodes were used as RF envelope detectors in early radio designs. Against common-mode injected noise, the amplifier's internal common-mode rejection is usually sufficient.

To counter the effects of externally-injected noise, it has always been good engineering practice to add external low-pass filters in series with the inputs of a current-sense amplifier. In the design of discrete current-sense amplifiers, resistors used in the external low-pass filters were incorporated into the circuit's overall design so errors because of any input-bias current-generated offset voltage errors and gain errors were compensated.

With the advent of monolithic current-sense amplifiers, like the TS1100, the addition of external



low-pass filters in series with the current-sense amplifier's inputs only introduces additional offset voltage and gain errors. To minimize or eliminate altogether the need for external low-pass filters and to maintain low input offset voltage and gain errors, the TS1100 incorporates a 50-kHz (typ), 2nd-order differential low-pass filter as shown in the TS1100's Block Diagram.

Optional Output Filter Capacitor

If the TS1100 is part of a signal acquisition system where its OUT terminal is connected to the input of an ADC with an internal, switched-capacitor track-and-hold circuit, the internal track-and-hold's sampling capacitor can cause voltage droop at Vout. A 22nF to 100nF good-quality ceramic capacitor from the OUT terminal to GND forms a low-pass filters with the TS1100's Rout and should be used to minimize voltage droop (holding Vout constant during the sample interval. Using a capacitor on the OUT terminal will also reduce the TS1100's small-signal bandwidth as well as band-limiting amplifier noise.

PC Board Layout and Power-Supply Bypassing

For optimal circuit performance, the TS1100 should be in very close proximity to the external currentsense resistor and the pcb tracks from RSENSE to the RS+ and the RS- input terminals of the TS1100 should be short and symmetric. Also recommended are a ground plane and surface mount resistors and capacitors.

Using the TS1100 in Bidirectional Load Current Applications

In many battery-powered systems, it is oftentimes necessary to monitor a battery's discharge and charge currents. To perform this function, a bidirectional current-sense amplifier is required. The circuit illustrated in Figure 2 shows how two TS1100s can be configured as a bidirectional current-sense amplifier. As shown in the figure, the RS+/RS- input pair of TS1100 #2 is wired opposite in polarity with respect to the RS+/RS- connections of TS1100 #1. Current-sense amplifier #1 therefore measures the discharge current and current-sense amplifier #2 measures the charge current. Note that both output voltages are measured with respect to GND. When the discharge current is being measured, V_{OUT1} is active and V_{OUT2} is zero; for the case where charge current is being measured, VouT1 is zero, and V_{OUT2} is active.




Figure 2: Using Two TS1100s for Bidirectional Load Current Detection

Page 10 TS1100 Rev. 1.1



PACKAGE OUTLINE DRAWING

5-Pin SOT23 Package Outline Drawing

(N.B., Drawings are not to scale)


0.30 - 0.50 2.80 - 3.00 1.90 Max

NOTES:

- 1. Dimensions and tolerances are as per ANSI Y14.5M, 1982.
- 2. Package surface to be matte finish VDI 11~13.
- Die is facing up mold and facing down for trim/form, ie, reverse trim/form.
- 4. The foot length measuring is based on the gauge plane method.

5. Dimensions are exclusive of mold flash and gate burr.

- 6. Dimensions are exclusive of solder plating.
- 7. All dimensions are in mm.
- 8. This part is compliant with EIAJ spec. and JEDEC MO-178 AA
- Lead span/stand off height/coplanarity are considered as special characteristic.




Patent Notice

Silicon Labs invests in research and development to help our customers differentiate in the market with innovative low-power, small size, analog-intensive mixed-signal solutions. Silicon Labs' extensive patent portfolio is a testament to our unique approach and world-class engineering team.

The information in this document is believed to be accurate in all respects at the time of publication but is subject to change without notice. Silicon Laboratories assumes no responsibility for errors and omissions, and disclaims responsibility for any consequences resulting from the use of information included herein. Additionally, Silicon Laboratories assumes no responsibility for the functioning of undescribed features or parameters. Silicon Laboratories reserves the right to make changes without further notice. Silicon Laboratories makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does Silicon Laboratories assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. Silicon Laboratories products are not designed, intended, or authorized for use in applications intended to support or sustain life, or for any other application in which the failure of the Silicon Laboratories product could create a situation where personal injury or death may occur. Should Buyer purchase or use Silicon Laboratories products for any such unintended or unauthorized application, Buyer shall indemnify and hold Silicon Laboratories harmless against all claims and damages.

Silicon Laboratories and Silicon Labs are trademarks of Silicon Laboratories Inc.

Other products or brandnames mentioned herein are trademarks or registered trademarks of their respective holders.









Disclaimer

Silicon Laboratories intends to provide customers with the latest, accurate, and in-depth documentation of all peripherals and modules available for system and software implementers using or intending to use the Silicon Laboratories products. Characterization data, available modules and peripherals, memory sizes and memory addresses refer to each specific device, and "Typical" parameters provided can and do vary in different applications. Application examples described herein are for illustrative purposes only. Silicon Laboratories reserves the right to make changes without further notice and limitation to product information, specifications, and descriptions herein, and does not give warranties as to the accuracy or completeness of the included information. Silicon Laboratories shall have no liability for the consequences of use of the information supplied herein. This document does not imply or express copyright licenses granted hereunder to design or fabricate any integrated circuits. The products must not be used within any Life Support System without the specific written consent of Silicon Laboratories. A "Life Support System" is any product or system intended to support or sustain life and/or health, which, if it fails, can be reasonably expected to result in significant personal injury or death. Silicon Laboratories products are generally not intended for military applications. Silicon Laboratories products shall under no circumstances be used in weapons of mass destruction including (but not limited to) nuclear, biological or chemical weapons, or missiles capable of delivering such weapons.

Trademark Information

Silicon Laboratories Inc., Silicon Laboratories, Silicon Labs, SiLabs and the Silicon Labs logo, CMEMS®, EFM, EFM32, EFR, Energy Micro, Energy Micro logo and combinations thereof, "the world's most energy friendly microcontrollers", Ember®, EZLink®, EZMac®, EZRadio®, EZRadioPRO®, DSPLL®, ISOmodem ®, Precision32®, ProSLIC®, SiPHY®, USBXpress® and others are trademarks or registered trademarks of Silicon Laboratories Inc. ARM, CORTEX, Cortex-M3 and THUMB are trademarks or registered trademarks of ARM Holdings. Keil is a registered trademark of ARM Limited. All other products or brand names mentioned herein are trademarks of their respective holders.



Silicon Laboratories Inc. 400 West Cesar Chavez Austin, TX 78701 USA