

Plantagenet_Players_Base_2026_r1 · 28 September 2026

Venue Base Guide

The Plantagenet Hall lighting rig on its own: the Mantra base, the QLab base that tests it, the printouts and how to use them

40

fixtures patched

8

venue looks (P1)

8

venue memories 100–109

57

QLab base cues

WHAT THE BASE IS

Plantagenet_Players_Base_2026_r1.mtr is the venue's own Mantra show file: the patch, the five custom fixture types, the network, the rig view, the venue looks on Page 1 and the internal memories 100–109. It has none of the Little Mermaid cues. The R13.1 show file is built on it, and the two are checked to be identical in all of those parts (tools/check_mantra_base.py). **Plantagenet_Players_Base_2026_r1.qlab5** is a QLab 5 workspace that fires the base: each venue look, every fixture of one type at once (rig ID), one fixture at a time (rig test) and three emergency cues. Use it for the rig day and to put the venue back after the show.

ONLY WITH THE BASE ON THE DESK

Run **Plantagenet_Players_Base_2026_r1.qlab5** only when **Plantagenet_Players_Base_2026_r1.mtr** is loaded on the Mantra. With the show file loaded, its P2–P5 test cues would fire show memories instead.

1 Files in this folder

File	What it is	Use
00_READ_ME_FIRST.txt	What this folder is and the first steps	Everyone
Plantagenet_Players_Base_2026_r1.mtr	The venue base for the LSC Mantra Lite: patch, fixture library, network, rig view, venue looks P1 and memories 100–109. No show cues.	LX — import on the desk
Plantagenet_Players_Base_2026_r1.qlab5	QLab 5 workspace that fires the venue base: venue looks V1–V10, rig ID sweeps I1–I5, rig test T1–T41, emergency E1–E3	LX / QLab op — rig check
BASE_METADATA.json	SHA-256 of the two base files and where they came from	Checking a copy
docs/Plantagenet_Players_Base_2026_r1_Guide.pdf	This guide	Everyone
docs/Plantagenet_Players_Base_2026_r1_Link_Map.pdf	Which QLab base cue fires which Mantra page/memory, and every fixture's fader, address and test cue	LX
docs/Plantagenet_Players_Base_2026_r1_Mantra_Labels.pdf	Desk fader and playback labels for the base (venue names only)	LX — print
docs/Plantagenet_Players_Base_2026_r1_Rig_ID_Test.pdf	Rig ID test: find every fixture, check type, position, address and mode; fault table and sign-off	LX — rig day
docs/Plantagenet_Players_Base_2026_r1_Previz.pdf	The base lighting drawn on photos of the stage: the whole rig, every venue look, the rig ID sweeps and each fixture on its own	Everyone

2 The rig as installed

From the venue photos (29 Sep 2026) and the base patch. **The 12 Lightsky C42s are fixed on the FOH bar** in number order, #1 at the stage-right end, and **the 3 PixBars on the pelmet front are fixed**. Which COB PARs and PixBars hang where is assumed until the rig ID test.

#	Fixture	Hangs now	DMX	Mode	Fader	Test
1	Lightsky C42	FOH 1	U2 : 101–111	11 ch	Console 1	T1
2	Lightsky C42	FOH 2	U2 : 112–122	11 ch	Console 2	T2
3	Lightsky C42	FOH 3	U2 : 123–133	11 ch	Console 3	T3
4	Lightsky C42	FOH 4	U2 : 134–144	11 ch	Console 4	T4
5	Lightsky C42	FOH 5	U2 : 145–155	11 ch	Console 5	T5
6	Lightsky C42	FOH 6	U2 : 156–166	11 ch	Console 6	T6
7	Lightsky C42	FOH 7	U2 : 167–177	11 ch	Console 7	T7
8	Lightsky C42	FOH 8	U2 : 178–188	11 ch	Console 8	T8
9	Lightsky C42	FOH 9	U2 : 189–199	11 ch	Console 9	T9

#	Fixture	Hangs now	DMX	Mode	Fader	Test
10	Lightsky C42	FOH 10	U2 : 200–210	11 ch	Console 10	T10
11	Lightsky C42	FOH 11	U2 : 211–221	11 ch	Console 11	T11
12	Lightsky C42	FOH 12	U2 : 222–232	11 ch	Console 12	T12
13	Tour Pro Zoom	LX1	U1 : 301–312	12 ch	Console 13	T13
14	Tour Pro Zoom	LX1	U1 : 313–324	12 ch	Console 14	T14
15	Tour Pro Zoom	LX1	U1 : 325–336	12 ch	Console 15	T15
16	Tour Pro Zoom	LX1	U1 : 337–348	12 ch	Console 16	T16
17	Tour Pro Zoom	LX1	U1 : 349–360	12 ch	Console 17	T17
18	Tour Pro Zoom	LX1	U1 : 361–372	12 ch	Console 18	T18
19	Tour Pro Zoom	LX1	U1 : 373–384	12 ch	Console 19	T19
20	Tour Pro Zoom	LX1	U1 : 385–396	12 ch	Console 20	T20
21	Tour Pro Zoom	LX1	U1 : 397–408	12 ch	Console 21	T21
22	Tour Pro Zoom	LX1	U1 : 409–420	12 ch	Console 22	T22
23	TourCOB PAR	LX2	U1 : 421–426	6 ch	Console 23	T23
24	TourCOB PAR	LX2	U1 : 427–432	6 ch	Console 24	T24
25	TourCOB PAR	LX2	U1 : 433–438	6 ch	Wing 1 · 25	T25
26	TourCOB PAR	LX2	U1 : 439–444	6 ch	Wing 1 · 26	T26
27	TourCOB PAR	LX2	U1 : 445–450	6 ch	Wing 1 · 27	T27
28	TourCOB PAR	LX2	U1 : 451–456	6 ch	Wing 1 · 28	T28
29	TourCOB PAR	LX1	U1 : 457–462	6 ch	Wing 1 · 29	T29
30	TourCOB PAR	LX1	U1 : 463–468	6 ch	Wing 1 · 30	T30
31	TourCOB PAR	LX1	U1 : 469–474	6 ch	Wing 1 · 31	T31
32	TourCOB PAR	LX1	U1 : 475–480	6 ch	Wing 1 · 32	T32
33	PixBar	pelmet/LX2	U1 : 1–6	6 ch	Wing 1 · 33	T33
34	PixBar	pelmet/LX2	U1 : 7–12	6 ch	Wing 1 · 34	T34
35	PixBar	pelmet/LX2	U1 : 13–18	6 ch	Wing 1 · 35	T35
36	PixBar	pelmet/LX2	U1 : 19–24	6 ch	Wing 1 · 36	T36
37	PixBar	pelmet/LX2	U1 : 25–30	6 ch	Wing 2 · 37	T37
38	PixBar	pelmet/LX2	U1 : 31–36	6 ch	Wing 2 · 38	T38
39	TourCOB PAR	LX2 wall	U1 : 481–486	6 ch	Wing 2 · 39	T39
40	Hazer	floor US	U1 : 487–488	2 ch	Wing 2 · 40	T40

POWER AND DATA

FOH C42s run from the venue dimmers: set those dimmer channels to **NON-DIM** (hard power) before switching on; never dim an LED fixture.

Universe 1 on the desk XLR (stage rig and hazer); universe 2 over Ethernet to the node 2.0.0.10 for the FOH bar. Desk 2.0.0.1 / 255.0.0.0, DHCP off; Art-Net and sACN are both on — turn off the one the node doesn't use.

3 Venue looks and memories

Look	Desk	QLab base	What is lit
STAGE WORK	P1 M1	V1	Lightsky C42 #1–12 · Tour Pro Zoom #13–22 · TourCOB PAR #23–32, 39 · PixBar #33–38
FULL STAGE WHITE	P1 M2	V2	Lightsky C42 #1–12 · Tour Pro Zoom #13–22 · TourCOB PAR #23–32
WARM STAGE	P1 M3	V3	Lightsky C42 #1–12 · Tour Pro Zoom #13–22 · TourCOB PAR #23–32
COOL STAGE	P1 M4	V4	Lightsky C42 #1–12 · Tour Pro Zoom #13–22 · TourCOB PAR #23–32
BLUE STAGE	P1 M5	V5	Lightsky C42 #1–12 · Tour Pro Zoom #13–22 · TourCOB PAR #23–32
RED STAGE	P1 M6	V6	Lightsky C42 #1–12 · Tour Pro Zoom #13–22 · TourCOB PAR #23–32
PIXBAR WASH	P1 M9	V9	PixBar #33–38
CURTAIN CALL	P1 M10	V10	Lightsky C42 #1–12 · Tour Pro Zoom #13–22 · TourCOB PAR #23–32, 39 · PixBar #33–38
LIGHTSKY ROW	memory 100	—	Lightsky C42 #1–12
ZOOM ROW	memory 101	—	Tour Pro Zoom #13–22
TOURCOB ROW	memory 102	—	TourCOB PAR #23–32
PIXBAR ROW	memory 103	—	PixBar #33–38
STAGE RIGHT	memory 104	—	Lightsky C42 #1–4 · Tour Pro Zoom #13–15 · TourCOB PAR #23–25 · PixBar #33–34

Look	Desk	QLab base	What is lit
CENTRE STAGE	memory 105	—	Lightsky C42 #5–8 · Tour Pro Zoom #16–19 · TourCOB PAR #26–29 · PixBar #35–36
STAGE LEFT	memory 106	—	Lightsky C42 #9–12 · Tour Pro Zoom #20–22 · TourCOB PAR #30–32 · PixBar #37–38
BLACKOUT	memory 109	—	nothing (blackout)

Memories 100–109 are internal venue memories (rows by type, the three stage areas, blackout); they are not on a playback page.

4 The QLab base cues

Group	Cues	Count	What it does
V	V1 – V10	8	Venue looks P1, one at a time — each GO releases the other P1 looks
I	I1 – I5	5	Rig ID: every fixture of one type at full (I1 C42, I2 Zoom, I3 COB, I4 PixBar); I5 clears
T	T1 – T41	41	Rig test: one fixture per GO (T1–T40, P2 M1 – P5 M10 test memories), each releasing the one before; T41 ends
E	E1 – E3	3	E1 stop all (QLab panic) · E2 all Mantra memories off · E3 stage work

5 How to

Load the venue base on the Mantra

1. Put a FAT32 USB stick in the Mantra. Home > Tools > Export Show — keep that export as the restore point.
2. Copy Plantagenet_Players_Base_2026_r1.mtr onto the stick. Home > Tools > Import Show > Plantagenet_Players_Base_2026_r1.mtr.
3. Check the five custom fixture types: CX 42 NEW, ZOOM 12 CHANNEL, TOURCOB PAR, PIXBAR 6CH, HAZER 2CH.
4. Tools > Setup > Network: 2.0.0.1, 255.0.0.0; turn off Art-Net or sACN (whichever the node doesn't use).
5. Tools > Setup > Remote Triggers > Add > OSC · Play Memory · port 8000 (for QLab). Save (T S).

Run the rig check from QLab

1. Open Plantagenet_Players_Base_2026_r1.qlab5 on the show Mac. Workspace Settings > Network: MANTRA → wired Ethernet.
2. GO I1–I4: count each type against the rig ID test sheet (12 C42 · 10 Zoom · 11 COB · 6 PixBar); I5 clears.
3. GO T1–T40: one fixture at a time. Tick lit alone, where it hangs, right type; write the real numbers of the LX1/LX2 COBs and the pelmet PixBars.
4. Faults: the fault table on the rig ID test (address, mode, cable, terminator). E2 turns everything off.

Go to the show, and put the venue back afterwards

1. For the show: Home > Tools > Import Show > TLM_nov_2026_final.mtr (in the show folder) and open TLM_nov_2026_final.qlab5 — not this QLab base.
2. After the last show: Import Plantagenet_Players_Base_2026_r1.mtr, check V1 STAGE WORK from the QLab base or the desk, save and export to USB. The venue is back to its own rig and looks.

6 Lighting previz

docs/Plantagenet_Players_Base_2026_r1_Previz.pdf draws the base on photos of the stage: the whole rig (tabs open and closed), every venue look, the rig ID sweeps and each fixture on its own, as installed. The same pictures are on the interactive Venue Base Previz page.

7 Checksums

File	SHA-256
Plantagenet_Players_Base_2026_r1.mtr	e273d54b71abb69bc9e2c6d5b431ebb5ceb09e22673f6b67d082fbfc66c63076
Plantagenet_Players_Base_2026_r1 qlab5	35cf343d1870a12dd1218a6e0a8a85fa60b1b60d760c7f60a96014bf45d3e4ba
Rig day notes	