

# C

## PART C DMX Patch & Step-by-Step Guide

The venue patch (40 fixtures + optional pinspots), channel maps, Art-Net/sACN network, fader map, the patch procedure for the R13.1 show file, rig sheets, power and troubleshooting.

Revision R13.1 · 28 September 2026

PART C · R13.1 · 28 September 2026

# DMX Patch & Step-by-Step Guide

Confirmed desk patch, channel maps, network, and the procedure from load to rig check

|                                           |                                      |                                            |                                  |
|-------------------------------------------|--------------------------------------|--------------------------------------------|----------------------------------|
| <b>40</b><br>fixtures patched (base file) | <b>2</b><br>optional pinspots #41–42 | <b>2</b><br>universes (DMX + Art-Net/sACN) | <b>0</b><br>re-addressing needed |
|-------------------------------------------|--------------------------------------|--------------------------------------------|----------------------------------|

**R13.1**

The patch is unchanged: TLM\_SHOW\_2026\_R13\_FLASHY\_SCENE\_SPLIT.mtr carries the venue base patch, custom fixtures and network exactly as R8. What changed is where things live on the desk: **HAZE is P5 M4** (was P2 M4), and P2 M3 is now the ship/storm scene memory, so the optional pinspots go on **P5 M7** (free).

**THE ADDRESS TRAVELS WITH THE FIXTURE**

Every fixture keeps its desk number and DMX address wherever it hangs. Moving a C42 to the FOH truss means re-cabling it into the universe 2 line — not changing its address.

## Address map

| Universe | Range   | Fixtures                           | Free                           |
|----------|---------|------------------------------------|--------------------------------|
| U1       | 1–36    | PixBars #33–38 (6 ch)              |                                |
| U1       | 37–38   | Pinspots #41–42 (optional)         |                                |
| U1       | 39–300  | —                                  | 262 free (future moving heads) |
| U1       | 301–420 | Tour Pro Zooms #13–22 (12 ch)      |                                |
| U1       | 421–486 | TourCOB PARs #23–32 and #39 (6 ch) |                                |
| U1       | 487–488 | Hazer #40 (2 ch)                   | 489–512 free                   |
| U2       | 101–232 | Lightsky C42 #1–12 (11 ch)         | 1–100 and 233–512 free         |

## 1 Master DMX patch

| #  | Desk library               | Mode  | Universe:address | Intensity at | Display | Position | Fader   |
|----|----------------------------|-------|------------------|--------------|---------|----------|---------|
| 1  | LIGHTSKY · CX 42 NEW       | 11 ch | U2:101–111       | 109          | A101    | FOH      | Console |
| 2  | LIGHTSKY · CX 42 NEW       | 11 ch | U2:112–122       | 120          | A112    | FOH      | Console |
| 3  | LIGHTSKY · CX 42 NEW       | 11 ch | U2:123–133       | 131          | A123    | FOH      | Console |
| 4  | LIGHTSKY · CX 42 NEW       | 11 ch | U2:134–144       | 142          | A134    | FOH      | Console |
| 5  | LIGHTSKY · CX 42 NEW       | 11 ch | U2:145–155       | 153          | A145    | FOH      | Console |
| 6  | LIGHTSKY · CX 42 NEW       | 11 ch | U2:156–166       | 164          | A156    | FOH      | Console |
| 7  | LIGHTSKY · CX 42 NEW       | 11 ch | U2:167–177       | 175          | A167    | FOH      | Console |
| 8  | LIGHTSKY · CX 42 NEW       | 11 ch | U2:178–188       | 186          | A178    | FOH      | Console |
| 9  | LIGHTSKY · CX 42 NEW       | 11 ch | U2:189–199       | 197          | A189    | LX1      | Console |
| 10 | LIGHTSKY · CX 42 NEW       | 11 ch | U2:200–210       | 208          | A200    | LX1      | Console |
| 11 | LIGHTSKY · CX 42 NEW       | 11 ch | U2:211–221       | 219          | A211    | LX1      | Console |
| 12 | LIGHTSKY · CX 42 NEW       | 11 ch | U2:222–232       | 230          | A222    | LX1      | Console |
| 13 | TOUR PRO · ZOOM 12 CHANNEL | 12 ch | U1:301–312       | 301          | A301    | LX1      | Console |
| 14 | TOUR PRO · ZOOM 12 CHANNEL | 12 ch | U1:313–324       | 313          | A313    | LX1      | Console |
| 15 | TOUR PRO · ZOOM 12 CHANNEL | 12 ch | U1:325–336       | 325          | A325    | LX1      | Console |
| 16 | TOUR PRO · ZOOM 12 CHANNEL | 12 ch | U1:337–348       | 337          | A337    | LX1      | Console |
| 17 | TOUR PRO · ZOOM 12 CHANNEL | 12 ch | U1:349–360       | 349          | A349    | LX1      | Console |
| 18 | TOUR PRO · ZOOM 12 CHANNEL | 12 ch | U1:361–372       | 361          | A361    | LX1      | Console |
| 19 | TOUR PRO · ZOOM 12 CHANNEL | 12 ch | U1:373–384       | 373          | A373    | LX2      | Console |
| 20 | TOUR PRO · ZOOM 12 CHANNEL | 12 ch | U1:385–396       | 385          | A385    | LX2      | Console |
| 21 | TOUR PRO · ZOOM 12 CHANNEL | 12 ch | U1:397–408       | 397          | A397    | SR boom  | Console |
| 22 | TOUR PRO · ZOOM 12 CHANNEL | 12 ch | U1:409–420       | 409          | A409    | SL boom  | Console |
| 23 | TOUR PRO · TOURCOB PAR     | 6 ch  | U1:421–426       | 421          | A421    | LX2      | Console |
| 24 | TOUR PRO · TOURCOB PAR     | 6 ch  | U1:427–432       | 427          | A427    | LX2      | Console |
| 25 | TOUR PRO · TOURCOB PAR     | 6 ch  | U1:433–438       | 433          | A433    | LX2      | Wing 1  |

| #  | Desk library           | Mode | Universe:address | Intensity at | Display | Position   | Fader  |
|----|------------------------|------|------------------|--------------|---------|------------|--------|
| 26 | TOUR PRO · TOURCOB PAR | 6 ch | U1:439–444       | 439          | A439    | LX2        | Wing 1 |
| 27 | TOUR PRO · TOURCOB PAR | 6 ch | U1:445–450       | 445          | A445    | LX2        | Wing 1 |
| 28 | TOUR PRO · TOURCOB PAR | 6 ch | U1:451–456       | 451          | A451    | LX2        | Wing 1 |
| 29 | TOUR PRO · TOURCOB PAR | 6 ch | U1:457–462       | 457          | A457    | SR boom    | Wing 1 |
| 30 | TOUR PRO · TOURCOB PAR | 6 ch | U1:463–468       | 463          | A463    | SR boom    | Wing 1 |
| 31 | TOUR PRO · TOURCOB PAR | 6 ch | U1:469–474       | 469          | A469    | SL boom    | Wing 1 |
| 32 | TOUR PRO · TOURCOB PAR | 6 ch | U1:475–480       | 475          | A475    | SL boom    | Wing 1 |
| 33 | TOUR PRO · PIXBAR 6CH  | 6 ch | U1:1–6           | virtual      | A001    | LX2        | Wing 1 |
| 34 | TOUR PRO · PIXBAR 6CH  | 6 ch | U1:7–12          | virtual      | A007    | LX2        | Wing 1 |
| 35 | TOUR PRO · PIXBAR 6CH  | 6 ch | U1:13–18         | virtual      | A013    | LX2        | Wing 1 |
| 36 | TOUR PRO · PIXBAR 6CH  | 6 ch | U1:19–24         | virtual      | A019    | LX2        | Wing 1 |
| 37 | TOUR PRO · PIXBAR 6CH  | 6 ch | U1:25–30         | virtual      | A025    | LX2        | Wing 2 |
| 38 | TOUR PRO · PIXBAR 6CH  | 6 ch | U1:31–36         | virtual      | A031    | LX2        | Wing 2 |
| 39 | TOUR PRO · TOURCOB PAR | 6 ch | U1:481–486       | 481          | A481    | LX2        | Wing 2 |
| 40 | GENERIC · HAZER 2CH    | 2 ch | U1:487–488       | 487          | A487    | Floor, US  | Wing 2 |
| 41 | Generic dimmer (1 ch)  | 1 ch | U1:37            | 37           | A037    | FOH SR end | Wing 2 |
| 42 | Generic dimmer (1 ch)  | 1 ch | U1:38            | 38           | A038    | FOH SL end | Wing 2 |

## 2 Channel maps

Each fixture must be in the matching DMX mode (11 / 12 / 6 channels) or colours land on the wrong channels. Home = value when the fixture is cleared.

### Lightsky 8800-C42 · CX 42 NEW · 11 ch

| Ch | Function     | Home / rule |
|----|--------------|-------------|
| 1  | Red          | 255         |
| 2  | Amber        | 0           |
| 3  | Lime         | 0           |
| 4  | Green        | 255         |
| 5  | Blue         | 255         |
| 6  | UV           | 0           |
| 7  | CCT          | 0           |
| 8  | Colour macro | 0 · keep 0  |
| 9  | Intensity    | 0           |
| 10 | Control      | 0 · keep 0  |
| 11 | Strobe       | 0 · keep 0  |

### Tour Pro Zoom · ZOOM 12 CHANNEL · 12 ch

| Ch | Function   | Home / rule  |
|----|------------|--------------|
| 1  | Intensity  | 0            |
| 2  | Red        | 255          |
| 3  | Green      | 255          |
| 4  | Blue       | 255          |
| 5  | White      | 0            |
| 6  | Control    | keep 0       |
| 7  | Strobe     | keep 0       |
| 8  | Zoom       | set in focus |
| 9  | Other      | keep 0       |
| 10 | Default    | keep 0       |
| 11 | Auto speed | keep 0       |
| 12 | Reset      | keep 0       |

**Tour Pro TourCOB PAR · 6 ch**

| Ch | Function  | Home / rule |
|----|-----------|-------------|
| 1  | Intensity | 0           |
| 2  | Red       | 255         |
| 3  | Green     | 255         |
| 4  | Blue      | 255         |
| 5  | White     | 0           |
| 6  | Strobe    | keep 0      |

**Tour Pro PixBar · PIXBAR 6CH · 6 ch**

| Ch | Function | Home / rule |
|----|----------|-------------|
| 1  | Red      | 255         |
| 2  | Green    | 255         |
| 3  | Blue     | 255         |
| 4  | White    | 0           |
| 5  | Amber    | 0           |
| 6  | UV       | 0           |

**Hazer · HAZER 2CH · 2 ch**

| Ch | Function | Home / rule |
|----|----------|-------------|
| 1  | Output   | 0           |
| 2  | Fan      | 0           |

**KEEP CONTROL-TYPE CHANNELS AT 0**

Control, Strobe, Reset, Auto speed, Other, Default and Colour macro can trigger resets, strobing or built-in programs. Every cue in the R13.1 file keeps them at 0; lightning is done with intensity (R-04). The Zoom library name is spelled TOUR PRO (zero) on the desk — cosmetic only.

## 3 DMX runs, network and fader map

| Line                  | Route                                                                                                                          |                                   |
|-----------------------|--------------------------------------------------------------------------------------------------------------------------------|-----------------------------------|
| Universe 1 (desk XLR) | Desk → LX1 Zooms #13–18 → LX2 (#19–20, 23–28, 39, 33–38) → SR boom (#21, 29–30) → SL boom (#22, 31–32) → hazer #40 · terminate |                                   |
| Universe 2 (Ethernet) | Desk → switch → node 2.0.0.10 → FOH truss C42 #1–8 → LX1 C42 #9–12 · terminate                                                 |                                   |
| Setting               | Desk (Mantra)                                                                                                                  | Node for universe 2               |
| IP address            | 2.0.0.1 (static, DHCP off)                                                                                                     | 2.0.0.10                          |
| Subnet mask           | 255.0.0.0                                                                                                                      | 255.0.0.0                         |
| Protocols             | Art-Net on · sACN on — turn off the one the node doesn't use                                                                   | sACN universe 2, or Art-Net 0-0-1 |
| Faders                | Fixtures                                                                                                                       |                                   |
| Console 1–12          | C42 #1–8 FOH · #9–12 LX1                                                                                                       |                                   |
| Console 13–24         | Zoom #13–18 LX1 · #19–20 LX2 · #21 SR · #22 SL · COB #23–24 LX2                                                                |                                   |
| Wing 1 25–36          | COB #25–28 LX2 · #29–30 SR · #31–32 SL · PixBar #33–36                                                                         |                                   |
| Wing 2 37–48          | PixBar #37–38 · COB #39 · hazer #40 · pinspots #41–42 · 43–48 spare                                                            |                                   |

Both wings must be connected (fixtures 25–42). Printed fader labels:

03\_Lighting\_Mantra/TLM\_R13\_1\_Mantra\_Labels.pdf.

## 4 Step-by-step patch procedure

### 1 Back up what is on the desk

1. FAT32 USB stick in the Mantra. Home > Tools > Export Show — keep it untouched as the venue restore point.
2. Keep BASE\_SHOW\_2026.mtr (the clean venue base) on the stick too.

### 2 Load the R13.1 show file

1. Copy TLM\_SHOW\_2026\_R13\_FLASHY\_SCENE\_SPLIT.mtr to the stick (check it in Mantra Editor first — Part D §9).
2. Home > Tools > Import Show > choose it. Check five custom fixture types: CX 42 NEW, ZOOM 12 CHANNEL, TOURCOB PAR, PIXBAR 6CH, HAZER 2CH.

### 3 Clear the output

1. A L, then O, so nothing is live while you check the patch.

#### 4 Check fixtures 1–40

- Tools › Setup › Patch. Step through against section 1: number, library, universe, address.
- Expected: #1–12 U2:101–232 · #13–22 U1:301–420 · #23–32 U1:421–480 · #33–38 U1:1–36 · #39 U1:481–486 · #40 U1:487–488.

#### 5 Pinspots — only if the mirror ball is used

- Generic dimmer, U1:37 as #41 and U1:38 as #42 → Patch.
- Record both at full on **P5 M7** (free in R13.1). Save.

#### 6 Network and universe 2

- Tools › Setup › Network: 2.0.0.1, 255.0.0.0; turn off Art-Net or sACN (whichever the node doesn't use).
- Set the node, connect it through the switch, run its DMX out to the FOH truss. Test C42 #1 at 50 %.

#### 7 Remote trigger for QLab (R13.1)

- Tools › Setup › Remote Triggers › Add › OSC · Play Memory · port 8000. Save.

#### 8 Cable, power, terminate

- One chain per universe in the order of section 3; label both ends; terminate the last fixture.
- No more than about 1,840 W per 10 A circuit.

#### 9 Rig check and save

- Each fixture alone at 50 %, then 0 → 100 %, then each colour. Use the ROW memories (100–103) for each type.
- Confirm PixBar #38 and TourCOB #39 physically exist (R13.1 fix list). Save (T S), export to USB, tick the rig sheets.

## 5 Rig sheets by position

#### FOH

| # | Type | Mode  | Start  | Role / focus                          | Addr                     | DMX                      | Pwr                      | Test                     |
|---|------|-------|--------|---------------------------------------|--------------------------|--------------------------|--------------------------|--------------------------|
| 1 | C42  | 11 ch | U2:101 | Face zone 1 — DSR (from house left)   | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| 2 | C42  | 11 ch | U2:112 | Face zone 1 — DSR (from house right)  | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| 3 | C42  | 11 ch | U2:123 | Face zone 2 — DSC (from house left)   | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| 4 | C42  | 11 ch | U2:134 | Face zone 2 — DSC (from house right)  | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| 5 | C42  | 11 ch | U2:145 | Face zone 3 — DSL (from house left)   | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| 6 | C42  | 11 ch | U2:156 | Face zone 3 — DSL (from house right)  | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| 7 | C42  | 11 ch | U2:167 | SP1 Ariel — DSC mark, shuttered tight | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| 8 | C42  | 11 ch | U2:178 | SP2 Spirit — DS audience-left mark    | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |

#### FOH SR end

| #  | Type | Mode | Start | Role / focus                        | Addr                     | DMX                      | Pwr                      | Test                     |
|----|------|------|-------|-------------------------------------|--------------------------|--------------------------|--------------------------|--------------------------|
| 41 | PIN  | 1 ch | U1:37 | Mirror ball (optional, not patched) | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |

#### FOH SL end

| #  | Type | Mode | Start | Role / focus                        | Addr                     | DMX                      | Pwr                      | Test                     |
|----|------|------|-------|-------------------------------------|--------------------------|--------------------------|--------------------------|--------------------------|
| 42 | PIN  | 1 ch | U1:38 | Mirror ball (optional, not patched) | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |

#### LX1

| #  | Type | Mode  | Start  | Role / focus                                    | Addr                     | DMX                      | Pwr                      | Test                     |
|----|------|-------|--------|-------------------------------------------------|--------------------------|--------------------------|--------------------------|--------------------------|
| 9  | C42  | 11 ch | U2:189 | SP3 Octavia — US audience-right mark            | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| 10 | C42  | 11 ch | U2:200 | SP4 Shell — plinth mark, shuttered to the shell | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| 11 | C42  | 11 ch | U2:211 | V1 Dame — voice-transfer mark 1                 | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| 12 | C42  | 11 ch | U2:222 | V2 Flanders — voice-transfer mark 2             | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| 13 | ZM   | 12 ch | U1:301 | Top/front colour wash — DSR                     | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| 14 | ZM   | 12 ch | U1:313 | Top/front colour wash — DSC                     | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| 15 | ZM   | 12 ch | U1:325 | Top/front colour wash — DSL                     | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| 16 | ZM   | 12 ch | U1:337 | Top/front colour wash — CSR                     | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| 17 | ZM   | 12 ch | U1:349 | Top/front colour wash — CSC                     | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| 18 | ZM   | 12 ch | U1:361 | Top/front colour wash — CSL                     | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |

**LX2**

| #  | Type | Mode  | Start  | Role / focus                                                 | Addr                     | DMX                      | Pwr                      | Test                     |
|----|------|-------|--------|--------------------------------------------------------------|--------------------------|--------------------------|--------------------------|--------------------------|
| 19 | ZM   | 12 ch | U1:373 | V3 Theodore — 13°, barn doors, steep top light               | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| 20 | ZM   | 12 ch | U1:385 | V4 Marina — 13°, barn doors, steep top light                 | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| 23 | COB  | 6 ch  | U1:421 | Backlight — DSR                                              | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| 24 | COB  | 6 ch  | U1:427 | Backlight — DSC                                              | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| 25 | COB  | 6 ch  | U1:433 | Backlight — DSL                                              | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| 26 | COB  | 6 ch  | U1:439 | Backlight — CSR                                              | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| 27 | COB  | 6 ch  | U1:445 | Backlight — CSC                                              | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| 28 | COB  | 6 ch  | U1:451 | Backlight — CSL                                              | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| 33 | PIX  | 6 ch  | U1:1   | Effect row, tilted downstage off the screen (R-25)           | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| 34 | PIX  | 6 ch  | U1:7   | Effect row, tilted downstage off the screen (R-25)           | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| 35 | PIX  | 6 ch  | U1:13  | Effect row, tilted downstage off the screen (R-25)           | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| 36 | PIX  | 6 ch  | U1:19  | Effect row, tilted downstage off the screen (R-25)           | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| 37 | PIX  | 6 ch  | U1:25  | Effect row, tilted downstage off the screen (R-25)           | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| 38 | PIX  | 6 ch  | U1:31  | Effect row, tilted downstage off the screen (R-25)           | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| 39 | COB  | 6 ch  | U1:481 | Extra backlight — centre (confirm it exists, R13.1 fix list) | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |

**SR boom**

| #  | Type | Mode  | Start  | Role / focus                                                | Addr                     | DMX                      | Pwr                      | Test                     |
|----|------|-------|--------|-------------------------------------------------------------|--------------------------|--------------------------|--------------------------|--------------------------|
| 21 | ZM   | 12 ch | U1:397 | High side — top of boom (~2.8 m), across to SL, head height | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| 29 | COB  | 6 ch  | U1:457 | Mid side — boom arm ~1.2 m, knee to hip                     | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| 30 | COB  | 6 ch  | U1:463 | Low side (shin) — boom arm ~0.4 m                           | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |

**SL boom**

| #  | Type | Mode  | Start  | Role / focus                                                | Addr                     | DMX                      | Pwr                      | Test                     |
|----|------|-------|--------|-------------------------------------------------------------|--------------------------|--------------------------|--------------------------|--------------------------|
| 22 | ZM   | 12 ch | U1:409 | High side — top of boom (~2.8 m), across to SR, head height | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| 31 | COB  | 6 ch  | U1:469 | Mid side — boom arm ~1.2 m, knee to hip                     | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| 32 | COB  | 6 ch  | U1:475 | Low side (shin) — boom arm ~0.4 m                           | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |

**Floor, US**

| #  | Type | Mode | Start  | Role / focus                             | Addr                     | DMX                      | Pwr                      | Test                     |
|----|------|------|--------|------------------------------------------|--------------------------|--------------------------|--------------------------|--------------------------|
| 40 | HAZE | 2 ch | U1:487 | Atmosphere — P5 M4 HAZE (50 %, fan 50 %) | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |

**6 Power, labels and troubleshooting**

| Position     | Fixtures                | Known load            | Suggested     |
|--------------|-------------------------|-----------------------|---------------|
| FOH          | 8 × C42                 | 2,400 W (10.4 A)      | 2 × 10 A      |
| LX1          | 4 × C42 + 6 × Zoom      | ~2,280 W (9.9 A)      | 2 × 10 A      |
| LX2          | 2 Zoom, 7 COB, 6 PixBar | 360 W + label ratings | 1 × 10 A      |
| SR / SL boom | 1 Zoom + 2 COB each     | 180 W + labels        | 1 × 10 A each |
| Floor        | Hazer                   | From label            | 1 × 10 A      |

| Symptom                       | Likely cause                       | Fix                                                      |
|-------------------------------|------------------------------------|----------------------------------------------------------|
| Two fixtures respond together | Duplicate address                  | Check displays against the master patch                  |
| Colours on the wrong channel  | Wrong DMX mode                     | Set 11 / 12 / 6 ch to match section 2                    |
| All C42s dead, U1 fine        | Universe 2 not reaching the node   | Switch, node IP, node universe                           |
| Nothing past a fixture        | Broken cable / through-port        | Swap the cable after the last working unit               |
| Random flicker                | No terminator or mic cable         | Terminate; use DMX cable                                 |
| Fixture strobes or resets     | Control/Strobe/Reset not 0         | Clear it; record 0                                       |
| Looks stack with odd colours  | Another memory still playing (LTP) | O (All Cues Off) and re-fire; check the QLab release cue |

|                       |
|-----------------------|
| Patch notes / changes |
|                       |
|                       |
|                       |
|                       |
|                       |
|                       |