REDMI NOTE 10 PRO FULL POWER TREE & RAIL SEQUENCING

Snapdragon 732G + PM6150 + PM6150L Complete Power Map | Sheet 1 of 1

POWER TREE PROGRESSION

Step-by-Step Voltage Escalation

Stage 1: Battery connected -> VBAT (3.85V) enters PM6150 Pin B2

Stage 2: PM6150 generates VPH_PWR (3.9V) through inductor L1001

Stage 3: Power button pressed -> PWR_KEY pulled low to 0V

Stage 4: PM6150 starts internal reference LDO (VREG_L1A_1P0)

Stage 5: Master PMIC releases PON_RESET to Slave PMIC (PM6150L)

Stage 6: Secondary BUCK coils fire: S1C, S2C, S3C (CPU big.LITTLE cores)

Stage 7: PM6150 asserts PS_HOLD (1.8V) confirming stable CPU execution

CONFIDENTIAL - SALEN MOBILE GURU CHIP-LEVEL HARDWARE LAB