
Warteschlangensimulator

Tutorial: Creating a first queueing model

Alexander Herzog TU Clausthal / SWZ www.simzentrum.de


Adding stations to the model (1)

- In Warteschlangensimulator queueing systems are modelled in form of flow charts.
- Our model will consist of a source, a process station and an exit element.
- To add these elements to the drawing surface open the element templates panel by clicking on "Element" on the left toolbar.




Adding stations to the model (2)

Drag and drop a "Source", a "Process station" and an "Exit" to the drawing surface.




Adding stations to the model (3)

After adding the elements again click on "Element" to close the templates panel.




Connecting the stations (1)

- As next step, the three stations need to be connected.
- Clients created at the source are to be directed to the process station. After being served the clients should leave the system via the exit station.
- ► To activate the connections adding function click on the "Edge" button on the left toolbar.




Connecting the stations (2)

- ► Edges are added by clicking the source and then the destination element of a connection.
- So click on "Source" and then on "Process station".
- After adding the first edge click on "Process station" and then on "Exit" to add the second connection.




Connecting the stations (3)

After adding the connections deactivate the connections adding function by clicking the "Edge" button on the left toolbar again.




Configuring the source station (1)

- Now the stations need to be configured.
- ► To define the properties of the source, double click on the source station.




Configuring the source station (2)

- In the default case the exponential distribution with an average inter-arrival time of 60 seconds is chosen.
- We want an average inter-arrival time of 50 seconds, so we click on "Edit" and change the average inter-arrival time.




Configuring the source station (3)

- After closing the distribution editor the new inter-arrival time is shown in the source properties dialog.
- The dialog can be closed by clicking "Ok" now.




Configuring the process station (1)

- As the last step the process station needs to be configured.
- By double clicking the process station element the properties dialog for this station can be opened.




Configuring the process station (2)

- In the default case the exponential distribution with an average service time of 50 seconds is chosen.
- We want an average service time of 80 seconds, so we click on "Edit" and change the average service time.




Configuring the process station (3)

- After closing the distribution editor the new service time is shown in the process station properties dialog.
- To make the process station work, we need to add operators as the last step. Therefore the "Operators" dialog page needs to be activated.




Configuring the process station (4)

- There are no operator groups in the system at the moment.
- So we need to create an operator group and assign it to the process station. This can be done by clicking "Create new operator group".




Configuring the process station (5)

- In the dialog for creating a new operator group the group size (the number of available operators in this group) can be specified.
- ▶ Because we want to create a M/M/c system with c=2, we enter a group size of 2.



Configuring the process station (6)

- Two operators are available in the group and one is needed to serve a client.
- That's all. The dialog can be closed by clicking "Ok" now.



Running simulations or animations

The model can be animated or simulated now by clicking "Start animation" or "Start simulation" on the toolbar.

- You will find more tutorial documents in the Help menu of Warteschlangensimulator.
- Many ready-to-run models can be loaded via the "Load example" menu item of the File menu.

