set_config

Command: `set_config`

Description

Command issued to set the complete device configuration such as current region details, ethernet & wifi configuration, end point configuration, event and alert configuration

Request

Request Fields

Field	Type	Required	Description
`command`	string	**Yes**	Specifies the operation being performed, in this case, setting the reader configuration.
`requestId`	string	**Yes**	A unique identifier for the request, allowing tracking and debugging of the operation.
`configData`	object	No	
`configData.applyAfterReboot`	boolean	No	if set to true, configuration changes will be applied after reboot
`configData.wifiConfig`	object	No	
`configData.wifiConfig.interfaceName`	string	**Yes**	The name of the network interface for which the Wi-Fi configuration is being set.
`configData.wifiConfig.enableInterface`	boolean	**Yes**	Specifies whether the network interface should be enabled or disabled.

Field	Type	Required	Description
`configData.wifiConfig.operation`	string (enum)	**Yes**	The operation to be performed on the Wi-Fi configuration. It can either create a new configuration or modify an existing one.
`configData.wifiConfig.accessPoint`	object	**Yes**	
`configData.wifiConfig.accessPoint.connect`	boolean	**Yes**	Indicates whether to connect to this profile. If true, disconnects the currently connected profile and connects to the specified one; if false, just saves the profile.
`configData.wifiConfig.accessPoint.isPreferred`	boolean	**Yes**	Marks this profile as the preferred one to always connect to when available.
`configData.wifiConfig.accessPoint.autoConn`	boolean	No	Reserved for backward compatibility. It will be removed in the future.
`configData.wifiConfig.accessPoint.essid`	string	**Yes**	The ESSID (network name) of the access point.
`configData.wifiConfig.accessPoint.enableSecurity`	boolean	**Yes**	Indicates whether security is enabled for this access point.
`configData.wifiConfig.accessPoint.ipv4Configuration`	object	No	
`configData.wifiConfig.accessPoint.ipv4Configuration.ipAddress`	string	No	The IPv4 address to assign to the interface.

Field	Type	Required	Description
`configData.wifiConfig.accessPoint.ipv4Configuration.subnetMask`	string	No	The IPv4 subnet mask.
`configData.wifiConfig.accessPoint.ipv4Configuration.gateway`	string	No	The IPv4 gateway address.
`configData.wifiConfig.accessPoint.ipv4Configuration.enableDhcp`	boolean	No	Specifies whether DHCP is enabled for automatic IP address assignment.
`configData.wifiConfig.accessPoint.ipv4Configuration.dnsServer`	string	No	The IPv4 address of the DNS server.
`configData.wifiConfig.accessPoint.ipv4Configuration.domainName`	string	No	The domain name for the network.
`configData.wifiConfig.accessPoint.ipv6Configuration`	object	No	
`configData.wifiConfig.accessPoint.ipv6Configuration.ipAddress`	string	No	The IPv6 address to assign to the interface.
`configData.wifiConfig.accessPoint.ipv6Configuration.prefix`	integer	No	The IPv6 address prefix length.
`configData.wifiConfig.accessPoint.ipv6Configuration.gateway`	string	No	The IPv6 gateway address.

Field	Type	Required	Description
`configData.wifiConfig.accessPoint.ipv6Configuration.enableAuto`	boolean	No	Specifies whether automatic IPv6 address assignment (e.g., SLAAC) is enabled.
`configData.wifiConfig.accessPoint.ipv6Configuration.dnsServer`	string	No	The IPv6 address of the DNS server.
`configData.wifiConfig.accessPoint.ipv6Configuration.domainName`	string	No	The domain name for the IPv6 network.
`configData.wifiConfig.accessPoint.security`	object	No	
`configData.wifiConfig.accessPoint.security.securityType`	string (enum)	**Yes**	The security type for the access point, specifying the authentication and encryption method.
`configData.wifiConfig.accessPoint.security.securityDetails`	object	**Yes**	
`configData.wifiConfig.accessPoint.security.securityDetails.WPA2Personal`	object	No	
`configData.wifiConfig.accessPoint.security.securityDetails.WPA2Personal.password`	string	**Yes**	The password for WPA2-Personal authentication.
`configData.wifiConfig.accessPoint.security.securityDetails.WPA3Personal`	object	No	

Field	Type	Required	Description
`configData.wifiConfig.accessPoint.security.securityDetails.WPA3Personal.password`	string	**Yes**	The password for WPA3-Personal authentication.
`configData.wifiConfig.accessPoint.security.securityDetails.WPA2Enterprise`	object	No	WPA2-Enterprise security configuration with optional certificate parameters.
`configData.wifiConfig.accessPoint.security.securityDetails.WPA2Enterprise.authentication`	string (enum)	**Yes**	Authentication protocol for WPA2-Enterprise.
`configData.wifiConfig.accessPoint.security.securityDetails.WPA2Enterprise.innerAuthentication`	string (enum)	No	Inner authentication method to be used within the outer authentication protocol.
`configData.wifiConfig.accessPoint.security.securityDetails.WPA2Enterprise.identity`	string	No	The identity (username) for WPA2-Enterprise authentication.
`configData.wifiConfig.accessPoint.security.securityDetails.WPA2Enterprise.anonymousIdentity`	string	No	The anonymous identity for WPA2-Enterprise authentication.
`configData.wifiConfig.accessPoint.security.securityDetails.WPA2Enterprise.password`	string	No	The password for WPA2-Enterprise authentication.
`configData.wifiConfig.accessPoint.security.securityDetails.WPA2Enterprise.passphrase`	string	No	The passphrase for WPA2-Enterprise.

Field	Type	Required	Description
`configData.wifiConfig.accessPoint.security.securityDetails.WPA2Enterprise.certificate`	array	No	
`configData.wifiConfig.accessPoint.security.securityDetails.WPA2Enterprise.protocol`	string (enum)	No	The encryption protocol for WPA2-Enterprise.
`configData.wifiConfig.accessPoint.security.securityDetails.WPA3Enterprise`	object	No	WPA3-Enterprise security configuration with optional certificate parameters.
`configData.wifiConfig.accessPoint.security.securityDetails.WPA3Enterprise.authentication`	string (enum)	**Yes**	Authentication protocol for WPA3-Enterprise.
`configData.wifiConfig.accessPoint.security.securityDetails.WPA3Enterprise.innerAuthentication`	string (enum)	No	Inner authentication method to be used within the outer authentication protocol.
`configData.wifiConfig.accessPoint.security.securityDetails.WPA3Enterprise.identity`	string	No	The identity (username) for WPA3-Enterprise authentication.
`configData.wifiConfig.accessPoint.security.securityDetails.WPA3Enterprise.anonymousIdentity`	string	No	The anonymous identity for WPA3-Enterprise authentication.
`configData.wifiConfig.accessPoint.security.securityDetails.WPA3Enterprise.password`	string	No	The password for WPA3-Enterprise authentication.

Field	Type	Required	Description
`configData.wifiConfig.accessPoint.security.securityDetails.WPA3Enterprise.passphrase`	string	No	The passphrase for WPA3-Enterprise.
`configData.wifiConfig.accessPoint.security.securityDetails.WPA3Enterprise.certificate`	array	No	
`configData.wifiConfig.accessPoint.security.securityDetails.WPA3Enterprise.protocol`	string (enum)	No	The encryption protocol for WPA3-Enterprise.
`configData.wifiConfig.accessPoint.security.securityDetails.OWEPublic`	object	No	
`configData.wifiConfig.accessPoint.security.securityDetails.OWEPublic.authentication`	string	**Yes**	Authentication protocol for OWE-Public.
`configData.epConfig`	object	No	
`configData.epConfig.operation`	string (enum)	**Yes**	Specifies the type of operation to perform, either adding or deleting a configuration.
`configData.epConfig.configuration`	object	**Yes**	
`configData.epConfig.configuration.endpointName`	string	**Yes**	Identifies the name of the endpoint, which determines its purpose or function.

Field	Type	Required	Description
`configData.epConfig.configuration.epType`	string (enum)	**Yes**	Specifies the type of the endpoint.
`configData.epConfig.configuration.protocol`	string (enum)	**Yes**	Defines the communication protocol used by the endpoint.
`configData.epConfig.configuration.activate`	boolean	**Yes**	Indicates whether the endpoint is active or inactive.
`configData.epConfig.configuration.url`	string	**Yes**	Specifies the URL associated with the endpoint.
`configData.epConfig.configuration.verificationType`	string (enum)	**Yes**	Specifies the type of verification used for establishing secure connections.
`configData.epConfig.configuration.port`	integer	**Yes**	Specifies the port number used for communication.
`configData.epConfig.configuration.qosCommon`	integer	**Yes**	Defines the Quality of Service (QoS) level for the endpoint.
`configData.epConfig.configuration.tenantId`	string	**Yes**	Identifies the tenantID associated with the configuration.
`configData.epConfig.configuration.mqttParams`	object	No	
`configData.epConfig.configuration.mqttParams.keepAlive`	integer	No	Specifies the keep-alive interval in seconds for MQTT connections.
`configData.epConfig.configuration.mqttParams.cleanSession`	boolean	No	Indicates whether to start a clean session for the MQTT client.

Field	Type	Required	Description
`configData.epConfig.configuration.mqttParams.reconnectDelayMin`	integer	No	Specifies the minimum delay in seconds before reconnecting.
`configData.epConfig.configuration.mqttParams.reconnectDelayMax`	integer	No	Specifies the maximum delay in seconds before reconnecting.
`configData.epConfig.configuration.mqttParams.clientId`	string	No	Specifies the client ID used for MQTT connections.
`configData.epConfig.configuration.mqttParams.username`	string	No	The username for authentication in MQTT connections.
`configData.epConfig.configuration.mqttParams.password`	string	No	The password for authentication in MQTT connections.
`configData.epConfig.configuration.mqttParams.publishTopics`	array	No	
`configData.epConfig.configuration.mqttParams.subscribeTopics`	array	No	
`configData.epConfig.configuration.securityParams`	object	No	Defines the security parameters for the endpoint.
`configData.epConfig.configuration.securityParams.format`	string (enum)	**Yes**	Specifies the format of the security certificates. Currently, only PEM is supported.
`configData.epConfig.configuration.securityParams.algorithm`	string (enum)	**Yes**	Specifies the algorithm used for encryption.

Field	Type	Required	Description
`configData.epConfig.configuration.securityParams.caCertificateFile`	string	**Yes**	Specifies the file containing the CA certificates.
`configData.epConfig.configuration.securityParams.clientCert`	string	**Yes**	Specifies the file containing the client certificate.
`configData.epConfig.configuration.securityParams.clientKey`	string	**Yes**	Specifies the file containing the client private key.
`configData.epConfig.configuration.eventConfiguration`	object	No	
`configData.epConfig.configuration.eventConfiguration.antenna`	boolean	No	set to true to enable antenna events
`configData.epConfig.configuration.eventConfiguration.terminalConnection`	boolean	No	set to true to enable terminal connection/disconnection events
`configData.epConfig.configuration.eventConfiguration.firmwareUpdate`	boolean	No	set to true to enable fw update events
`configData.epConfig.configuration.eventConfiguration.gpi`	boolean	No	set to true to enable gpi events
`configData.epConfig.configuration.eventConfiguration.network`	boolean	No	set to true to enable network events

Field	Type	Required	Description
`configData.epConfig.configuration.eventConfiguration.exceptions`	boolean	No	set to true to enable exception events
`configData.epConfig.configuration.eventConfiguration.ntp`	boolean	No	set to true to enable battery alerts
`configData.epConfig.configuration.eventConfiguration.userApp`	boolean	No	set to true to enable user app events
`configData.epConfig.configuration.eventConfiguration.heartbeat`	boolean	No	set to true to enable heart beat
`configData.epConfig.configuration.eventConfiguration.power`	boolean	No	set to true to enable power source alerts
`configData.epConfig.configuration.eventConfiguration.battery`	boolean	No	set to true to enable battery alerts
`configData.epConfig.configuration.eventConfiguration.temperature`	boolean	No	set to true to enable temperature alerts
`configData.epConfig.configuration.eventConfiguration.fileDownload`	boolean	No	set to true to enable file download alerts
`configData.epConfig.configuration.eventConfiguration.cpuUsage`	boolean	No	set to true to enable cpu usage alerts

Field	Type	Required	Description
`configData.epConfig.configuration.eventConfiguration.flashUsage`	boolean	No	set to true to enable flash usage alerts
`configData.epConfig.configuration.eventConfiguration.ramUsage`	boolean	No	set to true to enable ram usage alerts
`configData.epConfig.configuration.eventConfiguration.heartbeatConfiguration`	object	No	
`configData.epConfig.configuration.eventConfiguration.heartbeatConfiguration.interval`	integer	No	heart beat interval in seconds
`configData.epConfig.configuration.eventConfiguration.heartbeatConfiguration.inventoryStatus`	boolean	No	set to true to enable inventory status as part of heartbeat message
`configData.epConfig.configuration.eventConfiguration.heartbeatConfiguration.batteryStatus`	boolean	No	set to true to enable battery status as part of heartbeat message
`configData.epConfig.configuration.eventConfiguration.heartbeatConfiguration.userApps`	boolean	No	set to true to enable user app status as part of heartbeat message
`configData.epConfig.configuration.eventConfiguration.cpuThreshold`	integer	No	cpu usage value(%) above which alert will be triggered

Field	Type	Required	Description
`configData.epConfig.configuration.eventConfiguration.ramThreshold`	integer	No	ram usage value(%) above which alert will be triggered
`configData.epConfig.configuration.eventConfiguration.flashThreshold`	integer	No	flash usage value(%) above which alert will be triggered
`configData.epConfig.configuration.eventConfiguration.temperatureThreshold`	integer	No	temperature treshold value above which alert will be triggered

Request Examples

Create wifi profile

```
{
  "command": "set_config",
  "requestId": "209543",
  "configData": {
    "wifiConfig": {
      "operation": "CREATE",
      "accessPoint": {
        "essid": "TEST_5G",
        "connect": true,
        "autoConn": true,
        "enableSecurity": true,
        "isPreferred": false,
        "security": {
          "securityType": "WPA2Personal",
          "securityDetails": {
            "WPA2Personal": {
              "password": "nov211985"
            }
          }
        }
      }
    }
  }
}
```

Modify wifi profile

```
{
  "command": "set_config",
  "requestId": "209543",
  "configData": {
    "wifiConfig": {
      "operation": "MODIFY",
      "accessPoint": {
        "essid": "TEST_5G",
        "connect": true,
        "autoConn": true,
        "enableSecurity": true,
        "isPreferred": true,
        "security": {
          "securityType": "WPA2Personal",
          "securityDetails": {
            "WPA2Personal": {
              "password": "nov211985"
            }
          }
        }
      }
    }
  }
}
```

Add mdm endpoint

```
{
  "command": "set_config",
  "requestId": "209543",
  "configData": {
    "applyAfterReboot": true,
    "epConfig": {
      "operation": "add",
      "configuration": {
        "endpointName": "gmdm",
        "epType": "MDM",
        "mqttParams": {
          "keepAlive": 300
        }
      }
    }
  }
}
```

Add data endpoint

```
{
  "command": "set_config",
  "requestId": "1233",
  "configData": {
```

```
    "epConfig": {
      "operation": "add",
      "configuration": {
        "endpointName": "dataEP",
        "epType": "DATA1",
        "protocol": "MQTT",
        "activate": true,
        "url": "17L11-GG6663-1",
        "verificationType": "NONE",
        "port": 1883,
        "qosCommon": 1,
        "tenantId": "ZEBRA",
        "mqttParams": {
          "keepAlive": 300,
          "cleanSession": true,
          "reconnectDelayMin": 50,
          "reconnectDelayMax": 500,
          "clientId": "zebra-rfd40-01",
          "username": "username",
          "password": "password"
        }
      }
    }
  }
}
```

Add control endpoint

```
{
  "command": "set_config",
  "requestId": "1234",
  "configData": {
    "epConfig": {
      "operation": "add",
      "configuration": {
        "endpointName": "ctrlEP",
        "epType": "CTRL",
        "protocol": "MQTT",
        "activate": true,
        "url": "17L11-GG6663-1",
        "verificationType": "NONE",
        "port": 1883,
        "qosCommon": 1,
        "tenantId": "zebra",
        "mqttParams": {
          "keepAlive": 300,
          "cleanSession": true,
          "reconnectDelayMin": 50,
          "reconnectDelayMax": 500,
          "clientId": "zebra-rfd40-01",
          "username": "mqttuser",
          "password": "password",
          "publishTopics": [
```

```
            {
              "topic": "MDM/clients/resp",
              "qos": 1,
              "retain": false
            },
            {
              "topic": "MDM/clients/event",
              "qos": 1,
              "retain": false
            },
            {
              "topic": "MDM/clients/rfid",
              "qos": 0,
              "retain": true
            }
          ],
          "subscribeTopics": [
            {
              "topic": "MDM/clients/cmnd",
              "qos": 0,
              "retain": false
            }
          ]
        }
      }
    }
  }
}
```

Complete config setup

```
{
  "command": "set_config",
  "requestId": "5678",
  "configData": {
    "wifiConfig": {
      "operation": "CREATE",
      "accessPoint": {
        "essid": "CORP_WIFI",
        "connect": true,
        "autoConn": false,
        "enableSecurity": true,
        "isPreferred": true,
        "security": {
          "securityType": "WPA2Personal",
          "securityDetails": {
            "WPA2Personal": {
              "password": "corp_pass_2024"
            }
          }
        }
      }
    },
```

```
    "epConfig": {
      "operation": "add",
      "configuration": {
        "endpointName": "mgmtEp",
        "epType": "MGMT",
        "protocol": "MQTT",
        "activate": true,
        "url": "iot-broker.company.com",
        "verificationType": "NONE",
        "port": 8883,
        "qosCommon": 1,
        "tenantId": "ZEBRA",
        "mqttParams": {
          "keepAlive": 60,
          "cleanSession": true,
          "reconnectDelayMin": 10,
          "reconnectDelayMax": 120,
          "clientId": "iot",
          "username": "iotuser",
          "password": "iotpassword",
          "publishTopics": [
            {
              "topic": "IOT/data/resp",
              "qos": 1,
              "retain": false
            }
          ],
          "subscribeTopics": [
            {
              "topic": "IOT/data/cmnd",
              "qos": 1,
              "retain": false
            }
          ]
        }
      }
    }
  }
}
```

Response

Response Fields

Field	Type	Required	Description
`command`	string	**Yes**	
`requestId`	string	**Yes**	
`apiVersion`	string (enum)	**Yes**	

Field	Type	Required	Description
`cfgResponse`	object	No	
`cfgResponse.ethConfig`	object	No	
`cfgResponse.ethConfig.interfaceName`	string	**Yes**	Name of the network interface (e.g., eth0).
`cfgResponse.ethConfig.enableInterface`	boolean	**Yes**	Indicates whether the network interface is enabled.
`cfgResponse.ethConfig.lldp`	boolean	**Yes**	Specifies if Link Layer Discovery Protocol (LLDP) is enabled.
`cfgResponse.ethConfig.ipv4Configuration`	object	No	Configuration settings for IPv4.
`cfgResponse.ethConfig.ipv4Configuration.ipAddress`	string	No	The IPv4 address assigned to the interface.
`cfgResponse.ethConfig.ipv4Configuration.subnetMask`	string	No	The subnet mask associated with the IPv4 address.
`cfgResponse.ethConfig.ipv4Configuration.gateway`	string	No	The default gateway for the IPv4 network.
`cfgResponse.ethConfig.ipv4Configuration.enableDhcp`	boolean	No	Indicates whether DHCP is enabled for IPv4.
`cfgResponse.ethConfig.ipv4Configuration.dnsServer`	string	No	The IPv4 address of the DNS server.
`cfgResponse.ethConfig.ipv4Configuration.domainName`	string	No	The domain name associated with the network.
`cfgResponse.ethConfig.ipv6Configuration`	object	No	Configuration settings for IPv6.

Field	Type	Required	Description
`cfgResponse.ethConfig.ipv6Configuration.ipAddress`	string	No	The IPv6 address assigned to the interface.
`cfgResponse.ethConfig.ipv6Configuration.prefix`	integer	No	The prefix length for the IPv6 address.
`cfgResponse.ethConfig.ipv6Configuration.gateway`	string	No	The default gateway for the IPv6 network.
`cfgResponse.ethConfig.ipv6Configuration.enableAuto`	boolean	No	Indicates whether auto-configuration is enabled for IPv6.
`cfgResponse.ethConfig.ipv6Configuration.dnsServer`	string	No	The IPv6 address of the DNS server.
`cfgResponse.ethConfig.ipv6Configuration.domainName`	string	No	The domain name associated with the IPv6 network.
`cfgResponse.ethConfig.security`	object	No	Security configuration for the network interface.
`cfgResponse.ethConfig.security.enableSecurity`	boolean	No	Indicates if security is enabled. If enabled, 802.X parameters must be provided.
`cfgResponse.ethConfig.security.EAP802_1X`	object	No	Extensible Authentication Protocol (EAP) 802.1X settings.
`cfgResponse.ethConfig.security.EAP802_1X.authentication`	string (enum)	No	The authentication method used for EAP 802.1X.
`cfgResponse.ethConfig.security.EAP802_1X.innerAuthentication`	string (enum)	No	The inner authentication method used within the EAP tunnel.
`cfgResponse.ethConfig.security.EAP802_1X.certificate`	string	No	The certificate used for EAP authentication.

Field	Type	Required	Description
`cfgResponse.wifiConfigResp`	object	No	
`cfgResponse.wifiConfigResp.interfaceName`	string	**Yes**	The name of the network interface for which the Wi-Fi configuration is being set.
`cfgResponse.wifiConfigResp.enableInterface`	boolean	**Yes**	Specifies whether the network interface should be enabled or disabled.
`cfgResponse.wifiConfigResp.operation`	string (enum)	**Yes**	The operation to be performed on the Wi-Fi configuration. It can either create a new configuration or modify an existing one.
`cfgResponse.wifiConfigResp.accessPoint`	object	**Yes**	
`cfgResponse.wifiConfigResp.accessPoint.connect`	boolean	**Yes**	Indicates whether to connect to this profile. If true, disconnects the currently connected profile and connects to the specified one; if false, just saves the profile.
`cfgResponse.wifiConfigResp.accessPoint.isPreferred`	boolean	**Yes**	Marks this profile as the preferred one to always connect to when available.
`cfgResponse.wifiConfigResp.accessPoint.autoConn`	boolean	No	Reserved for backward compatibility. It will be removed in the future.
`cfgResponse.wifiConfigResp.accessPoint.essid`	string	**Yes**	The ESSID (network name) of the access point.

Field	Type	Required	Description
`cfgResponse.wifiConfigResp.accessPoint.enableSecurity`	boolean	**Yes**	Indicates whether security is enabled for this access point.
`cfgResponse.wifiConfigResp.accessPoint.ipv4Configuration`	object	No	
`cfgResponse.wifiConfigResp.accessPoint.ipv4Configuration.ipAddress`	string	No	The IPv4 address to assign to the interface.
`cfgResponse.wifiConfigResp.accessPoint.ipv4Configuration.subnetMask`	string	No	The IPv4 subnet mask.
`cfgResponse.wifiConfigResp.accessPoint.ipv4Configuration.gateway`	string	No	The IPv4 gateway address.
`cfgResponse.wifiConfigResp.accessPoint.ipv4Configuration.enableDhcp`	boolean	No	Specifies whether DHCP is enabled for automatic IP address assignment.
`cfgResponse.wifiConfigResp.accessPoint.ipv4Configuration.dnsServer`	string	No	The IPv4 address of the DNS server.
`cfgResponse.wifiConfigResp.accessPoint.ipv4Configuration.domainName`	string	No	The domain name for the network.
`cfgResponse.wifiConfigResp.accessPoint.ipv6Configuration`	object	No	

Field	Type	Required	Description
`cfgResponse.wifiConfigResp.accessPoint.ipv6Configuration.ipAddress`	string	No	The IPv6 address to assign to the interface.
`cfgResponse.wifiConfigResp.accessPoint.ipv6Configuration.prefix`	integer	No	The IPv6 address prefix length.
`cfgResponse.wifiConfigResp.accessPoint.ipv6Configuration.gateway`	string	No	The IPv6 gateway address.
`cfgResponse.wifiConfigResp.accessPoint.ipv6Configuration.enableAuto`	boolean	No	Specifies whether automatic IPv6 address assignment (e.g., SLAAC) is enabled.
`cfgResponse.wifiConfigResp.accessPoint.ipv6Configuration.dnsServer`	string	No	The IPv6 address of the DNS server.
`cfgResponse.wifiConfigResp.accessPoint.ipv6Configuration.domainName`	string	No	The domain name for the IPv6 network.
`cfgResponse.wifiConfigResp.accessPoint.security`	object	No	
`cfgResponse.wifiConfigResp.accessPoint.security.securityType`	string (enum)	**Yes**	The security type for the access point, specifying the authentication and encryption method.
`cfgResponse.wifiConfigResp.accessPoint.security.securityDetails`	object	**Yes**	

Field	Type	Required	Description
`cfgResponse.wifiConfigResp.accessPoint.security.securityDetails.WPA2Personal`	object	No	
`cfgResponse.wifiConfigResp.accessPoint.security.securityDetails.WPA2Personal.password`	string	**Yes**	The password for WPA2-Personal authentication.
`cfgResponse.wifiConfigResp.accessPoint.security.securityDetails.WPA3Personal`	object	No	
`cfgResponse.wifiConfigResp.accessPoint.security.securityDetails.WPA3Personal.password`	string	**Yes**	The password for WPA3-Personal authentication.
`cfgResponse.wifiConfigResp.accessPoint.security.securityDetails.WPA2Enterprise`	object	No	WPA2-Enterprise security configuration with optional certificate parameters.
`cfgResponse.wifiConfigResp.accessPoint.security.securityDetails.WPA2Enterprise.authentication`	string (enum)	**Yes**	Authentication protocol for WPA2-Enterprise.
`cfgResponse.wifiConfigResp.accessPoint.security.securityDetails.WPA2Enterprise.innerAuthentication`	string (enum)	No	Inner authentication method to be used within the outer authentication protocol.

Field	Type	Required	Description
`cfgResponse.wifiConfigResp.accessPoint.security.securityDetails.WPA2Enterprise.identity`	string	No	The identity (username) for WPA2-Enterprise authentication.
`cfgResponse.wifiConfigResp.accessPoint.security.securityDetails.WPA2Enterprise.anonymousIdentity`	string	No	The anonymous identity for WPA2-Enterprise authentication.
`cfgResponse.wifiConfigResp.accessPoint.security.securityDetails.WPA2Enterprise.password`	string	No	The password for WPA2-Enterprise authentication.
`cfgResponse.wifiConfigResp.accessPoint.security.securityDetails.WPA2Enterprise.passphrase`	string	No	The passphrase for WPA2-Enterprise.
`cfgResponse.wifiConfigResp.accessPoint.security.securityDetails.WPA2Enterprise.certificate`	array	No	
`cfgResponse.wifiConfigResp.accessPoint.security.securityDetails.WPA2Enterprise.protocol`	string (enum)	No	The encryption protocol for WPA2-Enterprise.
`cfgResponse.wifiConfigResp.accessPoint.security.securityDetails.WPA3Enterprise`	object	No	WPA3-Enterprise security configuration with optional certificate parameters.

Field	Type	Required	Description
`cfgResponse.wifiConfigResp.accessPoint.security.securityDetails.WPA3Enterprise.authentication`	string (enum)	**Yes**	Authentication protocol for WPA3-Enterprise.
`cfgResponse.wifiConfigResp.accessPoint.security.securityDetails.WPA3Enterprise.innerAuthentication`	string (enum)	No	Inner authentication method to be used within the outer authentication protocol.
`cfgResponse.wifiConfigResp.accessPoint.security.securityDetails.WPA3Enterprise.identity`	string	No	The identity (username) for WPA3-Enterprise authentication.
`cfgResponse.wifiConfigResp.accessPoint.security.securityDetails.WPA3Enterprise.anonymousIdentity`	string	No	The anonymous identity for WPA3-Enterprise authentication.
`cfgResponse.wifiConfigResp.accessPoint.security.securityDetails.WPA3Enterprise.password`	string	No	The password for WPA3-Enterprise authentication.
`cfgResponse.wifiConfigResp.accessPoint.security.securityDetails.WPA3Enterprise.passphrase`	string	No	The passphrase for WPA3-Enterprise.
`cfgResponse.wifiConfigResp.accessPoint.security.securityDetails.WPA3Enterprise.certificate`	array	No	

Field	Type	Required	Description
`cfgResponse.wifiConfigResp.accessPoint.security.securityDetails.WPA3Enterprise.protocol`	string (enum)	No	The encryption protocol for WPA3-Enterprise.
`cfgResponse.wifiConfigResp.accessPoint.security.securityDetails.OWEPublic`	object	No	
`cfgResponse.wifiConfigResp.accessPoint.security.securityDetails.OWEPublic.authentication`	string	**Yes**	Authentication protocol for OWE-Public.
`cfgResponse.epConfig`	object	No	
`cfgResponse.epConfig.operation`	string (enum)	**Yes**	Specifies the type of operation to perform, either adding or deleting a configuration.
`cfgResponse.epConfig.configuration`	object	**Yes**	
`cfgResponse.epConfig.configuration.endpointName`	string	**Yes**	Identifies the name of the endpoint, which determines its purpose or function.
`cfgResponse.epConfig.configuration.epType`	string (enum)	**Yes**	Specifies the type of the endpoint.
`cfgResponse.epConfig.configuration.protocol`	string (enum)	**Yes**	Defines the communication protocol used by the endpoint.
`cfgResponse.epConfig.configuration.activate`	boolean	**Yes**	Indicates whether the endpoint is active or inactive.
`cfgResponse.epConfig.configuration.url`	string	**Yes**	Specifies the URL associated with the endpoint.

Field	Type	Required	Description
`cfgResponse.epConfig.configuration.verificationType`	string (enum)	**Yes**	Specifies the type of verification used for establishing secure connections.
`cfgResponse.epConfig.configuration.port`	integer	**Yes**	Specifies the port number used for communication.
`cfgResponse.epConfig.configuration.qosCommon`	integer	**Yes**	Defines the Quality of Service (QoS) level for the endpoint.
`cfgResponse.epConfig.configuration.tenantId`	string	**Yes**	Identifies the tenantID associated with the configuration.
`cfgResponse.epConfig.configuration.mqttParams`	object	No	
`cfgResponse.epConfig.configuration.mqttParams.keepAlive`	integer	No	Specifies the keep-alive interval in seconds for MQTT connections.
`cfgResponse.epConfig.configuration.mqttParams.cleanSession`	boolean	No	Indicates whether to start a clean session for the MQTT client.
`cfgResponse.epConfig.configuration.mqttParams.reconnectDelayMin`	integer	No	Specifies the minimum delay in seconds before reconnecting.
`cfgResponse.epConfig.configuration.mqttParams.reconnectDelayMax`	integer	No	Specifies the maximum delay in seconds before reconnecting.
`cfgResponse.epConfig.configuration.mqttParams.clientId`	string	No	Specifies the client ID used for MQTT connections.
`cfgResponse.epConfig.configuration.mqttParams.username`	string	No	The username for authentication in MQTT connections.

Field	Type	Required	Description
`cfgResponse.epConfig.configuration.mqttParams.password`	string	No	The password for authentication in MQTT connections.
`cfgResponse.epConfig.configuration.mqttParams.publishTopics`	array	No	
`cfgResponse.epConfig.configuration.mqttParams.subscribeTopics`	array	No	
`cfgResponse.epConfig.configuration.securityParams`	object	No	Defines the security parameters for the endpoint.
`cfgResponse.epConfig.configuration.securityParams.format`	string (enum)	**Yes**	Specifies the format of the security certificates. Currently, only PEM is supported.
`cfgResponse.epConfig.configuration.securityParams.algorithm`	string (enum)	**Yes**	Specifies the algorithm used for encryption.
`cfgResponse.epConfig.configuration.securityParams.caCertificateFile`	string	**Yes**	Specifies the file containing the CA certificates.
`cfgResponse.epConfig.configuration.securityParams.clientCert`	string	**Yes**	Specifies the file containing the client certificate.
`cfgResponse.epConfig.configuration.securityParams.clientKey`	string	**Yes**	Specifies the file containing the client private key.
`cfgResponse.epConfig.configuration.eventConfiguration`	object	No	

Field	Type	Required	Description
`cfgResponse.epConfig.configuration.eventConfiguration.antenna`	boolean	No	set to true to enable antenna events
`cfgResponse.epConfig.configuration.eventConfiguration.terminalConnection`	boolean	No	set to true to enable terminal connection/disconnection events
`cfgResponse.epConfig.configuration.eventConfiguration.firmwareUpdate`	boolean	No	set to true to enable fw update events
`cfgResponse.epConfig.configuration.eventConfiguration.gpi`	boolean	No	set to true to enable gpi events
`cfgResponse.epConfig.configuration.eventConfiguration.network`	boolean	No	set to true to enable network events
`cfgResponse.epConfig.configuration.eventConfiguration.exceptions`	boolean	No	set to true to enable exception events
`cfgResponse.epConfig.configuration.eventConfiguration.ntp`	boolean	No	set to true to enable battery alerts
`cfgResponse.epConfig.configuration.eventConfiguration.userApp`	boolean	No	set to true to enable user app events
`cfgResponse.epConfig.configuration.eventConfiguration.heartbeat`	boolean	No	set to true to enable heart beat

Field	Type	Required	Description
`cfgResponse.epConfig.configuration.eventConfiguration.power`	boolean	No	set to true to enable power source alerts
`cfgResponse.epConfig.configuration.eventConfiguration.battery`	boolean	No	set to true to enable battery alerts
`cfgResponse.epConfig.configuration.eventConfiguration.temperature`	boolean	No	set to true to enable temperature alerts
`cfgResponse.epConfig.configuration.eventConfiguration.fileDownload`	boolean	No	set to true to enable file download alerts
`cfgResponse.epConfig.configuration.eventConfiguration.cpuUsage`	boolean	No	set to true to enable cpu usage alerts
`cfgResponse.epConfig.configuration.eventConfiguration.flashUsage`	boolean	No	set to true to enable flash usage alerts
`cfgResponse.epConfig.configuration.eventConfiguration.ramUsage`	boolean	No	set to true to enable ram usage alerts
`cfgResponse.epConfig.configuration.eventConfiguration.heartbeatConfiguration`	object	No	
`cfgResponse.epConfig.configuration.eventConfiguration.heartbeatConfiguration.interval`	integer	No	heart beat interval in seconds

Field	Type	Required	Description
`cfgResponse.epConfig.configuration.eventConfiguration.heartbeatConfiguration.inventoryStatus`	boolean	No	set to true to enable inventory status as part of heartbeat message
`cfgResponse.epConfig.configuration.eventConfiguration.heartbeatConfiguration.batteryStatus`	boolean	No	set to true to enable battery status as part of heartbeat message
`cfgResponse.epConfig.configuration.eventConfiguration.heartbeatConfiguration.userApps`	boolean	No	set to true to enable user app status as part of heartbeat message
`cfgResponse.epConfig.configuration.eventConfiguration.cpuThreshold`	integer	No	cpu usage value(%) above which alert will be triggered
`cfgResponse.epConfig.configuration.eventConfiguration.ramThreshold`	integer	No	ram usage value(%) above which alert will be triggered
`cfgResponse.epConfig.configuration.eventConfiguration.flashThreshold`	integer	No	flash usage value(%) above which alert will be triggered
`cfgResponse.epConfig.configuration.eventConfiguration.temperatureThreshold`	integer	No	temperature treshold value above which alert will be triggered
`cfgResponse.wifiProfiles`	object	No	
`cfgResponse.wifiProfiles.wifiConfig`	array	No	

Field	Type	Required	Description
`response`	object	**Yes**	Status of the command execution — check `code` to confirm success (0) or identify the error.
`response.code`	integer	**Yes**	Response code indicating success or failure. • **0** — Success • **2** — Invalid payload • **10** — Configuration already exist • **15** — WIFI Error - SSID not found • **17** — WIFI Error - SSID missed • **18** — WIFI Error - SSID already exist • **19** — WIFI Error - SSID count overflow • **20** — Wifi is not supported • **23** — Invalid enum value • **25** — Max 3 publish topics exceeded • **26** — Max 1 subscribe topic exceeded • **27** — Invalid tenant ID length
`response.description`	string	**Yes**	Human-readable description of the response code (e.g. "Success", "Invalid payload").

Response Examples

example1

```
{
  "command": "set_config",
  "requestId": "209543",
  "apiVersion": "V1.1",
  "cfgResponse": {
    "wifiConfig": {
      "operation": "CREATE",
      "accessPoint": {
        "essid": "TEST_5G",
        "connect": true,
        "autoConn": true,
        "enableSecurity": true,
        "isPreferred": false,
        "security": {
          "securityType": "WPA2Personal",
          "securityDetails": {
            "WPA2Personal": {
              "password": "XXXXXXXX"
            }
          }
        }
      }
    }
  },
  "response": {
    "code": 0,
    "description": "Success"
  }
}
```

example2

```
{
  "command": "set_config",
  "requestId": "209543",
  "apiVersion": "V1.1",
  "cfgResponse": {
    "wifiConfig": {
      "operation": "MODIFY",
      "accessPoint": {
        "essid": "TEST_5G",
        "connect": true,
        "autoConn": true,
        "enableSecurity": true,
        "isPreferred": true,
        "security": {
          "securityType": "WPA2Personal",
          "securityDetails": {
            "WPA2Personal": {
              "password": "XXXXXXXX"
            }
          }
```

```
        }
      }
    }
  },
  "response": {
    "code": 0,
    "description": "Success"
  }
}
```

example3

```
{
  "command": "set_config",
  "requestId": "209543",
  "apiVersion": "V1.1",
  "cfgResponse": {
    "applyAfterReboot": true,
    "epConfig": {
      "operation": "add",
      "configuration": {
        "endpointName": "gmdm",
        "epType": "MDM",
        "mqttParams": {
          "keepAlive": 300
        }
      }
    }
  },
  "response": {
    "code": 0,
    "description": "Success"
  }
}
```

example4

```
{
  "command": "set_config",
  "requestId": "1233",
  "apiVersion": "V1.1",
  "cfgResponse": {
    "epConfig": {
      "operation": "add",
      "configuration": {
        "endpointName": "dataEP",
        "epType": "DATA1",
        "protocol": "MQTT",
        "activate": true,
        "url": "17L11-GG6663-1",
        "verificationType": "NONE",
```

```
        "port": 1883,
        "qosCommon": 1,
        "tenantId": "ZEBRA",
        "mqttParams": {
          "keepAlive": 300,
          "cleanSession": true,
          "reconnectDelayMin": 50,
          "reconnectDelayMax": 500,
          "clientId": "zebra-rfd40-01",
          "username": "XXXXXXXX",
          "password": "XXXXXXXX"
        }
      }
    }
  },
  "response": {
    "code": 0,
    "description": "Success"
  }
}
```

example5

```
{
  "command": "set_config",
  "requestId": "1234",
  "apiVersion": "V1.1",
  "cfgResponse": {
    "epConfig": {
      "operation": "add",
      "configuration": {
        "endpointName": "ctrlEP",
        "epType": "CTRL",
        "protocol": "MQTT",
        "activate": true,
        "url": "17L11-GG6663-1",
        "verificationType": "NONE",
        "port": 1883,
        "qosCommon": 1,
        "tenantId": "zebra",
        "mqttParams": {
          "keepAlive": 300,
          "cleanSession": true,
          "reconnectDelayMin": 50,
          "reconnectDelayMax": 500,
          "clientId": "zebra-rfd40-01",
          "username": "XXXXXXXX",
          "password": "XXXXXXXX",
          "publishTopics": [
            {
              "topic": "MGMT/clients/cmnd",
              "qos": 0,
              "retain": false
```

```
            }
          ],
          "subscribeTopics": [
            {
              "topic": "MGMT/clients/resp",
              "qos": 1,
              "retain": false
            },
            {
              "topic": "MGMT/clients/event",
              "qos": 1,
              "retain": false
            },
            {
              "topic": "MGMT/clients/rfid",
              "qos": 2,
              "retain": true
            }
          ]
        }
      }
    }
  },
  "response": {
    "code": 0,
    "description": "Success"
  }
}
```

example6

```
{
  "command": "set_config",
  "requestId": "5678",
  "apiVersion": "V1.1",
  "cfgResponse": {
    "wifiConfig": {
      "operation": "CREATE",
      "accessPoint": {
        "essid": "CORP_WIFI",
        "connect": true,
        "autoConn": false,
        "enableSecurity": true,
        "isPreferred": true,
        "security": {
          "securityType": "WPA2Personal",
          "securityDetails": {
            "WPA2Personal": {
              "password": "XXXXXXXX"
            }
          }
        }
      }
```

```
    },
    "epConfig": {
      "operation": "add",
      "configuration": {
        "endpointName": "mgmtEp",
        "epType": "MGMT",
        "protocol": "MQTT",
        "activate": true,
        "url": "iot-broker.company.com",
        "verificationType": "NONE",
        "port": 8883,
        "qosCommon": 1,
        "tenantId": "ZEBRA",
        "mqttParams": {
          "keepAlive": 60,
          "cleanSession": true,
          "reconnectDelayMin": 10,
          "reconnectDelayMax": 120,
          "clientId": "iot",
          "username": "XXXXXXXX",
          "password": "XXXXXXXX",
          "publishTopics": [
            {
              "topic": "IOT/data/cmnd",
              "qos": 1,
              "retain": false
            }
          ],
          "subscribeTopics": [
            {
              "topic": "IOT/data/resp",
              "qos": 1,
              "retain": false
            }
          ]
        }
      }
    }
  },
  "response": {
    "code": 0,
    "description": "Success"
  }
}
```

Status / Error Codes

Code	Status Constant	Description
0	`IOT_STATUS_SUCCESS`	Success
2	`IOT_ERROR_INVALID_PAYLOAD`	Invalid payload

Code	Status Constant	Description
10	`IOT_ERROR_CONFIG_ALREADY_EXIST`	Configuration already exist
15	`IOT_ERROR_SSID_NOT_FOUND`	WIFI Error - SSID not found
17	`IOT_ERROR_SSID_MISSED`	WIFI Error - SSID missed
18	`IOT_ERROR_SSID_ALREADY_EXIST`	WIFI Error - SSID already exist
19	`IOT_ERROR_SSID_LIMIT_OVERFLOW`	WIFI Error - SSID count overflow
20	`IOT_ERROR_WIFI_INTER_NOT_SUPPORTED`	Wifi is not supported
23	`IOT_ERROR_INVALID_ENUM`	Invalid enum value
25	`IOT_ERROR_PUBLISH_TOPICS_EXCEEDED`	Max 3 publish topics exceeded
26	`IOT_ERROR_SUBSCRIBE_TOPIC_EXCEEDED`	Max 1 subscribe topic exceeded
27	`IOT_ERROR_INVALID_TENANTID_LENGTH`	Invalid tenant ID length