get_version

Command: `get_version`

Description

Retrieves the **scanner's identity card** — model, serial number, SKU, and all firmware versions.

Command details:

- Pattern Name: Reader Identity and Firmware Retrieval
- Communication Type: Bidirectional (Cloud to Device, Device to Cloud)
- MQTT Version: 3.1.1
- API Version: V1.1
- Document Version: 1.0.0
- Last Updated: 2026-03-12
- Applies To: RFD40 Series, RFD90 Series

Response fields:

Field	What it tells you
`firmwareVersion`	Main device firmware version
`model`	Scanner model — RFD40 or RFD90
`serialNumber`	Unique device serial number
`sku`	Stock Keeping Unit — encodes model, features, and region (e.g. `RFD4031-G10B700-US`)
`detailedVersions.scannerFirmware`	Barcode scanner module firmware
`detailedVersions.radioFirmware`	RFID radio module firmware
`detailedVersions.iotcVersion`	IoT Connector software version

Typical use cases:

- Inventory — collect model/serial/SKU across all scanners for asset tracking.
- Firmware management — check which scanners need firmware updates.

MQTT topics for this command:

- Command topic (Cloud to Device):

`<tenantId>/CTRL/clients/cmnd/<deviceSerial>`

- Response topic (Device to Cloud):

`<tenantId>/CTRL/clients/resp/<deviceSerial>`

Example:

- Command: `zebra/CTRL/clients/cmnd/RFD40-12345678`
- Response: `zebra/CTRL/clients/resp/RFD40-12345678`

Ensure these topic paths match your configured endpoint topics.

Request

Request Fields

Field	Type	Required	Description	Example
`command`	string (enum)	Yes	Must be `get_version`. Tells the scanner to return its identity and firmware information.	`get_version`
`requestId`	string	Yes	A unique ID you assign to this request. The scanner echoes it back in the response so you can match requests to responses.	`abc123`

Request Examples

Generated Example

```
{
  "command": "get_version",
  "requestId": "abc123"
}
```

Response

Response Fields

Field	Type	Required	Description	Example
`command`	string	Yes	Echoes back the command name — always `get_version` for this response.	
`requestId`	string	Yes	Echoes back the requestId you sent, so you can match this response to your original request.	`abcd123`
`apiVersion`	string (enum)	Yes	The API version of the IoT Connector responding to this command.	`V1.1`
`readerVersion`	object	No	Scanner identity — model, serial number, SKU, and firmware versions for the main device, barcode scanner, RFID radio, and IoT Connector. These values only change after a firmware update.	
`readerVersion.firmwareVersion`	string	Yes	The firmware version of the reader.	`SAAFKS00-006-R02`
`readerVersion.model`	string (enum)	Yes	The model of the reader, such as RFD40 or RFD90.	`RFD40`
`readerVersion.serialNumber`	string	Yes	The serial number of the reader.	`23053520102096`

Field	Type	Required	Description	Example
`readerVersion.sku`	string	Yes	The stock keeping unit (SKU) identifier for the reader.	`RFD4031-G10B700-US`
`readerVersion.detailedVersions`	object	No	Detailed version information for the reader.	
`readerVersion.detailedVersions.scannerFirmware`	string	No	The firmware version of the scanner component.	`PAAEOC20-003-R01`
`readerVersion.detailedVersions.radioFirmware`	string	No	The firmware version of the radio component.	`2.0.42.0`
`readerVersion.detailedVersions.iotcVersion`	string (enum)	No	The version of the IoT Connector (IoTC) software.	`V1.1`
`response`	object	Yes	Status of the command execution — check `code` to confirm success (0) or identify the error.	

Field	Type	Required	Description	Example
`response.code`	integer	Yes	Response code indicating success or failure. • **0** — Success • **1** — Command payload accepted • **2** — Invalid payload • **3** — Not able to retrieve information • **4** — Firmware update in progress • **5** — Can't reboot, inventory in progress • **6** — Region is not configured • **7** — Interface is not available • **8** — Insufficient flash size • **9** — File not found • **10** — Configuration already exists • **11** — Inventory in progress • **12** — No radio operation in progress • **13** — Firmware update failed • **14** — Battery too low for firmware update	`0`

Field	Type	Required	Description	Example
			• **15** — WIFI: SSID not found • **16** — WIFI: Cannot delete active SSID • **17** — WIFI: SSID missing • **18** — WIFI: SSID already exists • **19** — WIFI: SSID count overflow • **20** — WiFi is not supported • **21** — Certificate not found • **22** — Advanced configuration not set • **23** — Invalid enum value • **24** — Max 32 prefilters limit exceeded • **25** — Max 3 publish topics exceeded • **26** — Max 1 subscribe topic exceeded • **27** — Invalid tenant ID length • **28** — Tag match pattern length exceeded	

Field	Type	Required	Description	Example
`response.description`	string	Yes	Human-readable description of the response code (e.g. "Success", "Invalid payload").	`Success`

Response Examples

Device version info

```
{
  "command": "get_version",
  "requestId": "abc123",
  "apiVersion": "V1.1",
  "readerVersion": {
    "firmwareVersion": "PAAFKS00-007-D03",
    "model": "RFD40",
    "serialNumber": "22326520100477",
    "sku": "RFD4031-G10B700-US",
    "detailedVersions": {
      "scannerFirmware": "PAAEOC20-003-R01",
      "radioFirmware": "2.0.42.0",
      "iotcVersion": "V1.1"
    }
  },
  "response": {
    "code": 0,
    "description": "Success"
  }
}
```