

PRINT AT 100% / ACTUAL SIZE (no 'fit to page'). Then measure one square edge to confirm.

CHESSBOARD 10x7 squares (inner corners 9x6) | square = 25.0 mm | board 250x175 mm

