




## MATE3 Flat Mount Kit (FW-MB3-F)


This document contains instructions for installing the MATE3 flat against a wall. The CAT5 cable runs through an electrical outlet box and into the back of the MATE3. This kit can be used when the cable must be concealed inside a wall or brought from one room to another.



## **IMPORTANT: Box Required**

- This kit requires a standard electrical outlet box to be mounted in the wall behind the MATE3. The FW-MB3-F mounting plate must attach to this box. The plate can mount to a double-gang, triple-gang, or quadruple-gang box. The illustrations in this document show a double-gang outlet box.
- The CAT5 cable must be run through the box and made available to plug into the MATE3 before performing this installation (see below).





## **Instructions**

Flat-head Screws

- 1. Place the FW-MB3-F bracket on the surface of the wall. Align the opening in the electrical box with the bracket cutout. Align the FW-MB3-F mounting holes with the mounting holes in the electrical box. In this illustration, the box has four holes. In other box sizes, more holes may be present.
- 2. Thread the CAT5 cable through the bracket cutout.
- 3. Insert one #6 x 1" flat-head screw into each of the mounting holes. (Six screws are provided; not all may be required.) Turn each screw until it is seated in the electrical box's pre-threaded holes. Tighten firmly with a Phillips screwdriver.



- 4. Plug the CAT5 cable into the back of the MATE3. Follow the instructions shown in the *MATE3* Owner's Manual.
- 5. Place the MATE3 against the FW-MB3-F. Align the four mounting holes on the MATE3 with the four pre-threaded inserts on the FW-MB3-F.
- Insert one 8-32 x 1" screw in each of the the MATE3's mounting holes. Turn each screw until it is seated in the FW-MB3-F's inserts. Tighten firmly with a Phillips screwdriver.

The MATE3 is now attached to the electrical box and ready to be used.