Installation DDC_U v125

07.10.2020

- 1.) copy the file "DBBC3 Control DDC_U_v125.exe" in the folder C:\DBBC\bin, overwriting the existing file if necessary
- 2.) copy the firmware-file
 - dbbc3_ddc_U_v125-1hv1_071020_1.bit (for a 1hv1-DBBC3)
 - dbbc3_ddc_U_v125-2hv2_071020_1.bit (for a 2hv2-DBBC3) into the folder C:\DBBC_CONF\FilesDBBC
- 3.) copy the config files
 - dbbc3_config_file_ddc_U_125.txt (check that number of used boards, COM-Ports are correct for your system, adjust if necessary, make sure the correct firmware is selected)
 - ddc_U_core3H_1.fila10g, ddc_U_core3H_2.fila10g,... (make adjustments to Ethernet Configuration in the file if necessary)
 - config_adb3l.txt (only if not already present!)
 - config_ddc_U.txt (adjust frequency setup if necessary) into the folder C:\DBBC_CONF
- 4.) follow the instructions in the manual
 - Setting up the DBBC3 for DDC_U mode_v125.pdf