#### Thermal effects on wellbore stress

Strongly time dependent

$$\frac{\partial T}{\partial t} = \alpha_T \nabla^2 T$$


 $\alpha \rightarrow$  strongly dependent of the silica content of the rock.

Under steady-state conditions,

$$\Delta \sigma_{\theta\theta}^T = \frac{\alpha_T E \Delta T}{1 - \nu}$$




## **Time-temperature effects**






## **Stability through cooling?**



© Cambridge University Press Zoback, *Reservoir Geomechanics* (Fig. 6.14c pp. 194 and Fig. 6.3 pp. 173)




### **Rock strength anisotropy**



© Cambridge University Press Zoback, Reservoir Geomechanics (Fig. 4.12, pp. 106)



## Rock strength anisotropy effects on breakouts




© Cambridge University Press Zoback, Reservoir Geomechanics (Fig. 6.16a,b pp. 199)



#### Two mechanisms

- Stresses exceed intact rock strength
- Stresses activate slip on weak bedding planes



© Cambridge University Press Zoback, Reservoir Geomechanics (Fig. 6.16c pp. 199)



#### **Chemical effects**

• Water Activity  $(A_w \sim \frac{1}{\text{salinity}})$  can to increased pore pressure




a#  $S_{Hmax}$  from breakout data

$$S_{Hmax} = \frac{(C_0 + 2P_p + \Delta P + \Delta \sigma^T) - S_{hmin}(1 + 2\cos(\pi - w_{bo}))}{1 - 2\cos(\pi - w_{bo})}$$



## **Example**




© Cambridge University Press Zoback, Reservoir Geomechanics (Fig. 7.7 pp. 223)



## Wellbore stability




## Defining a "stable" wellbore




© Cambridge University Press Zoback, Reservoir Geomechanics (Fig. 10.1a,b pp. 304)



# **Emperical model: Maximum 90°** breakouts







## **Comprehensive model**

