
Reservoir Depletion



Effects of reservior depletion



© Cambridge University Press Zoback, Reservoir Geomechanics (Fig. 10.21, pp. 380)



Estimating stress changes in depleting reserviors

$$S_{Hor} = S_{Hmax} = S_{hmin} = \frac{\nu}{1 - \nu} S_{\nu} + \alpha P_{p} \left(1 - \frac{\nu}{1 - \nu} \right)$$

$$\frac{\mathrm{d}S_{Hor}}{\mathrm{d}P_p} = \alpha \frac{1 - 2\nu}{\nu - 1}$$
 during production


$$\Delta S_{Hor} = \alpha \frac{1 - 2\nu}{\nu - 1} \Delta P_p$$

Taking $\nu = \frac{1}{4}$ and $\alpha = 1$

$$\Delta S_{Hor} \sim \frac{2}{3} \Delta P_p$$



Comparison of theory and observation



© Cambridge University Press Zoback, Reservoir Geomechanics (Fig. 12.2, pp. 382)



Production induced faulting

$$\frac{S_v - (Pp - \Delta P_p)}{(S_{hmin} - \Delta S_{hmin}) - (Pp - \Delta P_p)} = (\sqrt{\mu^2 + 1} + \mu)^2$$


Simplification leads to

$$\frac{\Delta S_{Hmin}}{\Delta P_p} = 1 - \frac{1}{(\sqrt{\mu^2 + 1} + \mu)^2}$$

For
$$\mu = 0.6$$

$$\frac{\Delta S_{Hmin}}{\Delta P_p} = 0.67$$


Reservoir space plot



© Cambridge University Press Zoback, Reservoir Geomechanics (Fig. 12.4a, pp. 386)




GOM Field X



© Cambridge University Press Zoback, Reservoir Geomechanics (Fig. 12.3ab, pp. 383)






© Cambridge University Press Zoback, Reservoir Geomechanics (Fig. 12.4b, pp. 387)




Valhall field in North Sea



© Cambridge University Press Zoback, Reservoir Geomechanics (Fig. 12.5, pp. 388)



Stress rotations with depletion



Original

Depleted

© Cambridge University Press Zoback, Reservoir Geomechanics (Fig. 12.6ab, pp. 391)



Rotation angle, γ near the fault due to depletion

$$\gamma = \frac{1}{2} \tan^{-1} \left(\frac{Aq \sin(2\theta)}{1 + Aq \cos(2\theta)} \right)$$

with

$$A = \frac{\Delta S_{hmin}}{\Delta P_p}$$

and

$$q = \frac{\Delta P_p}{S_{Hmax} - S_{hmin}}$$

Deformation in depleting reservoirs




Subsidence



Source: Wikimedia Commons -- Public Domain




Recall: Compaction curves



© Cambridge University Press Zoback, Reservoir Geomechanics (Fig. 12.11, pp. 399)



Recall: End-cap models



© Cambridge University Press Zoback, Reservoir Geomechanics (Fig. 4.19, pp. 119)



$$p = \frac{1}{3}(S_1 + S_2 + S_3) - P_p$$

$$q^2 = \frac{1}{2}((S_1 - S_2)^2 + (S_2 - S_3)^2 + (S_1 - S_3)^2))$$

$$M^2p^2 - M^2p_0p + q^2 = 0$$


$$9P_p^2 + \left(1 + \frac{9}{M^2}\right)(S_v^2 + S_{Hmax}^2 + S_{hmin}^2)$$

$$+ \left(2 - \frac{9}{M^2}\right)(S_v S_{Hmax} + S_v S_{hmin} + S_{Hmax} S_{hmin})$$

$$+ 9P_p p_0 - 3(2P_p + p_0)(S_v + S_{Hmax} + S_{hmin}) = 0$$


$$M = \frac{6\mu}{3\sqrt{\mu^2 + 1} - \mu}$$
 From Mohr-Coulomb assuming C_0 is negligible

Deformation Analysis in Reservoir Space (DARS) model of GOM Field X





Permeability change as a function of porosity change



© Cambridge University Press Zoback, Reservoir Geomechanics (Fig. 12.13a, pp. 404)



Modified Kozeny-Carman relationship

$$\kappa = B \frac{(\phi - \phi_c)^3}{(1 + \phi_c - \phi)^2} d^2$$

For change in permeability


$$\frac{\kappa}{\kappa_i} = \left(\frac{\phi - \phi_c}{\phi_i - \phi_c}\right)^3 \left(\frac{1 + \phi_c - \phi_i}{1 + \phi_c - \phi}\right)^2$$

Including a factor for grain size reduction

$$\Gamma = \frac{1 - d/d_i}{1 - \phi/\phi_i}$$

$$\frac{\kappa}{\kappa_i} = \left(\frac{\phi - \phi_c}{\phi_i - \phi_c}\right)^3 \left(\frac{1 + \phi_c - \phi_i}{1 + \phi_c - \phi}\right)^2 \left(1 - \Gamma\left(1 - \frac{\phi}{\phi_i}\right)\right)$$


Permeability loss with depletion in GOM Field Z



© Cambridge University Press Zoback, Reservoir Geomechanics (Fig. 12.14, pp. 408)




Idealized resevoir study



© Cambridge University Press Zoback, Reservoir Geomechanics (Fig. 12.15, pp. 410)



Viscous compaction in GOM Field Z




© Cambridge University Press Zoback, Reservoir Geomechanics (Fig. 12.16, pp. 411)



Geertsma (1973) dispacement solution

$$u_z(r,0) = -\frac{1}{\pi}c_m(1-\nu)\frac{D}{\left(r^2 + D^2\right)^{3/2}}\Delta P_p V$$


$$u_r(r,0) = +\frac{1}{\pi}c_m(1-\nu)\frac{D}{\left(r^2 + D^2\right)^{3/2}}\Delta P_p V$$



© Cambridge University Press Zoback, Reservoir Geomechanics (Fig. 12.17, pp. 414)




Subsidence and horizontal dispacement




© Cambridge University Press Zoback, Reservoir Geomechanics (Fig. 12.17, pp. 414)



Leeville case study





© Cambridge University Press Zoback, Reservoir Geomechanics (Fig. 12.18, pp. 416)

