

```
Code:
int valAdc;
int m;
char x[4];
void main()
UART1_Init(9600);
ADC_Init();
while(1){
   valAdc=ADC_Read(0);
   m=(valAdc/2)-1;
   IntToStr(m,x);
   UART1_Write_Text("Analog Value=");
   UART1_Write_Text(x);
   UART1_Write(13);
   strcpy(x," ");
   delay_ms(1000);
}
}
```